

## FusionSolar App and SUN2000 App

# User Manual

**Issue**        **06**  
**Date**         **2020-04-11**

**Copyright © Huawei Technologies Co., Ltd. 2020. All rights reserved.**

No part of this document may be reproduced or transmitted in any form or by any means without prior written consent of Huawei Technologies Co., Ltd.

## **Trademarks and Permissions**



HUAWEI and other Huawei trademarks are trademarks of Huawei Technologies Co., Ltd.

All other trademarks and trade names mentioned in this document are the property of their respective holders.

## **Notice**

The purchased products, services and features are stipulated by the contract made between Huawei and the customer. All or part of the products, services and features described in this document may not be within the purchase scope or the usage scope. Unless otherwise specified in the contract, all statements, information, and recommendations in this document are provided "AS IS" without warranties, guarantees or representations of any kind, either express or implied.

The information in this document is subject to change without notice. Every effort has been made in the preparation of this document to ensure accuracy of the contents, but all statements, information, and recommendations in this document do not constitute a warranty of any kind, express or implied.

## **Huawei Technologies Co., Ltd.**

Address: Huawei Industrial Base  
Bantian, Longgang  
Shenzhen 518129  
People's Republic of China

Website: <https://e.huawei.com>

# About This Document

## Overview

This document describes the common operations of the FusionSolar app.






## Intended Audience

This document is intended for:

- Installers
- Users

## Symbol Conventions

The symbols that may be found in this document are defined as follows.

Symbol	Description
 <b>DANGER</b>	Indicates an imminently hazardous situation which, if not avoided, will result in death or serious injury.
 <b>WARNING</b>	Indicates a potentially hazardous situation which, if not avoided, could result in death or serious injury.
 <b>CAUTION</b>	Indicates a potentially hazardous situation which, if not avoided, may result in minor or moderate injury.
 <b>NOTICE</b>	Indicates a potentially hazardous situation which, if not avoided, could result in equipment damage, data loss, performance deterioration, or unanticipated results. NOTICE is used to address practices not related to personal injury.
 <b>NOTE</b>	Calls attention to important information, best practices and tips. NOTE is used to address information not related to personal injury, equipment damage, and environment deterioration.

## Change History

Changes between document issues are cumulative. The latest document issue contains all the changes made in earlier issues.

### Issue 06 (2020-04-11)

Updated [4.7 Settings](#).

### Issue 05 (2020-03-15)

Upgraded the SUN2000 app version to SUN2000 app 3.2.00.003.

Upgraded the FusionSolar app version to FusionSolar app 2.5.7.

### Issue 04 (2019-12-18)

Updated [1.1 Introduction to the App](#).

### Issue 03 (2019-11-29)

Upgraded the FusionSolar app version to FusionSolar app 2.5.0.

### Issue 02 (2019-09-10)

Upgraded the FusionSolar app version to FusionSolar app 2.3.5.

### Issue 01 (2019-07-25)

This issue is used for first office application (FOA).

---

# Contents

---

<b>About This Document</b> .....	<b>ii</b>
<b>1 Overview</b> .....	<b>1</b>
1.1 Introduction to the App .....	1
1.2 Downloading and Installing the App .....	1
<b>2 Operations on the FusionSolar APP</b> .....	<b>4</b>
2.1 (Optional) Registering an Installer Account (When No Account Is Available) .....	4
2.2 Setup Wizard.....	5
2.3 How to View Power Station PR .....	5
<b>3 Commissioning Devices</b> .....	<b>9</b>
<b>4 Operations on the Screen for Connecting to the Distributed Solar Inverter</b> .....	<b>11</b>
4.1 Distributed Solar Inverter .....	11
4.2 Login.....	13
4.3 Alarm Management .....	14
4.4 Quick Settings.....	14
4.5 Device Monitoring .....	15
4.6 Maintenance.....	15
4.7 Settings .....	17
4.8 Power Adjustment.....	32
<b>5 Operations on the Screen for Connecting to the Commercial Solar Inverter</b> .....	<b>38</b>
5.1 Commercial Solar Inverter.....	38
5.2 Required Accessories.....	46
5.3 User Operation Permissions.....	47
5.4 Login.....	49
5.5 Screen Operations (Common User) .....	54
5.5.1 Query .....	54
5.5.2 Settings .....	55
5.5.3 Maintenance.....	56
5.5.3.1 System Maintenance .....	56
5.5.3.2 Feedback.....	56
5.5.3.3 Help .....	57
5.5.3.4 About .....	58

5.6 Screen Operations (Advanced User).....	58
5.6.1 Query .....	58
5.6.2 Quick Settings.....	60
5.6.3 Settings .....	60
5.6.3.1 Setting Grid Parameters .....	61
5.6.3.2 Setting Protection Parameters .....	62
5.6.3.3 Setting Feature Parameters .....	62
5.6.3.4 Time setting .....	63
5.6.3.5 Setting Communications Parameters .....	64
5.6.3.6 Setting a Tracking System .....	65
5.6.3.7 Setting a File Save Path .....	67
5.6.4 Power Adjustment.....	67
5.6.5 Maintenance.....	68
5.6.5.1 Device Inspection .....	68
5.6.5.2 License Management .....	69
5.6.5.3 Device Management .....	70
5.6.5.4 PV String Access Detection .....	71
5.6.5.5 Startup and Shutdown .....	72
5.6.5.6 Restoring Factory Settings.....	72
5.6.5.7 Performing an AFCI Self-Check.....	73
5.6.5.8 Resetting a Solar Inverter .....	73
5.6.5.9 Resetting Alarms.....	73
5.6.5.10 Clearing Historical Energy Yield Data.....	74
5.6.5.11 Importing and Exporting Configuration Files .....	74
5.6.5.12 IPS Test.....	74
5.6.5.13 Spot-Check .....	75
5.6.5.14 DC Input Detection.....	76
5.6.5.15 Device Upgrade .....	76
5.6.5.16 Device Logs.....	77
5.6.5.17 Changing the WLAN Password.....	78
5.6.5.18 Feedback.....	79
5.6.5.19 Help .....	80
5.6.5.20 About .....	80
5.7 Screen Operations (Special User).....	81
5.7.1 Query .....	81
5.7.2 Settings .....	83
5.7.2.1 Setting Grid Parameters .....	83
5.7.2.2 Setting Protection Parameters .....	84
5.7.2.3 Setting Feature Parameters .....	85
5.7.2.4 Setting Power Adjustment Parameters.....	86
5.7.2.5 Setting a File Save Path .....	86
5.7.3 Power Adjustment.....	87

5.7.4 Maintenance.....	88
5.7.4.1 Device Management .....	88
5.7.4.2 Startup and Shutdown .....	89
5.7.4.3 Restoring Factory Settings .....	89
5.7.4.4 Device Upgrade .....	90
5.7.4.5 Device Logs .....	90
5.7.4.6 Feedback.....	91
5.7.4.7 Help .....	92
5.7.4.8 About .....	93
<b>6 Operations on the Screen for Connecting to the SmartLogger .....</b>	<b>94</b>
6.1 SmartLogger .....	94
6.2 User Operation Permissions.....	95
6.3 Login.....	98
6.4 Screen Operations (Common User) .....	103
6.4.1 Query .....	103
6.4.2 Settings .....	105
6.4.2.1 Setting the System Date and Time .....	105
6.4.2.2 Setting Plant Information.....	106
6.4.2.3 Setting Revenue Parameters .....	106
6.4.3 Maintenance.....	107
6.4.3.1 System Maintenance .....	107
6.4.3.2 Feedback.....	107
6.4.3.3 Help .....	109
6.4.3.4 About .....	109
6.4.4 Device Monitoring.....	110
6.4.4.1 Query .....	110
6.4.4.2 Maintenance.....	111
6.5 Screen Operations (Advanced User).....	112
6.5.1 Query .....	112
6.5.2 Settings .....	113
6.5.2.1 Setting the System Date and Time .....	114
6.5.2.2 Setting Plant Information.....	115
6.5.2.3 Setting Revenue Parameters .....	115
6.5.2.4 Setting Ethernet Parameters.....	116
6.5.2.5 Setting RS485 Parameters .....	116
6.5.2.6 Setting Modbus-RTU Power Meter Parameters.....	117
6.5.2.7 Setting Management System Parameters .....	118
6.5.2.8 Setting Modbus TCP Parameters .....	119
6.5.2.9 Setting IEC103 Device Parameters.....	120
6.5.2.10 Setting IEC104 Device Parameters.....	120
6.5.2.11 Setting FTP Parameters.....	121

6.5.2.12 Setting Email Parameters .....	122
6.5.2.13 Setting a File Save Path .....	123
6.5.3 Maintenance.....	123
6.5.3.1 Solar Inverter Inspection.....	123
6.5.3.2 System Maintenance .....	124
6.5.3.2.1 Changing a User Password .....	124
6.5.3.2.2 Resetting the System.....	125
6.5.3.2.3 Clearing Data .....	126
6.5.3.2.4 Generating the Local Maintenance Script.....	127
6.5.3.2.5 Offline Configuration.....	128
6.5.3.2.6 Importing and Exporting All Files .....	129
6.5.3.2.7 Restoring Factory Settings .....	130
6.5.3.3 Device Management .....	131
6.5.3.3.1 Changing a Device Name .....	131
6.5.3.3.2 Deleting Devices.....	132
6.5.3.3.3 Automatically Searching for Devices .....	133
6.5.3.3.4 Manually Adding a Device .....	134
6.5.3.3.5 Automatically Allocating Addresses .....	135
6.5.3.3.6 Importing Configuration .....	135
6.5.3.3.7 Exporting Configuration .....	136
6.5.3.3.8 Resetting Alarms.....	137
6.5.3.3.9 Starting, Shutting down, and Resetting Solar Inverters in Batches.....	137
6.5.3.3.10 Setting Access Parameter .....	138
6.5.3.4 Managing the Device List.....	139
6.5.3.5 Exporting Device Logs .....	139
6.5.3.6 Device Upgrade .....	140
6.5.3.7 Spot-Checking Solar Inverters .....	141
6.5.3.8 Feedback.....	142
6.5.3.9 Help .....	143
6.5.3.10 About .....	144
6.5.4 Device Monitoring.....	145
6.5.4.1 Query .....	145
6.5.4.2 Settings .....	146
6.5.4.3 Maintenance.....	146
6.5.4.3.1 Log Download .....	146
6.5.4.3.2 Solar Inverter Maintenance.....	147
6.5.4.3.3 MBUS Maintenance .....	147
6.5.4.3.4 PID Module Maintenance .....	147
6.6 Screen Operations (Special User) .....	148
6.6.1 Query .....	148
6.6.2 Settings .....	149
6.6.2.1 Setting RS485 Parameters .....	149



6.6.2.2 Active Power Control.....	150
6.6.2.3 Setting Modbus-RTU Power Meter Parameters.....	151
6.6.2.4 Remotely Shutting Down Solar Inverters in Dry Contact Mode .....	151
6.6.2.5 Setting Reactive Power Control.....	152
6.6.3 Maintenance.....	152
6.6.3.1 Solar Inverter Inspection.....	152
6.6.3.2 System Maintenance .....	153
6.6.3.2.1 Changing a User Password .....	153
6.6.3.2.2 Resetting the System.....	154
6.6.3.2.3 Clearing Data .....	155
6.6.3.2.4 Generating the Local Maintenance Script.....	156
6.6.3.2.5 Restoring Factory Settings .....	157
6.6.3.3 Device Management .....	158
6.6.3.3.1 Changing a Device Name .....	158
6.6.3.3.2 Deleting Devices.....	159
6.6.3.3.3 Automatically Searching for Devices .....	160
6.6.3.3.4 Manually Adding a Device .....	161
6.6.3.3.5 Automatically Allocating Addresses .....	162
6.6.3.3.6 Importing Configuration .....	162
6.6.3.3.7 Exporting Configuration .....	163
6.6.3.3.8 Resetting Alarms.....	164
6.6.3.3.9 Starting, Shutting down, and Resetting Solar Inverters in Batches.....	164
6.6.3.3.10 Setting Access Parameter .....	165
6.6.3.4 Managing the Device List.....	166
6.6.3.5 Exporting Device Logs .....	166
6.6.3.6 Device Upgrade .....	167
6.6.3.7 Spot-Checking Solar Inverters .....	168
6.6.3.8 Feedback.....	169
6.6.3.9 Help .....	170
6.6.3.10 About .....	171
6.6.4 Device Monitoring.....	172
6.6.4.1 Query .....	172
6.6.4.2 Settings .....	173
6.6.4.3 Maintenance.....	173
6.6.4.3.1 Log Download .....	173
6.6.4.3.2 Solar Inverter Maintenance.....	174
<b>7 Operations on the Screen for Connecting to the PID Module .....</b>	<b>175</b>
7.1 PID Module .....	175
7.2 Required Accessories.....	176
7.3 User Operation Permissions.....	176
7.4 Login.....	178

7.5 Screen Operations (Common User) .....	182
7.5.1 Query .....	182
7.5.2 Settings .....	183
7.5.3 Maintenance.....	183
7.5.3.1 Feedback.....	183
7.5.3.2 Help .....	184
7.5.3.3 About .....	185
7.6 Screen Operations (Advanced User).....	186
7.6.1 Query .....	186
7.6.2 Settings .....	188
7.6.2.1 Setting Protection Parameters .....	188
7.6.2.2 Setting Feature Parameters .....	189
7.6.2.3 Setting User Parameters.....	191
7.6.2.4 Setting Communications Parameters .....	192
7.6.2.5 Setting a File Save Path .....	192
7.6.3 Maintenance.....	193
7.6.3.1 Log Download .....	193
7.6.3.2 System Maintenance .....	194
7.6.3.3 Device Upgrade .....	195
7.6.3.4 Feedback.....	196
7.6.3.5 Help .....	197
7.6.3.6 About .....	198
7.7 Screen Operations (Special User).....	199
7.7.1 Query .....	199
7.7.2 Settings .....	201
7.7.2.1 Setting User Parameters.....	201
7.7.2.2 Setting a File Save Path .....	201
7.7.3 Maintenance.....	202
7.7.3.1 Log Download .....	202
7.7.3.2 System Maintenance .....	203
7.7.3.3 Device Upgrade .....	203
7.7.3.4 Feedback.....	204
7.7.3.5 Help .....	205
7.7.3.6 About .....	206
<b>8 SUN2000 APP Tool Kit.....</b>	<b>207</b>
8.1 Device Software Update .....	207
8.2 MBUS Whitelist .....	208
8.3 Local Maintenance Script .....	211
8.3.1 Solar Inverter Maintenance Script .....	211
8.3.2 SmartLogger Maintenance Script .....	212
8.4 File Management .....	213

---

8.5 About .....	214
<b>9 Troubleshooting .....</b>	<b>216</b>
<b>10 FAQs .....</b>	<b>219</b>
10.1 Setting the Email on the Mobile Phone .....	219
10.2 Changing the App Login Password.....	222
10.3 How Do I Set a User-Defined Grid Code .....	223
10.4 How Do I Fix WLAN Connection Failure.....	224
<b>A Commercial Smart Inverters Parameters.....</b>	<b>225</b>
A.1 Grid parameters.....	225
A.1.1 Advanced User.....	225
A.1.2 Special User .....	225
A.2 Protection Parameters .....	227
A.2.1 Advanced User.....	227
A.2.2 Special User .....	227
A.3 Feature parameters .....	230
A.3.1 Advanced User.....	230
A.3.2 Special User .....	235
A.4 Power adjustment parameters .....	237
A.4.1 Special User .....	237
A.5 Grid-tied control parameters .....	242
<b>B Domain Name List of Management Systems .....</b>	<b>244</b>
<b>C Acronyms and Abbreviations .....</b>	<b>245</b>

# 1 Overview

---

## 1.1 Introduction to the App

### Introduction to the FusionSolar app

The FusionSolar app is the software used to manage PV plants. On the FusionSolar app, you can create PV plants, and manage devices for solar inverters.

### Introduction to the SUN2000 app

The SUN2000 app is a mobile application that communicates with commercial solar inverters or PID modules over WLAN/Bluetooth or a USB data cable, communicates with the SmartLogger over WLAN/Bluetooth, and communicates with distributed solar inverters over WLAN. The app allows you to query alarms, configure parameters, and perform routine maintenance. It is a convenient platform for maintenance. The app name is displayed as **SUN2000**.

## 1.2 Downloading and Installing the App

### Downloading and Installing the FusionSolar app

### NOTICE

- The FusionSolar app will not be evolved in App Store (iOS) since 2.3.3. For new products and functions, use 2.5.1 or later versions in the Android system.
- The latest Android version is required for local commissioning. The iOS version is not updated and can be used only for viewing PV plant information. You can search for "FusionSolar" in App Store to download the iOS version.
- Delivering a restart, factory reset, shutdown, or upgrade command to the solar inverters may cause power grid connection failure, which affects the energy yield.
- Only professionals are allowed to set the grid parameters, protection parameters, feature parameters, power adjustment parameters, and grid-tied point control parameters of the solar inverters. If the grid parameters, protection parameters, and feature parameters are incorrectly set, the solar inverters may not connect to the power grid. If the power adjustment parameters and grid-tied point control parameters are incorrectly set, the solar inverters may not connect to the power grid as required. In these cases, the energy yield will be affected.

Search for **FusionSolar** in Google Play (Android) to download and install the app. You can also scan one of the following QR codes to obtain the app. The screenshots in this document correspond to app version 2.5.7.



### NOTE

- Mobile phone operating system: Android 4.4 or later.
- Recommended phone brands: Huawei and Samsung.
- The mobile phone supports the access to the Internet over a web browser.
- WLAN supported.
- The router supports WLAN (IEEE 802.11 b/g/n, 2.4 GHz) and the WLAN signal reaches the inverters.
- The WPA, WPA2, or WPA/WPA2 encryption mode is recommended for routers. The Enterprise mode is not supported (such as airport WLAN and other public hotspots that require authentication). WEP and WPA TKIP are not recommended because they have serious security vulnerabilities. If the access fails in WEP mode, log in to the router and change the encryption mode of the router to WPA2 or WPA/WPA2.

## Downloading and Installing the SUN2000 app

### NOTICE

The SUN2000 app will not be evolved in App Store (iOS) since 2.2.00.050. For new products and functions, use 3.2.00.002 or later versions in the Android system.


You can search for **SUN2000** in the Huawei AppGallery or scan the corresponding QR code (<https://solar.huawei.com/~media/Solar/APP/SUN2000.apk>), download the SUN2000 app installation package. After the installation package is downloaded, tap **Install** to install the app as instructed.



# 2 Operations on the FusionSolar APP

## 2.1 (Optional) Registering an Installer Account (When No Account Is Available)


- Creating the first installer account will generate a domain named after the company.



### NOTE

The email address is the user name for logging in to the FusionSolar app.

- To create multiple installer accounts for a company, log in to the app and create an installer account by choosing **New User**.



## 2.2 Setup Wizard

### NOTE

- Use the initial password upon first power-on and change it immediately after login. To ensure account security, change the password periodically and keep the new password in mind. Not changing the initial password may cause password disclosure. A password left unchanged for a long period of time may be stolen or cracked. If a password is lost, devices cannot be accessed. In these cases, the user is liable for any loss caused to the PV plant.

For details about how to set the setup wizard, see the *FusionSolar App Quick Guide*. The FusionSolar app UI may be different due to version upgrade or other reasons. You can scan the QR code on the browser to obtain the latest *FusionSolar App Quick Guide*.



## 2.3 How to View Power Station PR

Log in to the FusionSolar app and go to the home screen to learn about the PV plant overview.

### Permission


- After you log in to the app, you have the following permissions: **Home**, **O&M**, **Device**, and **My**. If a user is not assigned with a certain permission, the user cannot perform corresponding operations after logging in to the app.



- After you create an account and log in to the app for the first time, read the privacy policy and tap **OK**. After a dialog box is displayed, change the login password to ensure account security.
- When the app is in use, the location function works, which will increase the power consumption.
- Before using the app on a mobile phone, ensure that the phone has the following permissions. Otherwise, the app cannot be used properly.
  - a. Permission to access a WLAN or 2G/3G/4G carrier network. This permission is required when you are using the app.
  - b. Permission to obtain user location information.
    - After a mobile O&M engineer logs in to the app, the system reports the location information.
    - When a mobile inspection task is started, the location information is reported before the task is stopped.
    - When you add or modify a PV plant, the system obtains the current location information by default when you enter the PV plant location information.
  - c. Permission to use the camera. You must have this permission if you want to take photos using the camera or upload photos from the photo album to the app.
  - d. Permission to read, modify, or delete SD card content. You must have this permission to record logs of exceptions.

## UI Description

After you log in to the app, the following screen is displayed. [Table 2-1](#) describes the screen. [Table 2-4](#) describes the icons on the home screen.



**Table 2-1** UI description

Function	Description
Home	<p>On the <b>Plant</b> screen, tap a PV plant name to view its real-time information and the PV plant view.</p> <p>The <b>Statistics</b> screen displays the energy yield, revenue statistics, PV plant ranking on the current day, and social contribution.</p> <p>The PV plant KPI data, PV plant status, and real-time alarms are displayed in sequence in the upper part of the screen.</p>
O&M	The <b>O&amp;M</b> screen displays the PV plant status, device alarms, diagnosis warning, online diagnosis, I-V curve, and mobile O&M.
Device	The <b>Device</b> screen displays the device information, and is used to set device parameters and replace devices.
My	The <b>My</b> screen displays the user information, messages, local commissioning tool, PV plant management, owner management, company information, and personal settings.











**Table 2-2** KPI parameters of a PV plant

Parameter	Description
Energy/hour	Last value – First value (energy yield of all solar inverters during the hour).
Energy/day	Sum of the last valid values of all solar inverters during the day.
Energy/month	Sum of the last valid values of all solar inverters during the month.
Energy/year	Sum of the last valid values of all solar inverters during the year.
Revenue/hour	Energy/hour x Current tariff.
Revenue/day	Sum of the revenue per hour on the current day.
Revenue/month	Sum of the revenue per day in the current month.
Revenue/year	Sum of the revenue per month in the current year.
Lifetime	Collects statistics on the energy yield and revenue of each year for the connected PV plant.

**Table 2-3** Description of the energy flow diagram

Parameter	Description	Parameter	Description
PV	Indicates the PV strings. The generated electricity is equal to the PV string power.	Inverter	Converts DC power generated by PV strings into AC power.
Battery	Stores the remaining power.	Power Load	Indicates the power consumption of the PV plant. Power load = Output power – On-grid power.
Meter	Indicates the AC power distribution unit.	Grid	Indicates the low-voltage power grid.
Output	Indicates the output power of the solar inverter.	On-grid Power	Indicates the output power of the PV plant. $PV \text{ string power} \geq \text{On-grid power} + \text{Battery power}$

**Table 2-4** Icons on the home screen


Icon	Description
	Tap  to create a PV plant.
	Tap  to add a user.
	Tap  to view the PV plant distribution on a map.
	Tap  to search for PV plants.
	Tap  to filter the PV plants to be displayed.

# 3 Commissioning Devices


Access device commissioning:

Method 1: (SUN2000 App) open SUN2000 App

Method 2: (FusionSolar App) mobile phone connected to the Internet



Method 3: (FusionSolar App) mobile phone not connected to the Internet



**NOTE**

Method 3 is available only when no network is available. You are advised to use method 2 to log in to the FusionSolar app to commission devices.

# 4 Operations on the Screen for Connecting to the Distributed Solar Inverter

## NOTICE

- The app screenshots provided in this chapter correspond to the SUN2000 app 3.2.00.003 version. The data on the screenshots is for reference only.
- Delivering a reset, factory reset, shutdown, or upgrade command to the solar inverters may cause power grid connection failure, which affects the energy yield.
- Only professionals are allowed to set the grid parameters, protection parameters, feature parameters, power adjustment parameters, and grid-tied point control parameters of the solar inverters. If the grid parameters, protection parameters, and feature parameters are incorrectly set, the solar inverters may not connect to the power grid. If the power adjustment parameters and grid-tied point control parameters are incorrectly set, the solar inverters may not connect to the power grid as required. In these cases, the energy yield will be affected.

## 4.1 Distributed Solar Inverter

### Connection Modes

After the DC or AC side of the solar inverter is powered on, the app can connect to the solar inverter through the built-in WLAN of the solar inverter.

**Table 4-1** Product mapping (Android)

Solar Inverter Model	Version	App Version
SUN2000L-(2KTL-5KTL)	SUN2000L V100R001C00	3.2.00.003
SUN2000-(2KTL-5KTL)-L0	SUN2000L V100R001C00	


Solar Inverter Model	Version	App Version
SUN2000-(3.8KTL-11.6KTL)-USL0	SUN2000L V100R001C10	
SUN2000L-(4.125KTL-4.95KTL)-JP	SUN2000L V100R001C12SPC107 and later versions	
SUN2000L-(3KTL-5KTL)-CN	SUN2000L V100R001C00SPC114 and later versions	
SUN2000-(8KTL-12KTL)	SUN2000MA V100R001C00	
SUN2000-(3KTL-20KTL)-M0	SUN2000MA V100R001C00	

 **NOTE**

The version mapping in the preceding table is subject to change and is for reference only.

## 4.2 Login

### Login




#### NOTE

- Use the initial password upon first power-on and change it immediately after login. To ensure account security, change the password periodically and keep the new password in mind. Not changing the initial password may cause password disclosure. A password left unchanged for a long period of time may be stolen or cracked. If a password is lost, devices cannot be accessed. In these cases, the user is liable for any loss caused to the PV plant.
- To change the WLAN password of the solar inverter, see [Communication Configuration](#).
- To change the app login password, see [10.2 Changing the App Login Password](#).
- If you enter wrong login passwords for **installer** for five consecutive times and the interval between two attempts is within two minutes, your account will be locked. Log in to the app again after 5 minutes.




## 4.3 Alarm Management

On the home screen, tap **Alarm management**. You can query active and historical alarms.



## 4.4 Quick Settings

On the home screen, tap **Quick Settings**. Set parameters as prompted.




**NOTE**

The UI is for reference only. The UI varies with associated devices. The actual UI prevails.

## 4.5 Device Monitoring

On the home screen, tap **Device Monitoring**. Then tap a tab in the lower part of the screen as required to view related information.


**Figure 4-1** Device information



## 4.6 Maintenance

On the home screen, tap **Maintenance** to set device parameters.

**Figure 4-2** Maintaining devices



**NOTE**

The parameter list provided in this document includes all configurable parameters that vary with the device model and grid code. The actual screen prevails.


Parameter	Description	Parameter	Description
Add/Delete device	Adds power meters, batteries, optimizers, or safety shutdown boxes as required.	IPS test	Performs IPS self-check and generates a self-check report.
Physical Layout of PV Modules	Specifies the physical location of the optimizer.	Inverter ON/OFF	Sends a command to start or shut down the solar inverter based on its current startup or shutdown status.
Upgrade device	Upgrades the software version of devices such as the solar inverter as required.	Restore defaults	Restores the solar inverter parameters to factory settings.
Log Management	Downloads the logs of the solar inverters, batteries, optimizers, or the app.	Clear data	Clears historical data of the solar inverter.
Performance data	Views the performance data of devices such as power meters.	Adjust total energy yield	Specifies the initial energy yield of the solar inverter. This parameter is used in solar inverter replacement scenarios. Set the initial energy yield of the new solar inverter to the total energy yield of the old solar inverter to ensure continuous statistics of cumulative energy yield.
Alarm beacon	If this parameter is enabled, the alarm beacon produces audible and visual signals when the solar inverter generates an alarm.	Restart	Restarts the solar inverter.

Parameter	Description	Parameter	Description
AFCI self-test	Performs the AFCI self-test.	N/A	N/A

## 4.7 Settings

On the home screen, tap **Settings** to set solar inverter parameters.

**Figure 4-3** Settings



### NOTE

- The parameter list provided in this document includes all configurable parameters that vary with the device model and grid code. The actual screen prevails.
- The parameters are for reference only. The configurable parameters vary with the device model and grid code. The actual configurable parameters prevail.
- The parameter names, value ranges, and default values are subject to change.

## Grid Parameters

Parameter	Description	Value Range (Vn: Rated Voltage; Fn: Rated Frequency)
Grid Code	Set this parameter based on the grid code of the country or region where the inverter is used and the inverter application scenario.	N/A

Parameter	Description	Value Range (Vn: Rated Voltage; Fn: Rated Frequency)
Isolation settings	Set the working mode of the inverter based on the grounding status at DC side and the connection to the power grid.	<ul style="list-style-type: none"> <li>• Input ungrounded, without TF</li> <li>• Input ungrounded, with TF</li> </ul>
Output mode	Specifies whether the inverter output has a neutral wire based on the application scenario.	<ul style="list-style-type: none"> <li>• Three-phase three-wire</li> <li>• Three-phase four-wire</li> <li>• L/N</li> <li>• L1/L2/N</li> <li>• L1/L2</li> </ul>
Automatically start upon grid recovery	Specifies whether to allow the inverter to automatically start after the power grid recovers.	<ul style="list-style-type: none"> <li>• Disable</li> <li>• Enable</li> </ul>
Grid connected recovery time from grid faults (s)	Specifies the time after which the inverter begins connecting after the power grid recovers.	[0, 7200]
Grid reconnection voltage upper limit (V)	The standards of certain countries and regions require that after the inverter shuts down for protection due to a fault, if the power grid voltage is higher than <b>Grid reconnection voltage upper limit</b> , the inverter is not allowed to reconnect to the grid.	[100% Vn, 136% Vn]
Grid reconnection voltage lower limit (V)	The standards of certain countries and regions require that after the inverter shuts down for protection due to a fault, if the power grid voltage is lower than <b>Grid reconnection voltage lower limit</b> , the inverter is not allowed to reconnect to the grid.	[45% Vn, 100% Vn]
Grid reconnection frequency upper limit (Hz)	The standards of certain countries and regions require that after the inverter shuts down for protection due to a fault, if the power grid frequency is higher than <b>Grid reconnection frequency upper limit</b> , the inverter is not allowed to reconnect to the grid.	[100% Fn, 120% Fn]
Grid reconnection frequency lower limit (Hz)	The standards of certain countries and regions require that after the inverter shuts down for protection due to a fault, if the power grid frequency is lower than <b>Grid reconnection frequency lower limit</b> , the inverter is not allowed to reconnect to the grid.	[80% Fn, 100% Fn]

Parameter	Description	Value Range (Vn: Rated Voltage; Fn: Rated Frequency)
Reactive power compensation (cosφ-P) trigger voltage (%)	Specifies the voltage threshold for triggering reactive power compensation based on the cosφ-P curve.	[100, 136]
Reactive power compensation (cosφ-P) exit voltage (%)	Specifies the voltage threshold for exiting reactive power compensation based on the cosφ-P curve.	[70, 100]

## Protection Parameters

Parameter	Description	Value Range (Vn: Rated Voltage; Fn: Rated Frequency)
Insulation resistance protection threshold (MΩ)	To ensure device safety, the inverter detects the insulation resistance of the input side with respect to ground when it starts a self-check. If the detected value is less than the preset value, the inverter does not connect to the grid.	[0.02, 1.5]
Voltage unbalance protection threshold (%)	Specifies the inverter protection threshold when the power grid voltage is unbalanced.	[0, 50]
Phase protection point (°)	The Japanese standard requires that during passive islanding detection, protection should be triggered if an abrupt voltage phase change is detected.	[0.5, 15]
Phase angle offset protection	The standards of certain countries and regions require that the inverter needs to be protected when the phase angle offset of the power grid three phases exceeds a certain value.	<ul style="list-style-type: none"> <li>• Disable</li> <li>• Enable</li> </ul>
10-min overvoltage protection threshold (V)	Specifies the 10-minute overvoltage protection threshold.	[1 * Vn, 1.5 * Vn]
10-min overvoltage protection duration (ms)	Specifies the 10-minute overvoltage protection duration.	[50, 7200000]
Level-1 overvoltage protection threshold (V)	Specifies the level-1 overvoltage protection threshold.	[1 * Vn, 1.5 * Vn]
Level-1 overvoltage protection duration (ms)	Specifies the level-1 overvoltage protection duration.	[50, 7200000]
Level-2 overvoltage protection threshold (V)	Specifies the level-2 overvoltage protection threshold.	[1 * Vn, 1.5 * Vn]

<b>Parameter</b>	<b>Description</b>	<b>Value Range (Vn: Rated Voltage; Fn: Rated Frequency)</b>
Level-2 overvoltage protection duration (ms)	Specifies the level-2 overvoltage protection duration.	[50, 7200000]
Level-3 overvoltage protection threshold (V)	Specifies the level-3 overvoltage protection threshold.	[1 * Vn, 1.5 * Vn]
Level-3 overvoltage protection duration (ms)	Specifies the level-3 overvoltage protection duration.	[50, 7200000]
Level-4 overvoltage protection threshold (V)	Specifies the level-4 overvoltage protection threshold.	[1 * Vn, 1.5 * Vn]
Level-4 overvoltage protection duration (ms)	Specifies the level-4 overvoltage protection duration.	[50, 7200000]
Level-5 overvoltage protection threshold (V)	Specifies the level-5 overvoltage protection threshold.	[1 * Vn, 1.5 * Vn]
Level-5 overvoltage protection duration (ms)	Specifies the level-5 overvoltage protection duration.	[50, 7200000]
Level-6 overvoltage protection threshold (V)	Specifies the level-6 overvoltage protection threshold.	[1 * Vn, 1.5 * Vn]
Level-6 overvoltage protection duration (ms)	Specifies the level-6 overvoltage protection duration.	[50, 7200000]
Level-1 undervoltage protection threshold (V)	Specifies the level-1 undervoltage protection threshold.	[0.15 * Vn, 1 * Vn]
Level-1 undervoltage protection duration (ms)	Specifies the level-1 undervoltage protection duration.	[50, 7200000]
Level-2 undervoltage protection threshold (V)	Specifies the level-2 undervoltage protection threshold.	[0.15 * Vn, 1 * Vn]
Level-2 undervoltage protection duration (ms)	Specifies the level-2 undervoltage protection duration.	[50, 7200000]
Level-3 undervoltage protection threshold (V)	Specifies the level-3 undervoltage protection threshold.	[0.15 * Vn, 1 * Vn]
Level-3 undervoltage protection duration (ms)	Specifies the level-3 undervoltage protection duration.	[50, 7200000]
Level-4 undervoltage protection threshold (V)	Specifies the level-4 undervoltage protection threshold.	[0.15 * Vn, 1 * Vn]
Level-4 undervoltage protection duration (ms)	Specifies the level-4 undervoltage protection duration.	[50, 7200000]
Level-5 undervoltage protection threshold (V)	Specifies the level-5 undervoltage protection threshold.	[0.15 * Vn, 1 * Vn]

Parameter	Description	Value Range (Vn: Rated Voltage; Fn: Rated Frequency)
Level-5 undervoltage protection duration (ms)	Specifies the level-5 undervoltage protection duration.	[50, 7200000]
Level-6 undervoltage protection threshold (V)	Specifies the level-6 undervoltage protection threshold.	[0.15 * Vn, 1 * Vn]
Level-6 undervoltage protection duration (ms)	Specifies the level-6 undervoltage protection duration.	[50, 7200000]
Level-1 overfrequency protection threshold (Hz)	Specifies the level-1 overfrequency protection threshold.	[1 * Fn, 1.2 * Fn]
Level-1 overfrequency protection duration (ms)	Specifies the level-1 overfrequency protection duration.	[50, 7200000]
Level-2 overfrequency protection threshold (Hz)	Specifies the level-2 overfrequency protection threshold.	[1 * Fn, 1.2 * Fn]
Level-2 overfrequency protection duration (ms)	Specifies the level-2 overfrequency protection duration.	[50, 7200000]
Level-3 overfrequency protection threshold (Hz)	Specifies the level-3 overfrequency protection threshold.	[1 * Fn, 1.2 * Fn]
Level-3 overfrequency protection duration (ms)	Specifies the level-3 overfrequency protection duration.	[50, 7200000]
Level-4 overfrequency protection threshold (Hz)	Specifies the level-4 overfrequency protection threshold.	[1 * Fn, 1.2 * Fn]
Level-4 overfrequency protection duration (ms)	Specifies the level-4 overfrequency protection duration.	[50, 7200000]
Level-5 overfrequency protection threshold (Hz)	Specifies the level-5 overfrequency protection threshold.	[1 * Fn, 1.2 * Fn]
Level-5 overfrequency protection duration (ms)	Specifies the level-5 overfrequency protection duration.	[50, 7200000]
Level-6 overfrequency protection threshold (Hz)	Specifies the level-6 overfrequency protection threshold.	[1 * Fn, 1.2 * Fn]
Level-6 overfrequency protection duration (ms)	Specifies the level-6 overfrequency protection duration.	[50, 7200000]
Level-1 underfrequency protection threshold (Hz)	Specifies the level-1 underfrequency protection threshold.	[0.8 * Fn, 1 * Fn]
Level-1 underfrequency protection duration (ms)	Specifies the level-1 underfrequency protection duration.	[50, 7200000]
Level-2 underfrequency protection threshold (Hz)	Specifies the level-2 underfrequency protection threshold.	[0.8 * Fn, 1 * Fn]



Parameter	Description	Value Range (Vn: Rated Voltage; Fn: Rated Frequency)
Level-2 underfrequency protection duration (ms)	Specifies the level-2 underfrequency protection duration.	[50, 7200000]
Level-3 underfrequency protection threshold (Hz)	Specifies the level-3 underfrequency protection threshold.	[0.8 * Fn, 1 * Fn]
Level-3 underfrequency protection duration (ms)	Specifies the level-3 underfrequency protection duration.	[50, 7200000]
Level-4 underfrequency protection threshold (Hz)	Specifies the level-4 underfrequency protection threshold.	[0.8 * Fn, 1 * Fn]
Level-4 underfrequency protection duration (ms)	Specifies the level-4 underfrequency protection duration.	[50, 7200000]
Level-5 underfrequency protection threshold (Hz)	Specifies the level-5 underfrequency protection threshold.	[0.8 * Fn, 1 * Fn]
Level-5 underfrequency protection duration (ms)	Specifies the level-5 underfrequency protection duration.	[50, 7200000]
Level-6 underfrequency protection threshold (Hz)	Specifies the level-6 underfrequency protection threshold.	[0.8 * Fn, 1 * Fn]
Level-6 underfrequency protection duration (ms)	Specifies the level-6 underfrequency protection duration.	[50, 7200000]

## Feature Parameters

Parameter	Description	Value Range (Vn: Rated Voltage; Fn: Rated Frequency)	Remarks
MPPT multi-peak scanning	When the inverter is used in scenarios where PV strings are greatly shaded, set this parameter to <b>Enable</b> , and then the inverter will perform MPPT scanning at regular intervals to locate the maximum power.	<ul style="list-style-type: none"> <li>• Disable</li> <li>• Enable</li> </ul>	N/A
MPPT multi-peak scan interval (min)	Specifies the MPPT scanning interval.	[5, 30]	This parameter is displayed when <b>MPPT multi-peak scan interval</b> is set to <b>Enable</b> .

Parameter	Description	Value Range (Vn: Rated Voltage; Fn: Rated Frequency)	Remarks
Automatic OFF due to communication interrupted	The standards of certain countries and regions require that the inverter must shut down after the communication is interrupted for a certain time.	<ul style="list-style-type: none"><li>• Disable</li><li>• Enable</li></ul>	If <b>Automatic OFF due to communication interrupted</b> is set to Enable and the inverter communication is interrupted for a specified time (set by <b>Communication interruption duration</b> ), the inverter will automatically shut down.
Communication interruption duration (min)	Specifies the duration for determining communication interruption. Used for automatic shutdown for protection in case of communication interruption.	[1, 120]	N/A
Automatic ON due to communication resume	If this parameter is set to <b>Enable</b> , the inverter automatically starts after communication recovers. If this parameter is set to <b>Disable</b> , the inverter needs to be started manually after communication recovers.	<ul style="list-style-type: none"><li>• Disable</li><li>• Enable</li></ul>	This parameter is displayed when <b>Automatic OFF due to communication interrupted</b> is set to <b>Enable</b> .
Soft start/boot time (s)	Specifies the duration for the power to gradually increase when the inverter starts.	[1, 1800]	N/A
AFCI	The North American standard requires that the inverter should have DC arc detection function.	<ul style="list-style-type: none"><li>• Disable</li><li>• Enable</li></ul>	N/A
AFCI detection adaptation mode	This function is used to adjust the sensitivity of arc detection.	<ul style="list-style-type: none"><li>• High</li><li>• Moderate</li><li>• Low</li></ul>	This parameter is displayed when <b>AFCI</b> is set to Enable.

Parameter	Description	Value Range (Vn: Rated Voltage; Fn: Rated Frequency)	Remarks
OFF due to abnormal ground	This function is used to check whether the solar inverter is properly grounded before the solar inverter starts, or check whether the solar inverter ground cable is disconnected when the solar inverter is running. By default, this parameter is set to <b>Enable</b> . If the solar inverter cannot be grounded properly, it shuts down.	<ul style="list-style-type: none"><li>• Disable</li><li>• Enable</li></ul>	For certain power grid types, if the output side of the solar inverter is connected to an isolation transformer, grounding detection is not required. Ensure that the solar inverter is properly grounded and set the parameter to <b>Disable</b> to enable the solar inverter to run properly. If you are not sure whether the solar inverter is connected to such a type of power grid, contact your dealer or Huawei technical support for confirmation.
Delay upgrade	This parameter is mainly used in the upgrade scenarios where the PV power supply is disconnected at night due to no sunlight or unstable at dawn or dusk due to poor sunlight.	<ul style="list-style-type: none"><li>• Disable</li><li>• Enable</li></ul>	After the inverter starts to upgrade, if <b>Delay upgrade</b> is set to <b>Enable</b> , the upgrade package is loaded first. After the PV power supply recovers and the activation conditions are met, the inverter automatically activates the upgrade.
Unlock optimizer	When replacing the optimizer, you need to disable the binding relationship between the optimizer and the MBUS master solar inverter. Set this parameter to <b>Enable</b> , and then unlock optimizer .	<ul style="list-style-type: none"><li>• Disable</li><li>• Enable</li></ul>	N/A
Heartbeat period at application layer (min)	Specifies the timeout period for the solar inverter to connect to the management system.	[1, 65535]	N/A
TCP frame length	Specifies the maximum length of the TCP frame sent by the northbound device to the solar inverter.	[320, 1500]	N/A
TCP heartbeat interval (s)	Specifies the TCP link timeout period for the solar inverter to connect to the management system.	[0, 65535]	N/A

Parameter	Description	Value Range (Vn: Rated Voltage; Fn: Rated Frequency)	Remarks
LVRT	LVRT is short for low voltage ride-through. When the grid voltage is abnormally low for a short time, the inverter cannot disconnect from the power grid immediately and has to work for some time.	<ul style="list-style-type: none"> <li>• Disable</li> <li>• Enable</li> </ul>	N/A
Threshold for triggering LVRT (V)	Specifies the threshold for triggering LVRT. The threshold settings should meet the local grid standard.	[50% Vn, 100% Vn]	This parameter is displayed when <b>LVRT</b> is set to <b>Enable</b> .
LVRT reactive power compensation factor	During LVRT, the inverter needs to generate reactive power to support the power grid. This parameter is used to set the reactive power generated by the inverter.	[0, 10]	<ul style="list-style-type: none"> <li>• This parameter is displayed when <b>LVRT</b> is set to <b>Enable</b>.</li> <li>• For example, if this parameter is set to <b>2</b>, the reactive power generated by the inverter is 20% of the rated power when the AC voltage drops by 10% during LVRT.</li> </ul>
LVRT characteristic curve	Specifies the low voltage ride through curve.	N/A	This parameter is displayed when <b>LVRT</b> is set to <b>Enable</b> .
HVRT	HVRT is short for high voltage ride-through. When the grid voltage is abnormally high for a short time, the inverter cannot disconnect from the power grid immediately and has to work for some time.	<ul style="list-style-type: none"> <li>• Disable</li> <li>• Enable</li> </ul>	N/A
Threshold for triggering HVRT (V)	Specifies the threshold for triggering HVRT. The threshold settings should meet the local grid standard.	[100% Vn, 136% Vn]	This parameter is displayed when <b>HVRT</b> is set to <b>Enable</b> .
Grid voltage protection shield during VRT	Specifies whether to apply voltage protective shielding to the power grid when HVRT or LVRT is enabled.	<ul style="list-style-type: none"> <li>• Disable</li> <li>• Enable</li> </ul>	This parameter is displayed when <b>LVRT</b> is set to <b>Enable</b> or <b>HVRT</b> is set to <b>Enable</b> .
Active islanding protection	Specifies whether to enable the active islanding protection function.	<ul style="list-style-type: none"> <li>• Disable</li> <li>• Enable</li> </ul>	N/A

Parameter	Description	Value Range (Vn: Rated Voltage; Fn: Rated Frequency)	Remarks
Passive islanding protection	Specifies whether to enable the passive islanding protection function.	<ul style="list-style-type: none"> <li>• Disable</li> <li>• Enable</li> </ul>	This parameter is displayed if the Japanese grid code is selected.
Voltage rise suppression	The standards of certain countries and regions require that when the output voltage exceeds a certain value, the inverter must suppress voltage rise by outputting reactive power and reducing active power.	<ul style="list-style-type: none"> <li>• Disable</li> <li>• Enable</li> </ul>	N/A
Voltage rise suppressing reactive power adjustment point (%)	The standards of certain countries and regions require that the inverter generate a certain amount of reactive power when the output voltage exceeds a certain value.	[100, 115)	<ul style="list-style-type: none"> <li>• This parameter is displayed when <b>Voltage rise suppression</b> is set to <b>Enable</b>.</li> <li>• The value of <b>Voltage rise suppressing active power derating point</b> must be greater than that of <b>Voltage rise suppressing reactive power adjustment point</b>.</li> </ul>
Voltage rise suppressing active power derating point (%)	The standards of certain countries and regions require that the active power of the inverter be derated according to a certain slope when the output voltage exceeds a certain value.	(100, 115]	
Voltage rise suppression P-U curve	The standards of certain countries and regions require that the P-U curve be set.	<ul style="list-style-type: none"> <li>• U (V): [176, 1500]</li> <li>• U device verification (V) : [0.8 Un, 1.36 Un]</li> <li>• P/Pn (%): [0, 100]</li> </ul>	This parameter is displayed when <b>Voltage rise suppression</b> is set to <b>Enable</b> .
Voltage rise suppression Q-U curve	The standards of certain countries and regions require that the Q-U curve be set.	<ul style="list-style-type: none"> <li>• U (V): [176, 1500]</li> <li>• U device verification (V) : [0.8 Un, 1.36 Un]</li> <li>• Q/S: [-0.6, 0.6]</li> </ul>	
Soft start time after grid failure (s)	Specifies the time for the power to gradually increase when the inverter restarts after the power grid recovers.	[1, 1800]	N/A

Parameter	Description	Value Range (Vn: Rated Voltage; Fn: Rated Frequency)	Remarks
PID running mode	Specifies the operation mode of the inverter built-in PID.	<ul style="list-style-type: none"> <li>• Disable</li> <li>• Suppress</li> <li>• Repair</li> <li>• Suppress + Repair</li> </ul>	N/A
PID nighttime off-grid repair	Specifies whether to enable the PID nighttime off-grid repair.	<ul style="list-style-type: none"> <li>• Disable</li> <li>• Enable</li> </ul>	This parameter is displayed when <b>PID running mode</b> is set to <b>Repair</b> .
Closed-loop controller	<ul style="list-style-type: none"> <li>• Set this parameter to <b>SDongle/SmartLogger</b> when the SmartLogger1000A is connected.</li> <li>• If multiple inverters are cascaded, set this parameter to <b>SDongle/SmartLogger</b>.</li> <li>• If there is only one inverter, set this parameter to <b>Inverter</b>.</li> </ul>	<ul style="list-style-type: none"> <li>• SDongle/SmartLogger</li> <li>• Solar inverter</li> </ul>	N/A
Active power output limit for fail-safe (%)	When the communication between the SDongle/SmartLogger, power meter, and solar inverter is interrupted, the solar inverter output is limited.	[0, 100]	N/A

## Power Adjustment

Parameter	Description	Value Range (Vn: Rated Voltage; Fn: Rated Frequency)	Remarks
Remote power schedule	If this parameter is set to <b>Enable</b> , the inverter responds to the scheduling instruction from the remote port. If this parameter is set to <b>Disable</b> , the inverter does not respond to the scheduling instruction from the remote port.	<ul style="list-style-type: none"> <li>• Disable</li> <li>• Enable</li> </ul>	N/A

Parameter	Description	Value Range (Vn: Rated Voltage; Fn: Rated Frequency)	Remarks
Schedule instruction valid duration (s)	Specifies the time for maintaining the scheduling instruction.	[0, 86400]	When this parameter is set to 0, the scheduling instruction takes effect permanently.
Apparent power baseline (kVA)	Adjust the apparent output baseline of the inverter.	[ $P_{max}$ , $S_{max\_real}$ ]	N/A
Active power baseline (kW)	Adjusts the active output baseline of the inverter.	[0.1, $\text{Min}(P_{max\_real}, S_{max})$ ]	N/A
Maximum apparent power (kVA)	Specifies the output upper threshold for the maximum apparent power to adapt to the capacity requirements of standard and customized inverters.	[ $P_{max}$ , $S_{max}$ ]	N/A
Maximum active power (kW)	Specifies the output upper threshold for the maximum active power to adapt to different market requirements.	[0.1, $P_{max}$ ]	N/A
OFF at %0 power limit	If this parameter is set to <b>Enable</b> , the inverter shuts down after receiving the 0% power limit command. If this parameter is set to <b>Disable</b> , the inverter does not shut down after receiving the 0% power limit command.	<ul style="list-style-type: none"> <li>• Disable</li> <li>• Enable</li> </ul>	N/A
Active power change gradient (%/s)	Specifies the change speed of the inverter active power.	[0.1, 1000]	N/A
Derated by fixed active power (kW)	Adjusts the active power output of the inverter by fixed value.	[0, $P_{max}$ ]	N/A
Active power percentage derating (%)	Adjusts the active power output of the inverter by percentage.	[0, 100]	If this parameter is set to <b>100</b> , the solar inverter generates power based on the maximum output power.
Reactive power change gradient (%/s)	Specifies the change speed of the inverter reactive power.	[0.1, 1000]	N/A
Reactive power compensation (Q/S)	Specifies the reactive power output by the inverter.	[-1, 1]	N/A
Power factor	Specifies the power factor of the inverter.	[-1.000, -0.800] U [0.800, 1.000]	N/A

Parameter	Description	Value Range (Vn: Rated Voltage; Fn: Rated Frequency)	Remarks
Overfrequency derating	If this parameter is set to <b>Enable</b> , the active power of the inverter will be derated according to a certain slope when the grid frequency exceeds the frequency that triggers overfrequency derating.	<ul style="list-style-type: none"> <li>• Disable</li> <li>• Enable</li> </ul>	N/A
Frequency for triggering overfrequency derating (Hz)	The standards of certain countries and regions require that the output active power of inverters be derated when the power grid frequency exceeds a certain value.	<ul style="list-style-type: none"> <li>• 50Hz: [40, 60]</li> <li>• 60Hz: [48, 72]</li> </ul>	<ul style="list-style-type: none"> <li>• This parameter is displayed when <b>Overfrequency derating</b> is set to <b>Enable</b>.</li> <li>• When setting this parameter, ensure that the following condition is met: <b>Frequency for exiting overfrequency derating</b> <math>\leq</math> <b>Trigger frequency of overfrequency derating</b> <math>&lt;</math> <b>Cutoff frequency of overfrequency derating</b>.</li> </ul>
Frequency for exiting overfrequency derating (Hz)	Specifies the frequency threshold for exiting overfrequency derating.	<ul style="list-style-type: none"> <li>• 50Hz: [40, 60]</li> <li>• 60Hz: [48, 72]</li> </ul>	
Cutoff frequency of overfrequency derating (Hz)	Specifies the frequency threshold for cutting off overfrequency derating.	<ul style="list-style-type: none"> <li>• 50Hz: [40, 60]</li> <li>• 60Hz: [48, 72]</li> </ul>	
Cutoff power of overfrequency derating (%)	Specifies the power threshold for cutting off overfrequency derating.	[0, 100]	
Power recovery gradient of overfrequency derating (%/min)	Specifies the recovery rate of the overfrequency derating power.	[1, 6000]	
Dry contact scheduling	The standards of some countries and regions require that this parameter be set to <b>Enable</b> when power scheduling through dry contacts is required.	<ul style="list-style-type: none"> <li>• Disable</li> <li>• Enable</li> </ul>	N/A
Dry contact scheduling settings	Specifies the dry contact power scheduling parameters.	N/A	This parameter is displayed when <b>Dry contact scheduling</b> is set to <b>Enable</b> .
cos $\phi$ -P/Pn characteristic curve	After this parameter is set, the solar inverter can adjust the power factor cos $\phi$ in real time based on the P/Pn.	<ul style="list-style-type: none"> <li>• P/Pn (%): [0, 100]</li> <li>• cos<math>\phi</math>: (-1, -0.8]U[0.8, 1]</li> </ul>	N/A



Parameter	Description	Value Range (Vn: Rated Voltage; Fn: Rated Frequency)	Remarks
Q-U characteristic curve	Specifies the voltage reactive power scheduling curve.	<ul style="list-style-type: none"> <li>U/Un (%): [80, 136]</li> <li>Q/S: [-0.6, 0.6]</li> </ul>	N/A
Q-U hysteresis curve	Specifies the voltage reactive power scheduling hysteresis curve.	<ul style="list-style-type: none"> <li>U/Un (%): [80, 136]</li> <li>Q/S: [-0.6, 0.6]</li> </ul>	Associated with the Italian standard code.
Underfrequency rise power	The standards of certain countries and regions require that if the power grid frequency is lower than <b>Frequency for triggering of underfrequency rise power</b> , the inverter needs to increase the active power output to help increase the power grid frequency. In this case, set this parameter to <b>Enable</b> .	<ul style="list-style-type: none"> <li>Disable</li> <li>Enable</li> </ul>	N/A
Frequency for triggering of underfrequency rise power (Hz)	Specifies the frequency threshold of <b>Underfrequency rise power</b> .	<ul style="list-style-type: none"> <li>50Hz: [40, 60]</li> <li>60Hz: [48, 72]</li> </ul>	<ul style="list-style-type: none"> <li>This parameter is displayed when <b>Underfrequency rise power</b> is set to <b>Enable</b>.</li> <li>When setting this parameter, ensure that the following condition is met: <b>Cutoff frequency of underfrequency rise power</b> &lt; <b>Frequency for triggering of underfrequency rise power</b> &lt; <b>Frequency for exiting of underfrequency rise power</b>.</li> </ul>
Power recovery gradient of underfrequency rise (%/min)	Specifies the recovery rate of <b>Underfrequency rise power</b> .	[1, 6000]	
Cutoff frequency of underfrequency rise power (Hz)	Specifies the cutoff frequency of <b>Underfrequency rise power</b> .	<ul style="list-style-type: none"> <li>50Hz: [40, 60]</li> <li>60Hz: [48, 72]</li> </ul>	
Cutoff power of underfrequency rise power (%)	Specifies the cutoff power of <b>Underfrequency rise power</b> .	[0, 100]	
Frequency for exiting of underfrequency rise power (Hz)	Specifies the exit frequency of <b>Underfrequency rise power</b> .	<ul style="list-style-type: none"> <li>50Hz: [40, 60]</li> <li>60Hz: [48, 72]</li> </ul>	

## Time Setting

Parameter	Description	Value Range (Vn: Rated Voltage; Fn: Rated Frequency)	Remarks
Time zone	Specifies the time zone.	N/A	N/A
Time setting	Specifies the time.	N/A	N/A
Daylight saving time	Specifies whether to enable daylight saving time (DST).	<ul style="list-style-type: none"> <li>• Disable</li> <li>• Enable</li> </ul>	N/A
Offset time	Specifies the DST offset.	[-240, 240]	This parameter is displayed when <b>Daylight saving time</b> is set to <b>Enable</b> .
Start date	Specifies the DST offset start date.	[01-01, 12-31]	
Start time	Specifies the DST offset start time.	[00:00:00, 23:59:59]	
End date	Specifies the DST offset end date.	[01-02, 12-30]	
End date	Specifies the DST offset end time.	[00:00:00, 23:59:59]	
NTP time synchronization	Specifies whether to enable NTP time synchronization.	<ul style="list-style-type: none"> <li>• Disable</li> <li>• Enable</li> </ul>	N/A
NTP server address	Specifies the NTP server IP address or domain name.	N/A	This parameter is displayed when <b>NTP time synchronization</b> is set to <b>Enable</b> .
NTP server port	Specifies the server port.	[0, 65535]	
NTP time synchronization interval	Specifies the NTP time synchronization interval.	[1, 1440]	

## Communication Configuration

Parameter	Description	Parameter	Description
Inverter WLAN settings	Changes the WLAN password for the solar inverter.	Inverter's connection to a router	When using WLAN for communication, enter the information about the connected router.
Dongle parameter settings	If the solar inverter is configured with a Dongle, view and set communication addresses to the solar inverter.	4G	When using a 4G Dongle, enter the SIM card information.


Parameter	Description	Parameter	Description
RS485 settings	Specifies the RS485 communications parameters of the solar inverter.	Management System Configuration	Enter information about the management system to which the solar inverter connects.

**Table 4-2** RS485 settings

Parameter	Description	
Protocol	Set the RS485 baud rate to be consistent with the baud rate of the devices on the same bus.	<ul style="list-style-type: none"> <li>• 4800</li> <li>• 9600</li> <li>• 19200</li> </ul>
Baud rate	The solar inverter can connect to the upper-layer management unit over the Modbus RTU, SunSpec, or AVM protocol.	<ul style="list-style-type: none"> <li>• MODBUS RTU</li> <li>• Sunspec</li> <li>• AVM</li> </ul>
Com address	Set the communications address of the SUN2000 when it connects to the upper-level management unit, which should not conflict with the addresses of other devices on the same bus.	[1, 247]

## 4.8 Power Adjustment

On the home screen, tap **Power Adjustment** and set power parameters as required.



### NOTE

- The UI is for reference only. The UI varies with associated devices. The actual UI prevails.
- The parameter list provided in this document includes all configurable parameters that vary with the device model and grid code. The actual screen prevails.

For details about how to set active and reactive power control parameters, see [Power Adjustment](#).

For details about how to set the grid-tied point control parameters, see [Table 4-3](#).

For details about how to set energy storage control parameters, see [Table 4-4](#).

**Table 4-3** Grid-tied point control

Parameter			Description
Active power	Unlimited	N/A	If this parameter is set to <b>Unlimited</b> , the output power of the solar inverter is not limited and the solar inverter can connect to the power grid at the rated power.
	Grid connection with zero power	Closed-loop controller	<ul style="list-style-type: none"> <li>When the SmartLogger1000A is connected, set this parameter to <b>SDongle/SmartLogger</b>.</li> <li>When multiple solar inverters are cascaded, set this parameter to <b>SDongle/SmartLogger</b>.</li> <li>When there is only one solar inverter, set this parameter to <b>Inverter</b>.</li> </ul>
		Limitation mode	<ul style="list-style-type: none"> <li><b>Total power</b> indicates export limitation of the total power at the grid-tied point.</li> <li><b>Single-phase power</b> indicates export limitation of the power in each phase at the grid-tied point. (Note: COUNTIS E43 does not apply to this scenario.)</li> </ul>
		Power adjustment period	Specifies the shortest interval for a single export limitation adjustment.
		Maximum protection time	Specifies the time for detecting power meter data. If the Dongle does not detect any power meter data within the preset time, the Dongle delivers the preset value of the <b>Fail-safe power threshold</b> to the solar inverter for protection.
		Power control hysteresis	Specifies the dead zone for adjusting the inverter output power. If the power fluctuation is within the power control hysteresis, the power is not adjusted.
		Communication disconnection fail-safe	In the solar inverter export limitation scenario, if this parameter is set to <b>Enable</b> , the solar inverter will derate according to the active power derating percentage when the communication between the solar inverter and the Dongle is disconnected for a period longer than <b>Communication disconnection detection time</b> .
		Communication disconnection detection time	Specifies the time for determining the communication disconnection between the solar inverter and the Dongle. This parameter is displayed only when <b>Communication disconnection fail-safe</b> is set to <b>Enable</b> .

Parameter		Description
	Active power output limit for fail-safe	Specifies the derating value of the solar inverter active power by percentage. If the Dongle does not detect any power meter data or the communication between the Dongle and the solar inverter is disconnected, the Dongle delivers the derating value of the solar inverter active power by percentage.
Grid connection with limited power (kW)	Closed-loop controller	<ul style="list-style-type: none"> <li>For a single solar inverter, set <b>Closed-loop controller to Inverter</b> or <b>SDongle/SmartLogger</b>. <ul style="list-style-type: none"> <li>When <b>Closed-loop controller</b> is set to <b>Inverter</b>, the duration is less than 2s.</li> <li>When <b>Closed-loop controller</b> is set to <b>SDongle/SmartLogger</b>, the duration is less than 5s.</li> </ul> </li> <li>For multiple solar inverters, <b>Closed-loop controller</b> can only be set to <b>SDongle/SmartLogger</b>. The duration is less than 5s.</li> </ul>
	Limitation mode	<ul style="list-style-type: none"> <li><b>Total power</b> indicates export limitation of the total power at the grid-tied point.</li> <li><b>Single-phase power</b> indicates export limitation of the power in each phase at the grid-tied point. (Note: COUNTIS E43 does not apply to this scenario.)</li> </ul>
	PV plant capacity	Specifies the total maximum active power in the solar inverter cascading scenario.
	Maximum grid feed-in power (kW)	Specifies the maximum active power transmitted from the grid-tied point to the power grid.
	Power adjustment period	Specifies the shortest interval for a single anti-backfeeding adjustment.
	Maximum protection time	Specifies the time for detecting meter data. If the Smart Dongle does not detect any meter data within the preset time, the Smart Dongle delivers the preset value of the <b>Active power output limit for fail-safe</b> to the inverter for protection.
	Power control hysteresis	Specifies the dead zone for adjusting the inverter output power. If the power fluctuation is within the power control hysteresis, the power is not adjusted.
	Communication disconnection fail-safe	In the inverter anti-backfeeding scenario, if this parameter is set to <b>Enable</b> , the inverter will derate according to the active power derating percentage when the communication between the inverter and the Smart Dongle is disconnected for a period longer than <b>Communication disconnection detection time</b> .
	Communication disconnection detection time	Specifies the time for determining the communication disconnection between the solar inverter and the Smart Dongle. This parameter is displayed when <b>Communication disconnection fail-safe</b> is set to Enable.

Parameter		Description
	Active power output limit for fail-safe	Specifies the derating value of the inverter active power by percentage. If the Smart Dongle does not detect any meter data or the communication between the Smart Dongle and the inverter is disconnected, the Smart Dongle delivers the derating value of the inverter active power by percentage.
Grid connection with limited power (%)	Closed-loop controller	<ul style="list-style-type: none"> <li>For a single solar inverter, set <b>Closed-loop controller to Inverter</b> or <b>SDongle/SmartLogger</b>. <ul style="list-style-type: none"> <li>When <b>Closed-loop controller</b> is set to <b>Inverter</b>, the duration is less than 2s.</li> <li>When <b>Closed-loop controller</b> is set to <b>SDongle/SmartLogger</b>, the duration is less than 5s.</li> </ul> </li> <li>For multiple solar inverters, <b>Closed-loop controller</b> can only be set to <b>SDongle/SmartLogger</b>. The duration is less than 5s.</li> </ul>
	Limitation mode	<ul style="list-style-type: none"> <li><b>Total power</b> indicates export limitation of the total power at the grid-tied point.</li> <li><b>Single-phase power</b> indicates export limitation of the power in each phase at the grid-tied point. (Note: COUNTIS E43 does not apply to this scenario.)</li> </ul>
	PV plant capacity	Specifies the total maximum active power in the inverter cascading scenario.
	Maximum grid feed-in power (%)	Specifies the percentage of the maximum active power of the grid-tied point to the PV plant capacity.
	Power adjustment period	Specifies the shortest interval for a single anti-backfeeding adjustment.
	Maximum protection time	Specifies the time for detecting meter data. If the Smart Dongle does not detect any meter data within the preset time, the Smart Dongle delivers the preset value of the <b>Active power output limit for fail-safe</b> to the inverter for protection.
	Power control hysteresis	Specifies the dead zone for adjusting the inverter output power. If the power fluctuation is within the power control hysteresis, the power is not adjusted.
	Communication disconnection fail-safe	In the inverter anti-backfeeding scenario, if this parameter is set to <b>Enable</b> , the inverter will derate according to the active power derating percentage when the communication between the inverter and the Smart Dongle is disconnected for a period longer than <b>Communication disconnection detection time</b> .
	Communication disconnection detection time	Specifies the time for determining the communication disconnection between the solar inverter and the Smart Dongle. This parameter is displayed when <b>Communication disconnection fail-safe</b> is set to Enable.

Parameter		Description	
	Active power output limit for fail-safe	Specifies the derating value of the inverter active power by percentage. If the Smart Dongle does not detect any meter data or the communication between the Smart Dongle and the inverter is disconnected, the Smart Dongle delivers the derating value of the inverter active power by percentage.	
Reactive power	Power factor closed-loop control	Target power factor	Specifies the target power factor of the power meter.
		Reactive power adjustment period	Specifies the interval for sending adjustment commands.
		Reactive power adjustment deadband	Specifies the adjustment power factor precision.
		Fail-safe power factor	When the communication between the SDongle/SmartLogger, power meter, and solar inverter is interrupted, the solar inverter outputs power based on this threshold.
		Communication disconnection fail-safe	When this parameter is set to <b>Enable</b> , and the communication between the solar inverter and the SDongle/SmartLogger is interrupted for a certain period (set by <b>Communication disconnection detection time</b> ), the solar inverter outputs power based on <b>Fail-safe power</b> .
		Communication disconnection detection time	Specifies the protection duration to determine whether the communication between the SDongle/SmartLogger and the solar inverter is interrupted.  This parameter is displayed only when <b>Communication disconnection fail-safe</b> is set to <b>Enable</b> .
	No Output	N/A	If this parameter is set to <b>No Output</b> , no parameter is available.

**Table 4-4** Energy storage control

Parameter		Description
Forcible charge/discharge	Charge/discharge power	Specifies the forced charge/discharge manually.
	Forced charge/discharge power (kW)	Specifies the forced charge/discharge power.
	Forced charge/discharge period (mins)	Specifies the forced charge/discharge duration.
	Remaining charge/discharge time (mins)	Displays the remaining charge and discharge time, which cannot be set.

Parameter	Description
Control mode	<ul style="list-style-type: none"> <li>• If this parameter is set to <b>Fixed charge/discharge</b>, you can charge or discharge the batteries in the specified time period. A maximum of 10 time periods can be added.</li> <li>• If this parameter is set to <b>Maximise self consumption</b> and the solar inverter connects to a power meter, the solar inverter provides output power for local loads before feeding the remaining power to the power grid.</li> <li>• If this parameter is set to <b>Time-of-use price</b>, batteries discharge when the electricity price is high and charge when the electricity price is low. A maximum of 10 time periods can be added.</li> </ul> <p><b>NOTE</b> When setting <b>Time-of-use price</b>, ensure that the number of time periods is greater than or equal to 2, and that the number of tariffs is greater than or equal to 2.</p>
Feed power into grid	<p>If this parameter is set to <b>Enable</b>, the batteries can be charged with the power supply from the power grid.</p> <p>If this parameter is set to <b>Disable</b> before delivery, you must comply with the local regulations on charging the batteries with the power supply from the power grid.</p>

 **NOTE**

The duration for export limitation control is as follows:

- For a single solar inverter, set **Closed-loop controller** to **Inverter** or **SDongle/SmartLogger**.
- When **Closed-loop controller** is set to **Inverter**, the duration of export limitation control is less than 2s.
- When **Closed-loop controller** is set to **SDongle/SmartLogger**, the duration is less than 5s if the controller is the SDongle. The duration is less than 2s if the controller is the SmartLogger.
- For multiple solar inverters, **Closed-loop controller** can only be set to **SDongle/SmartLogger**.
- The duration is less than 5s if the controller is the SDongle.
- The duration is less than 2s if the controller is the SmartLogger.



# 5 Operations on the Screen for Connecting to the Commercial Solar Inverter

---

## NOTICE

- The app screenshots provided in this chapter correspond to the SUN2000 app 3.2.00.003 version. The data on the screenshots is for reference only.
  - The document describes the operation method on the Android UI. The actual UI prevails.
  - The parameters displayed on the screen vary according to the solar inverter model connected to the app.
  - The 1000 V and 1500 V solar inverters have the maximum input voltages of 1000 V and 1500 V respectively. The 1100 V solar inverter refers to the one with the maximum input voltage of 1100 V or SUN2000-33KTL-US/36KTL-US/40KTL-US. The maximum input voltage can be queried from the product nameplate or the user manual.
  - Delivering a reset, factory reset, shutdown, or upgrade command to the solar inverters may cause power grid connection failure, which affects the energy yield.
  - Only professionals are allowed to set the grid parameters, protection parameters, feature parameters, power adjustment parameters, and grid-tied point control parameters of the solar inverters. If the grid parameters, protection parameters, and feature parameters are incorrectly set, the solar inverters may not connect to the power grid. If the power adjustment parameters and grid-tied point control parameters are incorrectly set, the solar inverters may not connect to the power grid as required. In these cases, the energy yield will be affected.
- 


## 5.1 Commercial Solar Inverter

### Connection Modes

After the DC or AC side of a solar inverter is energized, the app can connect to the solar inverter in two methods:

1. Connect over a WLAN/Bluetooth module.


**Figure 5-1** WLAN/Bluetooth connection



(A) Solar inverter      (B) WLAN/Bluetooth module      (C) Mobile phone

2. Connect over a USB data cable.

**Figure 5-2** USB data cable connection



(A) Solar inverter      (B) USB data cable      (C) Mobile phone

**Table 5-1** Product mapping (Android)

Solar Inverter Model	Version	App Version	Connection Mode		
			USB-Adapter2000-C WLAN Module/USB-Adapter2000-B Bluetooth Module	BF4030 Bluetooth Module	USB Data Cable
SUN2000-8KTL, SUN2000-10KTL, SUN2000-12KTL, SUN2000-15KTL, SUN2000-17KTL, SUN2000-20KTL, SUN2000-23KTL, SUN2000-24.5KTL, and SUN2000-28KTL	SUN2000 V100R01C81SP C110 and later versions	3.2.00.003	Supported	Supported	Supported

Solar Inverter Model	Version	App Version	Connection Mode		
			USB-Adapter2000-C WLAN Module/USB-Adapter2000-B Bluetooth Module	BF4030 Bluetooth Module	USB Data Cable
SUN2000-30KTL-A, SUN2000-33KTL, SUN2000-33KTL-E001, and SUN2000-40KTL	Versions earlier than SUN2000 V200R001C90SPC109		Not supported		
	SUN2000 V200R001C90SPC109 and later versions		Supported		
SUN2000-22KTL-US, SUN2000-25KTL-US, and SUN2000-30KTL-US	Versions earlier than SUN2000 V200R001C02SPC102		Not supported		
	SUN2000 V200R001C02SPC102 and later versions		Supported		
SUN2000-33KTL-JP, SUN2000-40KTL-JP, SUN2000-29.9KTL, SUN2000-33KTL-A, SUN2000-36KTL, SUN2000-42KTL, SUN2000-43KTL-IN-C1, SUN2000-50KTL,	Versions earlier than SUN2000 V200R002C00SPC102		Not supported		

Solar Inverter Model	Version	App Version	Connection Mode		
			USB-Adapter2000-C WLAN Module/USB-Adapter2000-B Bluetooth Module	BF4030 Bluetooth Module	USB Data Cable
and SUN2000-50KTL-C1	SUN2000 V200R002C00SP C102 and later versions		Supported		
SUN2000-60KTL-HV-D1	SUN2000HA V100R001C00 and later versions		Supported		
SUN2000-45KTL-US-HV-D0	SUN2000HA V100R001C10 and later versions		Supported		
SUN2000-33KTL-US/36KTL-US/40KTL-US	SUN2000 V200R002C20 and later versions		Supported		
SUN2000-70KTL-C1, SUN2000-65KTL-C1, SUN2000-60KTL-M0, SUN2000-50KTL-M0, SUN2000-65KTL-M0, SUN2000-70KTL-IN M0, SUN2000-75KTL-C1, SUN2000-63KTL-JP M0, SUN2000-50KTL-JP M0, and SUN2000-50KTL-JP M1	SUN2000 V300R001C00 and later versions		Supported	Not supported	

Solar Inverter Model	Version	App Version	Connection Mode		
			USB-Adapter2000-C WLAN Module/USB-Adapter2000-B Bluetooth Module	BF4030 Bluetooth Module	USB Data Cable
SUN2000-125KTL-M0, SUN2000-110KTL-M0, SUN2000-100KTL-M0, SUN2000-100KTL-M1, and SUN2000-100KTL-INM0	SUN2000 V500R001C00 and later versions		Supported	Not supported	
SUN2000-90KTL-H0, SUN2000-90KTL-H1, SUN2000-90KTL-H2, SUN2000-95KTL-INH0, SUN2000-95KTL-INH1, SUN2000-100KTL-H0 , SUN2000-100KTL-H1 , SUN2000-100KTL-H2 , SUN2000-105KTL-H1 , and SUN2000-63KTL-JPH0	SUN2000HA V200R001C30 and later versions		Supported	Not supported	
SUN2000-100KTL-USH0	SUN2000HA V200R001C20 and later versions		Supported	Not supported	
SUN2000-175KTL-H0 , SUN2000-185KTL-INH0, and SUN2000-185KTL-H1	SUN2000HA V300R001C00 and later versions		Supported	Not supported	

**Table 5-2** Product mapping (iOS)

Solar Inverter Model	Version	App Version	Connection Mode		
			USB-Adapter2 000-B Bluetooth Module	BF4030 Bluetooth Module	USB Data Cable
SUN2000-8KTL, SUN2000-10KTL, SUN2000-12KTL, SUN2000-15KTL, SUN2000-17KTL, SUN2000-20KTL, SUN2000-23KTL, SUN2000-24.5KTL, and SUN2000-28KTL	SUN2000 V100R001C81S PC110 and later versions	2.2.00.050	Supported	Not supported	Not supported
SUN2000-30KTL-A, SUN2000-33KTL, SUN2000-33KTL-E001, and SUN2000-40KTL	SUN2000 V200R001C90S PC109 and later versions				
SUN2000-22KTL-US, SUN2000-25KTL-US, and SUN2000-30KTL-US	SUN2000 V200R001C02S PC102 and later versions				

Solar Inverter Model	Version	App Version	Connection Mode		
			USB-Adapter2 000-B Bluetooth Module	BF4030 Bluetooth Module	USB Data Cable
SUN2000-33K TL-JP, SUN2000-40K TL-JP, SUN2000-29.9 KTL, SUN2000-33K TL-A, SUN2000-36K TL, SUN2000-42K TL, SUN2000-43K TL-IN-C1, SUN2000-50K TL, and SUN2000-50K TL-C1	SUN2000 V200R002C00S PC102 and later versions				
SUN2000-60K TL-HV-D1	SUN2000HA V100R001C00 and later versions				
SUN2000-45K TL-US-HV-D0	SUN2000HA V100R001C10 and later versions				
SUN2000-33K TL-US/36KTL- US/40KTL-US	SUN2000 V200R002C20 and later versions				

Solar Inverter Model	Version	App Version	Connection Mode		
			USB-Adapter2 000-B Bluetooth Module	BF4030 Bluetooth Module	USB Data Cable
SUN2000-70K TL-C1, SUN2000-65K TL-C1, SUN2000-60K TL-M0, SUN2000-50K TL-M0, SUN2000-65K TL-M0, SUN2000-70K TL-INM0, SUN2000-75K TL-C1, SUN2000-63K TL-JPM0, SUN2000-50K TL-JPM0, and SUN2000-50K TL-JPM1	SUN2000 V300R001C00 and later versions				
SUN2000-125K TL-M0	SUN2000 V500R001C00 and later versions				
SUN2000-90K TL-H0, SUN2000-90K TL-H1, SUN2000-90K TL-H2, SUN2000-95K TL-INH0, SUN2000-95K TL-INH1, SUN2000-100K TL-H0, SUN2000-100K TL-H1, SUN2000-100K TL-H2, SUN2000-105K TL-H1, and SUN2000-63K TL-JPH0	SUN2000HA V200R001C30 and later versions				



Solar Inverter Model	Version	App Version	Connection Mode		
			USB-Adapter2000-B Bluetooth Module	BF4030 Bluetooth Module	USB Data Cable
SUN2000-100K TL-USH0	SUN2000HA V200R001C20 and later versions				
SUN2000-175K TL-H0, SUN2000-185K TL-INH0, and SUN2000-185K TL-H1	SUN2000HA V300R001C00 and later versions				

 **NOTE**

- The version mapping in the preceding table is subject to change and is for reference only.
- You can view the solar inverter version on the app, LCD, SmartLogger, and the management system.

## 5.2 Required Accessories

### Mobile Phone

- Mobile phone operating system: Android 4.4 or later
- Recommended phone brands: Huawei and Samsung
- The mobile phone supports the access to the Internet over a web browser.
- WLAN/Bluetooth supported

### WLAN/Bluetooth Module

Purchase a Bluetooth module or WLAN module that matches the solar inverter. A Bluetooth module or a WLAN module purchased from any other source may not support communication between the app and the solar inverter.

**Table 5-3** WLAN/Bluetooth module model

Model	Module	Item Code	Purchased From
USB-Adapter2000-C	WLAN module	02312MCK	Can be purchased from Huawei
USB-Adapter2000-B	Bluetooth module	02311NEA	
BF4030	Bluetooth module	06080358	

## USB Data Cable

The USB data cable is delivered with the phone.

**NOTE**


The port type of the USB data cable connected to the solar inverter is USB 2.0.

## 5.3 User Operation Permissions


The user accounts that can log in to the app are classified into common users, special users, and advanced users. You can set different user permissions based on the responsibilities of PV plant operation personnel.

- Common user: Has the permission of viewing data and setting user parameters.
- Advanced user: Has the permission of viewing data, setting functional parameters, and maintaining devices.
- Special user: Has the permissions of viewing solar inverter data, setting grid related parameters, and maintaining devices (including starting and shutting down the solar inverter, restoring factory defaults, and upgrading devices).

**Figure 5-3** Operation permissions of common users




**Figure 5-4** Operation permissions of advanced users



**NOTE**

- **Support system** is available for SUN2000 V200R001C91 and SUN2000 V200R001C93 of 1000 V solar inverters, all 1100 V solar inverters, and all 1500 V solar inverters.
- **Spot-check** is available only to solar inverters using the **Japanese grid code**.
- **Start DC input detection** is available only to 1500 V solar inverters.
- **AFCI self-test** is available only to the solar inverters whose technical specifications contain AFCI on the product nameplate.
- **File save path** is displayed only for the Android system.

**Figure 5-5** Operation permissions of special users



## 5.4 Login

### Prerequisites


- The DC or AC side of the solar inverter has been energized.
- Connect over a WLAN/Bluetooth module:
  - a. The WLAN/Bluetooth module is connected to the **USB** port at the bottom of the solar inverter.
  - b. The WLAN/Bluetooth function is enabled on the mobile phone.
  - c. Keep the mobile phone within 5 m from the solar inverter. Otherwise, communication between them would be affected.
- Connect over a USB data cable:
  - a. The USB data cable is connected from the USB port at the bottom of the solar inverter to the USB port on the mobile phone.

- b. The USB data cable has been successfully connected and **Connected to USB Accessory** is displayed on the screen. Otherwise, the connection is invalid.

## Procedure


**Step 1** Start the app. Tap **Connect** to access the scanning screen and connect to the solar inverter.

**Figure 5-6** Connect




- Code scanning: On the scanning screen, place the QR code or bar code of the WLAN/Bluetooth module in the scan frame. The device will be automatically connected after the code is identified.

**Figure 5-7** Scan



- Manual connection: On the scanning screen, tap **Manual Connection** and select a connection mode.

**Figure 5-8** Manual connection



- Select **WLAN** and connect to the corresponding WLAN in the WLAN connection list of the APP. The initial name of the WLAN hotspot is **Adapter-WLAN module SN**, and the initial password is **Changeme**.


#### NOTICE

Use the initial password upon first power-on and change it immediately after login. To ensure account security, change the password periodically and keep the new password in mind. Not changing the initial password may cause password disclosure. A password left unchanged for a long period of time may be stolen or cracked. If a password is lost, devices cannot be accessed. In these cases, the user is liable for any loss caused to the PV plant.

- Select **Bluetooth**, and tap **Search for device**. After a Bluetooth device is found, select the target Bluetooth device, and set up a connection. If the Bluetooth module is USB-Adapter2000-B, the connected Bluetooth device is named after **last 8 digits of the SN barcode + HWAPP**.
- Select **USB**, and tap **OK** to allow the app to access the USB accessory. After you select **Use by default for this USB accessory**, the message will not appear if you log in to the app again without removing the USB data cable.

**Step 2** Select a login user and enter the password.

**Figure 5-9** Login



**NOTICE**

- The login password is the same as that for the solar inverter connected to the app and is used only when the solar inverter connects to the app.
- The initial passwords for **Common User**, **Advanced User**, and **Special User** are all **00000a**.
- Use the initial password upon first power-on and change it immediately after login. To ensure account security, change the password periodically and keep the new password in mind. Not changing the initial password may cause password disclosure. A password left unchanged for a long period of time may be stolen or cracked. If a password is lost, devices cannot be accessed. In these cases, the user is liable for any loss caused to the PV plant.
- During the login, if five consecutive invalid password entries are made (the interval between two consecutive entries is less than 2 minutes), the account will be locked for 10 minutes. The password should consist of six characters.

**Step 3** After successful login, the **Quick Settings** or **Function Menu** screen is displayed.

**NOTICE**

- If you log in to the SUN2000 app after the device powers on for the first time or factory defaults are restored, the **Quick Settings** screen will be displayed. If you do not set the basic parameters for the solar inverter on the **Quick Settings** screen, the screen is still displayed when you log in next time.
- To set the basic parameters on the **Quick Settings** screen, switch to **Advanced User**. When you log in as **Common User** or **Special User**, enter the password of **Advanced User** in the dialog box that is displayed. After you confirm the password, go to the **Quick Settings** screen.

**Table 5-4** Quick settings

Parameter	Description
Grid code	Set this parameter based on the grid code of the country or region where the SUN2000 is used and the SUN2000 application scenario.
Date	Specifies the system date.
Time	Specifies the system time.
Baud rate (bps)	Set the RS485 baud rate to be consistent with the baud rate of the devices on the same bus.
RS485 protocol	<ul style="list-style-type: none"> <li>• The solar inverter can connect to the upper-layer management unit over the Modbus RTU, SunSpec, or AVM protocol.</li> <li>• When the solar inverter connects to the support tracking system, only the Modbus RTU protocol is supported.</li> </ul>
Com address	Set the communications address of the SUN2000 when it connects to the upper-level management unit, which should not conflict with the addresses of other devices on the same bus.



----End


## 5.5 Screen Operations (Common User)

### 5.5.1 Query

#### Procedure

**Step 1** After logging in to the app, you can view the active power and energy yield of solar inverters on the home screen.

**Figure 5-10** Home screen





**Step 2** Tap **Alarm management** or **Device Monitoring** to view active alarms, historical alarms, and running information of the solar inverters.

You can view the following information on the alarm management screen:

- Tap an alarm record and view the alarm details.
- Swipe right or left on the screen or tap either **Active Alarm** or **Historical Alarm** to display a list of active alarms or historical alarms.

 **NOTE**

- Tap  to set the alarm sorting mode for active alarms or historical alarms.
- Tap  to set a time criterion. The historical alarms generated within the time segment are displayed.
- Select the alarms that can be manually cleared, and tap **Delete** on the right of the alarm to manually clear the alarms.

 **NOTE**

- Alarms that have been manually cleared can be viewed on the **Historical Alarm** screen.
- Only the **AFCI Self-Check Failure** and **DC Arc Fault** alarms can be manually cleared. Only the products whose technical specifications contain AFCI supports manual alarm clearance.

----End

## 5.5.2 Settings


### Context

Due to permission restrictions, common users can set time parameters only for the solar inverters.

### Procedure

- Step 1** On the home screen, choose **Settings** > **Time setting** and set time parameters.

**Figure 5-11** Time settings (common user)



**Table 5-5** Time settings

Parameter	Description
Time setting	Specifies the system time.

 **NOTE**

- For a solar inverter that supports DST, if an advanced user enables DST, a common user can view DST data.
- When an advanced user enables NTP time synchronization, common users can view the related data.

----End

## 5.5.3 Maintenance

### 5.5.3.1 System Maintenance


#### Context


Because of permission restriction, common users can only turn on or off solar inverters.

#### Procedure

**Step 1** On the home screen, tap **Maintenance** to access the maintenance screen.

**Figure 5-12** Maintenance



**Step 2** Tap  next to **Power on** or **Power off** to perform the operation.

**Step 3** Enter the password for logging in to the app, and tap **OK**.

----End

### 5.5.3.2 Feedback


#### Context

Users can provide feedback in text, pictures, and files.


#### NOTE

Do not add private data.

#### Procedure

**Step 1** Choose  > **Feedback** in the upper-right corner of the home screen.


**Figure 5-13** Feedback



**Step 2** Tap **Specify the type** and select **Feedback** or **Suggestion**.

**Step 3** Briefly describe the problem that you encounter in the **Description** column.

**Step 4** (Optional) Tap  to upload pictures.

**Step 5** (Optional) Tap  to upload logs. Select device logs or app logs as required.

**Step 6** Tap **Submit**.


----End

### 5.5.3.3 Help


#### Context

If you have any questions when using an involved device or the app, search for solutions in the help information.

#### Procedure

**Step 1** Choose  > **Help** in the upper-right corner of the home screen.

**Figure 5-14** Help



**Step 2** Specify your question. A solution will be displayed.

----End

### 5.5.3.4 About


#### Context

You can query the app version, connected product model, SN, part number, firmware version, software version, technical support website, privacy policy (displayed only on the SUN2000 app), customer service contact information, and open source software policy.


#### NOTE

- When the app starts for the first time after being downloaded or updated, the privacy policy is displayed. You can use the app only after agreeing to the privacy policy, and the privacy policy will no longer appear. If you do not agree to the privacy policy, the app exits, and the privacy policy is still displayed when you start the app next time until you agree to the privacy policy.
- You can revoke the agreed privacy policy.

#### Procedure

- Step 1** In the upper-right corner of the home screen, choose  > **About** to view the app version, connected product model, SN, part number, firmware version, software version, and technical support website.

**Figure 5-15** About



- Step 2** Tap **Privacy policy**, **Customer service contact information**, or **Open source software policy** to view the privacy policy, customer service contact information, and open source software policy.

----End


## 5.6 Screen Operations (Advanced User)

### 5.6.1 Query

#### Procedure

- Step 1** After logging in to the app, you can view the active power and energy yield of solar inverters on the home screen.

**Figure 5-16** Home screen





**Step 2** Tap **Alarm management** or **Device Monitoring** to view active alarms, historical alarms, and running information of the solar inverters.

You can view the following information on the alarm management screen:

- Tap an alarm record and view the alarm details.
- Swipe right or left on the screen or tap either **Active Alarm** or **Historical Alarm** to display a list of active alarms or historical alarms.

**NOTE**

- Tap  to set the alarm sorting mode for active alarms or historical alarms.
- Tap  to set a time criterion. The historical alarms generated within the time segment are displayed.
- Select the alarms that can be manually cleared, and tap **Delete** on the right of the alarm to manually clear the alarms.

**NOTE**

- Alarms that have been manually cleared can be viewed on the **Historical Alarm** screen.
- Only the **AFCI Self-Check Failure** and **DC Arc Fault** alarms can be manually cleared. Only the products whose technical specifications contain AFCI supports manual alarm clearance.

----End

## 5.6.2 Quick Settings


### Context

Due to permission restrictions, only advanced users can quickly set up the solar inverter.

### Procedure

**Step 1** On the home screen, tap **Quick Settings**.

**Figure 5-17** Quick settings



#### NOTE

The screenshot of **Quick settings** provided in this document is for reference only. The actual screens prevail.


**Step 2** Set parameters as prompted.

----End

## 5.6.3 Settings

On the home screen, an advanced user can tap **Settings** to set power grid, protection, and feature parameters for the solar inverter.

**Figure 5-18** Settings (advanced user)



#### NOTICE


- The configurable solar inverter parameters vary with the solar inverter model and grid code. The displayed parameters prevail. The parameter list provided in this section includes all configurable parameters.
- The parameter ranges vary with the device model. The listed ranges are for reference only.
- The parameter names, value ranges, and default values are subject to change. The actual display prevails.

### 5.6.3.1 Setting Grid Parameters

#### Procedure

- Step 1** On the home screen, choose **Settings** > **Grid Parameters** to access the parameter setting screen.

**Figure 5-19** Grid Parameters (advanced user)



For details about how to set the parameters, see [A Commercial Smart Inverters Parameters](#).

----End



### 5.6.3.2 Setting Protection Parameters

#### Procedure

- Step 1** On the home screen, choose **Settings > Protection Parameters** to access the parameter setting screen.

**Figure 5-20** Protection parameters (advanced user)



For details about how to set the parameters, see [A Commercial Smart Inverters Parameters](#).


----End

### 5.6.3.3 Setting Feature Parameters

#### Procedure

- Step 1** On the home screen, choose **Settings > Feature Parameters** to access the parameter setting screen.

**Figure 5-21** Feature parameters (advanced user)



For details about how to set the parameters, see [A Commercial Smart Inverters Parameters](#).

----End

### 5.6.3.4 Time setting

#### Procedure

**Step 1** On the home screen, choose **Settings > Time setting** and set user parameters.

**Figure 5-22** Time setting (advanced user)

The screenshot shows the 'Time setting' screen with the following parameters:

- Time zone: UTC+08:00
- Time setting: 30-Dec-2019 17:14:13
- Daylight saving time:
- Offset time: 60 min
- Start date: 01-01
- Start time: 02:00:00
- End date: 09-01
- End time: 02:00:00
- NTP time synchronization:
- NTP server address:
- NTP server port: 1
- NTP time synchronization interval: 5 min
- Last NTP synchronization status: Normal
- Last NTP synchronization time:

**Table 5-6** User parameters

Parameter	Description
Time zone	Specifies the time zone.
Time setting	Specifies the system date and time.
Daylight saving time	Specifies whether to enable daylight saving time (DST).
Offset time	Specifies the DST offset.
Start date	Specifies the DST offset start date.
Start time	Specifies the DST offset start time.
End date	Specifies the DST offset end date.
End time	Specifies the DST offset end time.
Clock source	Specifies whether to enable NTP time synchronization.
NTP server address	Specifies the NTP server IP address or domain name.

Parameter	Description
NTP server port	Specifies the server port.
NTP time synchronization interval	Specifies the NTP time synchronization interval.
Last NTP synchronization status	Display the result of the last synchronization of the NTP server.
Last NTP synchronization time	Set the time of the last synchronization of the NTP server.

 **NOTE**

You can set DST parameters and NTP parameters.


----End

### 5.6.3.5 Setting Communications Parameters



#### Procedure




**Step 1** On the home screen, choose **Settings > Comm. Parameters** to access the parameter setting screen.

**Figure 5-23** Communications parameters



**Table 5-7** Setting communications parameters

Parameter	Description
RS485_1	Set RS485 communications parameters. <b>RS485 CAN Resistor</b> is available only to the 1000 V solar inverters. This parameter is set to  by default. If signals are distorted or the communication is of poor quality because of an overlong communications cable, set the parameter to  for the last solar inverter in the daisy chain.
RS485_2	Set RS485 communications parameters. This parameter is displayed only for the solar inverters that can connect to the RS485 slave device.

Parameter	Description
MBUS	Set MBUS communications parameters. This parameter is displayed only for the solar inverters that support the MBUS function.
Ethernet	Set Ethernet parameters. <b>NOTE</b> <ul style="list-style-type: none"> <li>When <b>DHCP</b> is set to , the <b>IP address</b>, <b>Subnet mask</b>, and <b>Gateway</b> of the solar inverter are automatically allocated.</li> <li>When <b>DHCP</b> is set to , you can manually set the <b>IP address</b>, <b>Subnet mask</b>, and <b>Gateway</b>.</li> </ul>
Management system	Set management system parameters. This parameter is displayed only for the solar inverters that can connect to the SDongle. <b>NOTE</b> If <b>SSL encryption</b> is set to  , data will be transmitted without being encrypted, which may pose security risks. Therefore, exercise caution when setting this parameter.
4G/GPRS	Set 4G/GPRS communications parameters. This parameter is displayed only for the solar inverters that can connect to the SDongle.
WLAN	Setting WLAN communications parameters This parameter is displayed only for the solar inverters that can connect to the SDongle.
Dongle	Set Dongle communications parameters. This parameter is displayed only for the solar inverters that can connect to the SDongle.

**NOTE**

You can check whether the solar inverter supports the MBUS or SDongle function by viewing the product nameplate on it.

----End

### 5.6.3.6 Setting a Tracking System


#### Context

This function is available to the 1000 V (SUN2000 V200R001C91 and SUN2000 V200R001C93 only), 1100 V, and 1500 V solar inverters. The support parameters vary depending on the controller manufacturer. Set parameters based on site requirements. The following screenshots are based on the same scenario.

## Procedure

- Step 1** On the home screen, choose **Settings > Tracking System** to access the support parameter setting screen.

**Figure 5-24** Tracking system



- Step 2** Swipe left on the screen to access the support status screen, tap a support, and set parameters for the support.

**Figure 5-25** Support



----End

### 5.6.3.7 Setting a File Save Path

#### Prerequisite

This function is available only on the Android system.

#### Context

You can modify the save path for operation logs and solar inverter logs and export logs from the path.

#### Procedure

**Step 1** On the home screen, choose **Settings > File Save Path** to access the path setting screen.

**Figure 5-26** File save path



**Step 2** Tap **File save path** to set a file save path.

----End

### 5.6.4 Power Adjustment


#### Context

Due to permission restrictions, advanced users support the setting of power adjustment, which can set the grid-connected control parameters of the solar inverter.

#### Procedure

**Step 1** On the home screen, tap **Power Adjustment**.

**Figure 5-27** Power adjustment



**Step 2** Set power parameters as required.

For details about how to set the parameters, see [A Commercial Smart Inverters Parameters](#).

 **NOTE**


When setting the Grid-tied point control parameters, you need to enter the APP login password.

----End

## 5.6.5 Maintenance

An advanced user can tap **Maintenance** on the home screen to inspect, turn on, or turn off the solar inverters and detect the DC input.

**Figure 5-28** Maintenance screen (advanced user)



### 5.6.5.1 Device Inspection


#### Context


After a solar inverter is put into use, it should be inspected periodically to detect any potential risks and problems.

#### Procedure


- Step 1** On the home screen, choose **Maintenance** > **Inspection** to access the inspection screen.

**Figure 5-29** Device inspection



**Step 2** Choose **Inspection type**, tap  in the upper-right corner of the screen to start solar inverter inspection.

**Figure 5-30** Inverter Inspect



----End

## 5.6.5.2 License Management


### Context

The **License management** screen allows an advanced user to view the solar inverter certificate and obtain the status of the certificate.

### Procedure

**Step 1** On the home screen, choose **Maintenance** > **License management** to access the license management screen.

**Figure 5-31** License management





**NOTE**


- When **License status** is **Normal**, you can revoke the license through the drop-down list box in the upper-right corner.
- When **License status** is **Deregistered**, you can export and view the license revocation code.
- When **License status** is **No license**, you can load the license through the drop-down list box in the upper-right corner.

----End

### 5.6.5.3 Device Management

**Step 1** On the home screen, choose **Maintenance > Device Mgmt** to access the device management screen.

**Figure 5-32** Device management



- If no power meter is displayed on the screen, select a power meter from the drop-down list in the upper-right corner.

Parameter	Description
Model	<p>Set this parameter to the corresponding meter model.</p> <p><b>NOTE</b></p> <ul style="list-style-type: none"> <li>• Select an appropriate power meter based on the application scenario. The device model is subject to change. The actual product prevails.</li> <li>• Set the power meter model correctly. Otherwise, the power meter function may be unavailable.</li> </ul>
Device address	Set this parameter to the communication address of the power meter.
Current change ratio	<ul style="list-style-type: none"> <li>• Set this parameter to <b>1</b> if the power meter uploads the primary value.</li> <li>• Set this parameter based on the actual transformer ratio if the power meter uploads the secondary value.</li> </ul>

- After a power meter is added, tap it to view and modify the power meter parameters. To delete the power meter, touch and hold it.

----End

## 5.6.5.4 PV String Access Detection

### Context

- PV string access detection applies to large-scale commercial ground PV plants with PV strings facing the same direction.
- In AC or DC power limiting scenarios:
  - If the PV string access type has not been identified, **String Access Detection** will be displayed as **Not connected**. The PV string access type can be identified only when the solar inverters restore to the non-power limiting state and the current of all connected PV strings reaches the startup current.
  - If the PV string access type has been identified, when a certain PV string connected to the 2-in-1 terminals is lost, no alarm will be generated. If a certain PV string connected to the 2-in-1 terminals is restored, the access type cannot be identified. You can determine whether both 2-in-1 PV strings are restored only when the PV string current reaches **Startup current for 2-in-1 detection**.
- After setting the parameters, on the home screen, choose **Running Info. > Details** to check whether the PV string access status is normal.

### Procedure

- Step 1** On the home screen, choose **Maintenance > String Access Detection** and set PV string access detection parameters.

**Figure 5-33** String access detection



**Table 5-8** PV string access detection


Parameter	Description
String Access Detection	<b>String Access Detection</b> is set to <b>Disable</b> by default. After solar inverters are connected to the power grid, set <b>String Access Detection</b> to <b>Enable</b> .

Parameter	Description
Startup current (A)	<p>When the current of all connected PV strings reaches the preset value, the PV string access detection function is enabled.</p> <p><b>NOTE</b> Startup current setting rules:</p> <ul style="list-style-type: none"> <li>• Startup current = <math>I_{sc} (S_{1c}) \times 0.6</math> (rounded up). For details about <math>I_{sc} (S_{1c})</math>, see the PV module nameplate.</li> <li>• Default startup current (5 A): applicable to the scenarios where the short-circuit current <math>I_{sc} (S_{1c})</math> is greater than 8 A for the monocrystalline and polycrystalline PV modules.</li> </ul>
Startup current for 2-in-1 detection (A)	<p>When the current of a PV string reaches <b>Startup current for 2-in-1 detection</b>, the PV string is automatically identified as 2-in-1 string.</p> <p>You are advised to retain the default settings.</p>
PV string <i>N</i> access type <b>NOTE</b> <i>N</i> is the DC input terminal number of the solar inverter.	<p>Set this parameter based on the type of the PV string connected to DC input terminal <i>N</i> of the solar inverter.</p> <p>You are advised to retain the default value. If the value is incorrectly set, the PV string access type may be incorrectly identified and alarms may be generated by mistake for the PV string access status.</p>

----End

### 5.6.5.5 Startup and Shutdown

#### Procedure

- Step 1** On the home screen, tap **Maintenance** to access the maintenance screen.
- Step 2** Tap  next to **Power on** or **Power off** to perform the operation.
- Step 3** Enter the password for logging in to the app, and tap **OK**.

----End

### 5.6.5.6 Restoring Factory Settings

#### Context

#### NOTICE

Perform this operation with caution because all configured parameters except the current date, time, baud rate, and address will be restored to their factory default values. This operation will not affect operating information, alarm records, or system logs.

## Procedure

**Step 1** On the home screen, tap **Maintenance** to access the maintenance screen.

**Step 2** Tap  next to **Restore defaults** to perform the operation.

**Step 3** Enter the password for logging in to the app, and tap **OK**.

----End

## 5.6.5.7 Performing an AFCI Self-Check

### Context

The AFCI self-check function is available only to the solar inverter model marked with **-US**.

### Procedure

**Step 1** On the home screen, tap **Maintenance** to access the maintenance screen.

**Step 2** Tap  next to **AFCI self-check** to perform the operation.

**Step 3** Tap **OK**.

----End

## 5.6.5.8 Resetting a Solar Inverter

### Context

The solar inverter automatically shuts down and restarts after reset.

### Procedure

**Step 1** On the home screen, tap **Maintenance** to access the maintenance screen.

**Step 2** Click  next to **Reset** to perform the operation.

**Step 3** Enter the password for logging in to the app, and tap **OK**.

----End

## 5.6.5.9 Resetting Alarms

### Context

After alarms are reset, all active alarms and historical alarms of the solar inverter connected to the app will be cleared.

### Procedure

**Step 1** On the home screen, tap **Maintenance** to access the maintenance screen.

**Step 2** Click  next to **Alarm Reset** to perform the operation.

**Step 3** Enter the password for logging in to the app, and tap **OK**.

----End

### 5.6.5.10 Clearing Historical Energy Yield Data

#### Context

If you clear historical energy yield data, all the historical energy yield data of the solar inverters connecting to the app will be cleared.

#### Procedure

**Step 1** On the home screen, tap **Maintenance** to access the maintenance screen.

**Step 2** Tap  next to **Clear historical energy yield**.

**Step 3** Enter the password for logging in to the app, and tap **OK**.

----End

### 5.6.5.11 Importing and Exporting Configuration Files

#### Procedure

1. On the home screen, choose **Maintenance > Import and export configuration file** to access the screen for configuration file import and export.
  - Tap **Export Configuration File** to export the configuration files of the solar inverter to the phone.
  - Tap **Import Configuration File** to import the configuration files from the phone to the solar inverter.

### 5.6.5.12 IPS Test

#### Prerequisites

This function applies only to Italy CEIO-21 grid code.

#### Context

The Italy CEIO-21 grid code requires IPS self-check for the solar inverter. During the self-check process, the solar inverter consecutively checks the protection thresholds and time for 10-min overvoltage, level 1 overvoltage, level 1 undervoltage, level 1 overfrequency, and level 1 underfrequency. The solar inverter shuts down after the check starts, and it restarts after the check is successful.

#### Procedure

**Step 1** On the home screen, choose **Maintenance > IPS test** to access the IPS test screen.

- Step 2** Tap **Start** to start the check. After the check is complete, **IPS State** is displayed as **Self-test success**.  
**----End**

### 5.6.5.13 Spot-Check


#### Context

You can perform spot-check for the solar inverter whose **Grid Code** is **Japan standard**.

#### Procedure

- Step 1** On the home screen, tap **Spot-check** to access the spot-check screen.

**Figure 5-34** Spot-Check



- Step 2** Tap **START**.  
**----End**

## 5.6.5.14 DC Input Detection


### Context

The DC input detection function is only applicable to the 1500 V solar inverter system.

### Procedure

- Step 1** On the home screen, choose **Maintenance** > **Start DC Input Detection** to access the DC input detection screen.

**Figure 5-35** Starting DC input detection



- Step 2** Tap **Start**.

----End

## 5.6.5.15 Device Upgrade

### Prerequisites


- You have obtained the upgrade package with the help of the supplier or Huawei engineers.
- In the Android system, you have copied the upgrade package to the mobile phone. The package is a .zip file, which can be saved in a desired path and searched. To reduce the time for searching the package, you are advised to save it in the root directory of the memory or SD card of the mobile phone.
- Certain solar inverters (only SUN2000 V500R001C00) support MBUS upgrade. The actual UI prevails.

### Procedure

- Step 1** On the home screen, choose **Maintenance** > **Device upgrade**.

- Step 2** Access the device upgrade screen and tap **Upgrade**.

**Figure 5-36** Device upgrade



**Step 3** Perform operations as prompted.

----End

## 5.6.5.16 Device Logs

### Context


You can tap **Device Logs** to export operation logs, as well as alarm records and energy yield information of the solar inverter from the mobile phone.

### Procedure

**Step 1** On the home screen, choose **Maintenance** > **Device Logs** to access the log download screen.



**Figure 5-37** Downloading logs



**Step 2** You can download log files such as **Historical alarms** and **Configuration files**.

**NOTE**

- By default, Android system logs are saved in the **storage/emulated/0/inverterapp** folder in the phone memory. You can change the save path by referring to "Setting a File Save Path".
- The downloaded solar inverter logs are saved at the **Device Log** directory in **File Management** in your mobile phone. You can also send the logs to your mailbox for checking.

----End

### 5.6.5.17 Changing the WLAN Password

#### Context

You can tap **Maintenance** on the home screen to change the WLAN password to ensure account security.

**NOTE**

If the communication between the app and the solar inverter has not been established over WLAN, **Change WLAN Password** is not displayed on the screen.

## Procedure

**Step 1** On the **Maintenance** screen, tap **Change WLAN Password** on the app connection screen to access the password change screen.

**Step 2** Specify **Old password**, **New password**, and **Confirm password**, and then tap **OK**.

### **NOTE**

The password must meet the following requirements:

- Contains 8–30 characters.
- Contains at least two of the three types: lowercase letters, uppercase letters, and digits.

----End

## 5.6.5.18 Feedback


### Context

Users can provide feedback in text, pictures, and files.

### **NOTE**

Do not add private data.

## Procedure

**Step 1** Choose  > **Feedback** in the upper-right corner of the home screen.

**Figure 5-38** Feedback



**Step 2** Tap **Specify the type** and select **Feedback** or **Suggestion**.

**Step 3** Briefly describe the problem that you encounter in the **Description** column.

**Step 4** (Optional) Tap  to upload pictures.

**Step 5** (Optional) Tap  to upload logs. Select device logs or app logs as required.

**Step 6** Tap **Submit**.


----End

## 5.6.5.19 Help


### Context

If you have any questions when using an involved device or the app, search for solutions in the help information.

### Procedure

**Step 1** Choose  > **Help** in the upper-right corner of the home screen.

**Figure 5-39** Help



**Step 2** Specify your question. A solution will be displayed.

----End

## 5.6.5.20 About


### Context

You can query the app version, connected product model, SN, part number, firmware version, software version, technical support website, privacy policy (displayed only on the SUN2000 app), customer service contact information, and open source software policy.


#### NOTE

- When the app starts for the first time after being downloaded or updated, the privacy policy is displayed. You can use the app only after agreeing to the privacy policy, and the privacy policy will no longer appear. If you do not agree to the privacy policy, the app exits, and the privacy policy is still displayed when you start the app next time until you agree to the privacy policy.
- You can revoke the agreed privacy policy.

### Procedure

**Step 1** In the upper-right corner of the home screen, choose  > **About** to view the app version, connected product model, SN, part number, firmware version, software version, and technical support website.

**Figure 5-40** About



**Step 2** Tap **Privacy policy**, **Customer service contact information**, or **Open source software policy** to view the privacy policy, customer service contact information, and open source software policy.

----End


## 5.7 Screen Operations (Special User)

### 5.7.1 Query

#### Procedure

**Step 1** After logging in to the app, you can view the active power and energy yield of solar inverters on the home screen.

**Figure 5-41** Home screen





**Step 2** Tap **Alarm management** or **Device Monitoring** to view active alarms, historical alarms, and running information of the solar inverters.

You can view the following information on the alarm management screen:

- Tap an alarm record and view the alarm details.
- Swipe right or left on the screen or tap either **Active Alarm** or **Historical Alarm** to display a list of active alarms or historical alarms.

**NOTE**

- Tap  to set the alarm sorting mode for active alarms or historical alarms.
- Tap  to set a time criterion. The historical alarms generated within the time segment are displayed.
- Select the alarms that can be manually cleared, and tap **Delete** on the right of the alarm to manually clear the alarms.

**NOTE**


- Alarms that have been manually cleared can be viewed on the **Historical Alarm** screen.
- Only the **AFCI Self-Check Failure** and **DC Arc Fault** alarms can be manually cleared. Only the products whose technical specifications contain AFCI supports manual alarm clearance.

----End

## 5.7.2 Settings

On the home screen, a special user can tap **Settings** to set power grid, protection, and feature parameters for the solar inverter.

**Figure 5-42** Settings (special user)



### NOTICE


- The configurable solar inverter parameters vary with the solar inverter model and grid code. The displayed parameters prevail. The parameter list provided in this section includes all configurable parameters.
- The parameter ranges vary with the device model. The listed ranges are for reference only.
- The parameter names, value ranges, and default values are subject to change. The actual display prevails.

### 5.7.2.1 Setting Grid Parameters

#### Procedure

- Step 1** On the home screen, choose **Settings** > **Grid Parameters** to access the parameter setting screen.

**Figure 5-43** Grid parameters (special user)



For details about how to set the parameters, see [A Commercial Smart Inverters Parameters](#).


----End

## 5.7.2.2 Setting Protection Parameters

### Procedure

- Step 1** On the home screen, choose **Settings > Protection Parameters** to access the parameter setting screen.

**Figure 5-44** Protection parameters (special user)



For details about how to set the parameters, see [A Commercial Smart Inverters Parameters](#).

----End


### 5.7.2.3 Setting Feature Parameters

#### Procedure

- Step 1** On the home screen, choose **Settings** > **Feature Parameters** to access the parameter setting screen.



**Figure 5-45** Feature parameters (special user)



For details about how to set the parameters, see [A Commercial Smart Inverters Parameters](#).

----End

## 5.7.2.4 Setting Power Adjustment Parameters

### Procedure

- Step 1** On the home screen, choose **Settings** > **Power Adjustment** to access the parameter setting screen.

**Figure 5-46** Power adjustment parameters (special user)



For details about how to set the parameters, see [A Commercial Smart Inverters Parameters](#).

----End

## 5.7.2.5 Setting a File Save Path

### Prerequisite

This function is available only on the Android system.


## Context

You can modify the save path for operation logs and solar inverter logs and export logs from the path.

## Procedure

**Step 1** On the home screen, choose **Settings > File Save Path** to access the path setting screen.

**Figure 5-47** File save path



**Step 2** Tap **File save path** to set a file save path.

----End

## 5.7.3 Power Adjustment


### Context

Due to permission restrictions, special users support the setting of power adjustment, which can set the active power, reactive power, and grid connection point control parameters of the solar inverter.

### Procedure

**Step 1** On the home screen, tap **Power Adjustment**.

**Figure 5-48** Power adjustment



**Step 2** Set power parameters as required.

For details about how to set the parameters, see [A Commercial Smart Inverters Parameters](#).

#### NOTE


When setting the Grid-tied point control parameters, you need to enter the APP login password.

----End

## 5.7.4 Maintenance

On the home screen, a special user can tap **Maintenance** to start or shut down the solar inverter and restore factory settings.


**Figure 5-49** Maintenance (special user)



### 5.7.4.1 Device Management

**Step 1** On the home screen, choose **Maintenance** > **Device Mgmt** to access the device management screen.

**Figure 5-50** Device management



- If no power meter is displayed on the screen, select a power meter from the drop-down list in the upper-right corner.

Parameter	Description
Model	<p>Set this parameter to the corresponding meter model.</p> <p><b>NOTE</b></p> <ul style="list-style-type: none"> <li>• Select an appropriate power meter based on the application scenario. The device model is subject to change. The actual product prevails.</li> <li>• Set the power meter model correctly. Otherwise, the power meter function may be unavailable.</li> </ul>
Device address	Set this parameter to the communication address of the power meter.

Parameter	Description
Current change ratio	<ul style="list-style-type: none"><li>Set this parameter to <b>1</b> if the power meter uploads the primary value.</li><li>Set this parameter based on the actual transformer ratio if the power meter uploads the secondary value.</li></ul>


- After a power meter is added, tap it to view and modify the power meter parameters. To delete the power meter, touch and hold it.

----End

## 5.7.4.2 Startup and Shutdown

### Procedure

**Step 1** On the home screen, tap **Maintenance** to access the maintenance screen.

**Step 2** Tap  next to **Power on** or **Power off** to perform the operation.

**Step 3** Enter the password for logging in to the app, and tap **OK**.

----End

## 5.7.4.3 Restoring Factory Settings

### Context

#### NOTICE

Perform this operation with caution because all configured parameters except the current date, time, baud rate, and address will be restored to their factory default values. This operation will not affect operating information, alarm records, or system logs.

### Procedure

**Step 1** On the home screen, tap **Maintenance** to access the maintenance screen.

**Step 2** Tap  next to **Restore defaults** to perform the operation.

**Step 3** Enter the password for logging in to the app, and tap **OK**.

----End

## 5.7.4.4 Device Upgrade

### Prerequisites


- You have obtained the upgrade package with the help of the supplier or Huawei engineers.
- In the Android system, you have copied the upgrade package to the mobile phone. The package is a .zip file, which can be saved in a desired path and searched. To reduce the time for searching the package, you are advised to save it in the root directory of the memory or SD card of the mobile phone.
- Certain solar inverters (only SUN2000 V500R001C00) support MBUS upgrade. The actual UI prevails.

### Procedure

**Step 1** On the home screen, choose **Maintenance** > **Device upgrade**.

**Step 2** Access the device upgrade screen and tap **Upgrade**.

**Figure 5-51** Device upgrade



**Step 3** Perform operations as prompted.

----End

## 5.7.4.5 Device Logs


### Context

You can tap **Device Logs** to export operation logs, as well as alarm records and energy yield information of the solar inverter from the mobile phone.

### Procedure

**Step 1** On the home screen, choose **Maintenance** > **Device Logs** to access the log download screen.

**Figure 5-52** Downloading logs



**Step 2** You can download log files such as **Historical alarms** and **Configuration files**.

 **NOTE**

- By default, Android system logs are saved in the **storage/emulated/0/inverterapp** folder in the phone memory. You can change the save path by referring to "Setting a File Save Path".
- The downloaded solar inverter logs are saved at the **Device Log** directory in **File Management** in your mobile phone. You can also send the logs to your mailbox for checking.

----End

## 5.7.4.6 Feedback


### Context

Users can provide feedback in text, pictures, and files.


 **NOTE**

Do not add private data.

### Procedure

**Step 1** Choose  > **Feedback** in the upper-right corner of the home screen.


**Figure 5-53** Feedback



**Step 2** Tap **Specify the type** and select **Feedback** or **Suggestion**.

**Step 3** Briefly describe the problem that you encounter in the **Description** column.

**Step 4** (Optional) Tap  to upload pictures.

**Step 5** (Optional) Tap  to upload logs. Select device logs or app logs as required.

**Step 6** Tap **Submit**.


----End

## 5.7.4.7 Help


### Context

If you have any questions when using an involved device or the app, search for solutions in the help information.

### Procedure

**Step 1** Choose  > **Help** in the upper-right corner of the home screen.

**Figure 5-54** Help



**Step 2** Specify your question. A solution will be displayed.

----End

## 5.7.4.8 About


### Context

You can query the app version, connected product model, SN, part number, firmware version, software version, technical support website, privacy policy (displayed only on the SUN2000 app), customer service contact information, and open source software policy.


#### NOTE

- When the app starts for the first time after being downloaded or updated, the privacy policy is displayed. You can use the app only after agreeing to the privacy policy, and the privacy policy will no longer appear. If you do not agree to the privacy policy, the app exits, and the privacy policy is still displayed when you start the app next time until you agree to the privacy policy.
- You can revoke the agreed privacy policy.

### Procedure

- Step 1** In the upper-right corner of the home screen, choose  > **About** to view the app version, connected product model, SN, part number, firmware version, software version, and technical support website.

**Figure 5-55** About



- Step 2** Tap **Privacy policy**, **Customer service contact information**, or **Open source software policy** to view the privacy policy, customer service contact information, and open source software policy.

----End



# 6 Operations on the Screen for Connecting to the SmartLogger

---

## NOTICE

- The app screenshots provided in this section correspond to the SUN2000 app 3.2.00.003 version. The data on the screenshots is for reference only.
  - Delivering a reset, factory reset, shutdown, or upgrade command to the solar inverters may cause power grid connection failure, which affects the energy yield.
  - Only professionals are allowed to set the grid parameters, protection parameters, feature parameters, power adjustment parameters, and grid-tied point control parameters of the solar inverters. If the grid parameters, protection parameters, and feature parameters are incorrectly set, the solar inverters may not connect to the power grid. If the power adjustment parameters and grid-tied point control parameters are incorrectly set, the solar inverters may not connect to the power grid as required. In these cases, the energy yield will be affected.
  - Only professionals are allowed to set the power grid scheduling parameters of the SmartLogger. Incorrect settings may cause the PV plant to fail to connect to the power grid as required, which affects the energy yield.
- 

## 6.1 SmartLogger

### Connection Modes

- The SmartLogger2000 has a built-in Bluetooth module. The app can be connected to the SmartLogger2000 over Bluetooth after the SmartLogger2000 is powered on.
- The SmartLogger1000A/SmartLogger3000 has a built-in WLAN module. The app can be connected to the SmartLogger1000A/SmartLogger3000 over WLAN after the SmartLogger1000A/SmartLogger3000 is powered on.

**Table 6-1** Product mapping

SmartLogger	SmartLogger Version	App Version	Bluetooth Connection	WLAN Connection
SmartLogger3000	SmartLogger V300R001C00 and later versions	3.2.00.003	-	Supported
SmartLogger2000	SmartLogger V200R001C00SP C103 and later versions		Supported	-
	SmartLogger V200R001C10SP C010 and later versions			
	SmartLogger V200R001C30 and later versions			
	SmartLogger V200R002C10 and later versions			
	SmartLogger V200R002C20 and later versions			
SmartLogger1000A	SmartLogger V100R002C00 and later versions		-	Supported

## 6.2 User Operation Permissions


For SmartLogger2000 and SmartLogger1000A, the user accounts that can log in to the app are classified into common users, special users, and advanced users. You can set different user permissions based on the responsibilities of PV plant operation personnel.

- Common users: Has the permissions of viewing data about the SmartLogger and the devices connected to it, setting SmartLogger user parameters, and changing the system password.
- Advanced users: Has the permissions of viewing data about the SmartLogger and the devices connected to it, setting functional parameters, managing devices, and maintaining the system.
- Special users: Has the permissions of viewing data about the SmartLogger and the devices connected to it, managing devices, and maintaining the system.

For SmartLogger3000, the user accounts that can log in to the app are classified into installer and user, user permissions can refer to common users permissions, and installer permissions can refer to advanced users permissions and special users permissions.

Figure 6-1, Figure 6-2, and Figure 6-3 show the menu operation permissions of common users, special users, and advanced users respectively.


**Figure 6-1** Operation permissions of common users



**NOTE**

Common users can view data and start or shut down the devices under **Monitoring**.


**Figure 6-2** Operation permissions of advanced users



**NOTE**

- Advanced users can view data, set parameters, download logs, and start or shut down the devices under **Monitoring**.
- **Path Settings** is available only to the Android system.

**Figure 6-3** Operation permissions of special users



**NOTE**

Special users can view data, download logs, and start or shut down the devices under **Monitoring**.

## 6.3 Login

### Prerequisites


- The SmartLogger has been powered on.
- The Bluetooth function of the SmartLogger is enabled by default.
- Connect over a WLAN/Bluetooth:
  - a. The WLAN/Bluetooth function is enabled on the mobile phone.

- b. Keep the mobile phone within 5 m from the SmartLogger. Otherwise, the communication between them would be affected.

## Procedure


- Step 1** Start the app. Tap **Connect** to access the code scanning screen and connect to the SmartLogger.

**Figure 6-4** Connect




- Code scanning: On the scanning screen, place the QR code of the Device in the scan frame. The device will be automatically connected after the code is identified.

**Figure 6-5** Scan



- Manual connection: On the scanning screen, tap **Manual Connection** and select a connection mode.

**Figure 6-6** Manual connection



- Select **WLAN** and connect the SmartLogger1000A or SmartLogger3000 to the corresponding WLAN in the WLAN connection list of the APP. The initial name of the WLAN is **Logger\_SN bar code**, and the initial password is **Changeme**.

---

#### NOTICE

Use the initial password upon first power-on and change it immediately after login. To ensure account security, change the password periodically and keep the new password in mind. Not changing the initial password may cause password disclosure. A password left unchanged for a long period of time may be stolen or cracked. If a password is lost, devices cannot be accessed. In these cases, the user is liable for any loss caused to the PV plant.


---

- Select **Bluetooth**, and tap **Search for Device**. After a Bluetooth device is found, select the target Bluetooth device, and set up a connection. When the Bluetooth connection is used for the SmartLogger2000, the name of the connected Bluetooth device is **LOG+last eight digits of the SN bar code**.

**Step 2** Select a login user and enter the password, tap **Log In**.



**Figure 6-7** Login



### NOTICE

- The login password is the same as that for the SmartLogger connected to the app and is used only when the SmartLogger connects to the app.
- For SmartLogger1000A and SmartLogger2000, the initial passwords for **Common User**, **Advanced User**, and **Special User** are all **00000a**.
- For SmartLogger3000, the initial passwords for **installer** and **user** are all **00000a**.
- Use the initial password upon first power-on and change it immediately after login. To ensure account security, change the password periodically and keep the new password in mind. Not changing the initial password may cause password disclosure. A password left unchanged for a long period of time may be stolen or cracked. If a password is lost, devices cannot be accessed. In these cases, the user is liable for any loss caused to the PV plant.
- During the login, if five consecutive invalid password entries are made (the interval between two consecutive entries is less than 2 minutes), the account will be locked for 10 minutes. The password should consist of six characters.

**Step 3** After successful login, the quick settings screen or home screen is displayed.

### NOTE

- If you log in to the app after the SmartLogger powers on for the first time or the SmartLogger factory defaults are restored, the quick settings screen will be displayed. You can set basic parameters for the SmartLogger on the **Quick Settings** screen. After the setting, you can modify the parameters after choosing **MoreSettings**.
- If you do not set basic parameters for the SmartLogger on the **Quick Settings** screen, the screen is still displayed when you log in to the app next time.

----End


## 6.4 Screen Operations (Common User)

### 6.4.1 Query

#### Procedure

**Step 1** After logging in to the app, you can view the running details of the connected solar inverters on the home screen.

**Figure 6-8** Home screen



**Table 6-2** Home screen

Parameter	Description
Total Inverter Qty	Number of solar inverters connected to the SmartLogger.
Rated power	Total rated power of solar inverters connected to the SmartLogger.
Output power	Total output power of solar inverters connected to the SmartLogger.
E-Total	Total energy yields of solar inverters connected to the SmartLogger.
E-Daily	Total energy yields of solar inverters connected to the SmartLogger on the current day.
CO <sub>2</sub> reduction	Total amount of reduced CO <sub>2</sub> emission of the solar inverters connected to the SmartLogger
Income	Total revenues corresponding to energy yields of solar inverters connected to the SmartLogger.
Grid scheduling	Active power percentage and reactive power factor for power grid scheduling.


Parameter	Description
Alarm	<p>Current alarms: You can view the detailed information about major, minor, and warning alarms.</p> <p>Historical alarms: You can view details about historical alarms filtered by sequence number, device, and time.</p>
Yield	<p>You can query information about energy yields of all solar inverters connected to the SmartLogger.</p> <p>Tap <b>Day</b>, <b>Month</b>, <b>Year</b>, or <b>History</b> to display the daily, monthly, yearly, or historical energy yield information.</p>

----End

## 6.4.2 Settings

A common user can choose **More > Settings** to set user parameters for the SmartLogger.

**Figure 6-9** Settings (Common User)



### 6.4.2.1 Setting the System Date and Time

#### Procedure

**Step 1** Choose **More > Settings > User param. > Date&Time** to set the date and time.

**Figure 6-10** Date&Time screen



**Step 2** Set the date and time based on the region where the SmartLogger is located.

 **NOTE**


For a solar inverter that supports DST, if an advanced user enables DST, a common user can view DST data. The displayed parameters are for reference only.

----End

## 6.4.2.2 Setting Plant Information

**Step 1** Choose **More > Settings > User param. > Plant** to access the parameter setting screen.

**Figure 6-11** Plant



**Step 2** Tap target parameters. On the displayed screen, enter or select relevant information.

 **NOTE**

The plant parameters that are manually entered must not contain any special character, such as "<>:;'?()#&\\\$|%+;~^" in the English half-width status.

----End

## 6.4.2.3 Setting Revenue Parameters

### Procedure

**Step 1** Choose **More > Settings > User param. > Currency** to access the parameter setting screen.

**Figure 6-12** Gain



----End

## 6.4.3 Maintenance

### 6.4.3.1 System Maintenance


#### Context

A common user can choose **More > System Maintenance** to change only the SmartLogger password.

#### Procedure

- Step 1** Choose **More > System Maintenance > Change Password** to access the password change screen.

**Figure 6-13** Changing a password



- Step 2** Type the old password, new password, and confirmation password. Tap **OK**.

#### NOTE

The password must meet the following requirements:

- Contains 6–20 characters.
- Contains at least two of the three types: lowercase letters, uppercase letters, and digits.

----End

### 6.4.3.2 Feedback


#### Context

Users can provide feedback in text, pictures, and files.


 **NOTE**

Do not add private data.

## Procedure


**Step 1** Choose  > **Feedback** in the upper-right corner of the home screen.

**Figure 6-14** Feedback




**Step 2** Tap **Specify the type** and select **Feedback** or **Suggestion**.

**Figure 6-15** Problem record



**Step 3** Briefly describe the problem that you encounter in the **Description** column.

**Step 4** (Optional) Tap  to upload pictures.

**Step 5** (Optional) Tap  to upload logs. Select device logs or app logs as required.

**Step 6** Tap **Submit**.


----End

### 6.4.3.3 Help


#### Context

If you have any questions when using an involved device or the app, search for solutions in the help information.

#### Procedure


- Step 1** Choose  > **Help** in the upper-right corner of the home screen.

**Figure 6-16** Help 1



- Step 2** Specify your question. A solution will be displayed.

**Figure 6-17** Help 2



----End

### 6.4.3.4 About

#### Context


You can query the app version, connected product model, SN, firmware version, software version, technical support website, privacy policy (displayed only on the SUN2000 app), customer service contact information, and open source software policy.

#### NOTE


- When the app starts for the first time after being downloaded or updated, the privacy policy is displayed. You can use the app only after agreeing to the privacy policy, and the privacy policy will no longer appear. If you do not agree to the privacy policy, the app exits, and the privacy policy is still displayed when you start the app next time until you agree to the privacy policy.
- You can revoke the agreed privacy policy.



## Procedure

- Step 1** In the upper-right corner of the home screen, choose  > **About** to view the app version, connected product model, SN, firmware version, software version, and technical support website.

**Figure 6-18** About



- Step 2** Tap **Privacy policy**, **Customer service contact information**, or **Open source software policy** to view the privacy policy, customer service contact information, and open source software policy.


----End

## 6.4.4 Device Monitoring

### 6.4.4.1 Query

- Step 1** On the home screen, tap **Monitor** to access the device monitoring screen.

**Figure 6-19** Device monitoring



- Step 2** Select a target device to access the function menu screen of the device.
- Step 3** Tap **Alarm**, **Running Info.**, **Energy Yield**, or **About** to view the alarms, running information, energy yield, and version information about the device.

#### NOTE

- The displayed information varies according to the device type.
- The SmartLogger can connect to third-party devices that support the Modbus-RTU protocol, such as the box-type transformer and EMI. The SmartLogger cannot automatically search user-defined devices. You need to manually add them.

- The SmartLogger can connect to a maximum of five types of user-defined devices and can connect to multiple devices of the same type.
- The SmartLogger can connect to a third-party device that supports IEC103, such as a relay protection or monitoring device like a box-type transformer. The SmartLogger cannot automatically search IEC103 devices. You need to manually add them.
- The SmartLogger can connect to a maximum of five types of IEC103 devices and can connect to multiple devices of the same type.

----End

## 6.4.4.2 Maintenance


### Context

Common users can maintain only a solar inverter. They manually send commands to start or shut down the solar inverter.


### Procedure

- Step 1** Tap **SUN2000** on the **Monitor** screen and select the target device to access the function menu screen of the solar inverter.

**Figure 6-20** Maintenance



- Step 2** Tap **Maintenance**.

- Step 3** Tap  next to **Power on** or **Power off** to perform the operation.

#### **NOTE**

Tap **Performance Data** to view the performance data curve of the solar inverter.

- Step 4** Enter the password for logging in to the app, and tap **OK**.

----End


## 6.5 Screen Operations (Advanced User)

### 6.5.1 Query

#### Procedure

- Step 1** After logging in to the app, you can view the running details of the connected solar inverters on the home screen.

**Figure 6-21** Home screen



**Table 6-3** Home screen

Parameter	Description
Total Inverter Qty	Number of solar inverters connected to the SmartLogger.
Rated power	Total rated power of solar inverters connected to the SmartLogger.
Output power	Total output power of solar inverters connected to the SmartLogger.
E-Total	Total energy yields of solar inverters connected to the SmartLogger.


Parameter	Description
E-Daily	Total energy yields of solar inverters connected to the SmartLogger on the current day.
CO <sub>2</sub> reduction	Total amount of reduced CO <sub>2</sub> emission of the solar inverters connected to the SmartLogger
Income	Total revenues corresponding to energy yields of solar inverters connected to the SmartLogger.
Grid scheduling	Active power percentage and reactive power factor for power grid scheduling.
Alarm	Current alarms: You can view the detailed information about major, minor, and warning alarms. Historical alarms: You can view details about historical alarms filtered by sequence number, device, and time.
Yield	You can query information about energy yields of all solar inverters connected to the SmartLogger. Tap <b>Day</b> , <b>Month</b> , <b>Year</b> , or <b>History</b> to display the daily, monthly, yearly, or historical energy yield information.

----End

## 6.5.2 Settings

An advanced user can choose **More > Settings** to access the settings screen and set the user parameters, communications parameters, extended parameters, and file save path for the SmartLogger.

**Figure 6-22** Settings (advanced user)



**NOTE**

Only the SmartLogger1000A/SmartLogge3000 supports **Mobile Data (4G/3G/2G)** and **WLAN** settings.

## 6.5.2.1 Setting the System Date and Time

### Procedure

**Step 1** Choose **More > Settings > User param. > Date&Time** to set the date and time.

**Figure 6-23** Date&Time screen



**Step 2** Set the date and time based on the region where the SmartLogger is located.

 **NOTE**


For a solar inverter that supports DST, if an advanced user enables DST, a common user can view DST data. The displayed parameters are for reference only.

----End

## 6.5.2.2 Setting Plant Information

**Step 1** Choose **More > Settings > User param. > Plant** to access the parameter setting screen.

**Figure 6-24** Plant



**Step 2** Tap target parameters. On the displayed screen, enter or select relevant information.

 **NOTE**

The plant parameters that are manually entered must not contain any special character, such as "<>:;'?()#&\\\$|%+;~^" in the English half-width status.

----End

## 6.5.2.3 Setting Revenue Parameters

### Procedure

**Step 1** Choose **More > Settings > User param. > Currency** to access the parameter setting screen.

**Figure 6-25** Gain

----End

## 6.5.2.4 Setting Ethernet Parameters

### Context

Set Ethernet parameters to ensure proper operation of Ethernet ports and functions of logging in to the embedded WebUI of the SmartLogger, connecting to the NMS, and sending emails.

### Procedure

- Step 1** Choose **More > Settings > Comm. Param. > Ethernet** to access the Ethernet parameter setting screen.
- Step 2** Tap target parameters. On the displayed screen, enter relevant information.

#### NOTICE

If the SmartLogger connects to the Internet through a router, note the following when setting Ethernet parameters:

- Set the NMS address to the IP address of the router.
- Ensure that the IP address of the SmartLogger is in the same network segment as the NMS address.
- Set the domain name server (DNS) address to the IP address of the router or obtain the DNS address from the network provider.
- After the IP address is changed, you need to use the new IP address to log in to the system.
- When DHCP is enabled, the IP address cannot be set.

----End

## 6.5.2.5 Setting RS485 Parameters

### Context

Set RS485 parameters to ensure normal communication between the SmartLogger and devices such as the SUN2000, EMI, and power meter.


## Procedure

**Step 1** Choose **More > Settings > Comm. Param. > RS485** to access the parameter setting screen.

**Step 2** Select a port from **COM1** to **COM6**.

Use the settings of **COM1** as an example.

**Figure 6-26** COM1



COM1	
Baud rate(bps)	9600
Parity	None
Start address	1
End address	100
Protocol	Modbus
Stop Bit	NA

### NOTE

- **COM1** to **COM6** correspond to communications ports **COM1–COM3** (SmartLogger1000A and SmartLogger3000) or **COM1–COM6** (SmartLogger2000). The default baud rate is 9600 bit/s.
- Set the protocol supported by the RS485 port based on either the protocol supported by the connected device or the status of the device in the network. When the SmartLogger serves as a slave node to interconnect with a third-party device over Modbus-RTU, set **Protocol** to **Modbus-Slave**. When the connected solar inverter performs rapid power grid scheduling using both MBUS and RS485, set **Protocol** to **Modbus-Control**.
- **Parity**, **Protocol**, and **Stop bit** must be set to the same values for all devices connected to the same RS485 port.
- The baud rate for the RS485 ports of the SmartLogger must be the same as the baud rate for the device that communicates with the SmartLogger.
- $1 \leq \text{Start address} \leq \text{End address} \leq 247$ . The address range of the ports can overlap. Set the address range as required. A larger address range requires a longer searching time. The start and end addresses have no impact on the devices that have been connected.

**Step 3** On the **RS485** screen, tap **Night Communication Settings** to set the parameters for communication at night.

----End


## 6.5.2.6 Setting Modbus-RTU Power Meter Parameters

### Procedure

**Step 1** Choose **More > Settings > Comm. Param. > Power Meter** to access the parameter setting screen.



**Figure 6-27** Power Meter



**Step 2** Tap target parameters. On the displayed screen, enter relevant information.


----End

## 6.5.2.7 Setting Management System Parameters

### Procedure

**Step 1** Choose **More > Settings > Comm. Param. > Management System** to access the parameter setting screen.

**Figure 6-28** Management system



### NOTE

- Set **Server** to the IP address or domain name of the NMS server.
- When the SmartLogger connects to the Huawei NMS, retain the default value **16100** for **Port number**. When the SmartLogger connects to a third-party NMS, set **Port number** according to the server port enabled in the third-party NMS.

- In most cases, set **Address mode** to **Physical address**. In this mode, addresses of devices connected to each RS485 port cannot be duplicate. If the devices connected to the six RS485 ports of the SmartLogger have duplicate addresses, set **Address mode** to **Logical address**.
- If **SSL encryption** is set to , data will be transmitted without being encrypted, which may pose security risks. Therefore, exercise caution when setting this parameter.
- If **Secondary challenge authentication** is set to , the result of the second challenge authentication is not checked, which may pose security risks. Therefore, exercise caution when setting this parameter.

----End

## 6.5.2.8 Setting Modbus TCP Parameters


### Context

Set Modbus-TCP parameters correctly to ensure normal communication between the SmartLogger and a third-party NMS.

### Procedure

- Step 1** Choose **More > Settings > Comm. Param. > Modbus TCP** to access the parameter setting screen.

**Figure 6-29** Modbus TCP



 **NOTE**

- Modbus TCP is a universal standard protocol used to connect to a third-party management system. Because there is no security authentication mechanism, data transmitted by Modbus TCP is not encrypted. To reduce network security risks, the function of connecting to a third-party management system using Modbus TCP is disabled by default. This protocol can transmit the running data and control commands of PV plants, which may cause user data breach and control permission theft. Therefore, exercise caution when using this protocol. Users are liable for any loss caused by the use of this protocol to connect to a third-party management system (non-secure protocol). Users are advised to take measures at the PV plant level to reduce security risks, or use Huawei management system to mitigate the risks.
- If the devices connected to the six RS485 ports of the SmartLogger have duplicate addresses, set **Address mode** to **Logical address**.

----End

## 6.5.2.9 Setting IEC103 Device Parameters

### Procedure

**Step 1** Choose **More > Settings > Comm. Param. > IEC103** to access the parameter setting screen.

**Figure 6-30** IEC103



**Step 2** Tap target parameters. On the displayed screen, enter relevant information.


----End

## 6.5.2.10 Setting IEC104 Device Parameters

### Procedure

**Step 1** Choose **More > Settings > Comm. Param. > IEC104** to access the parameter setting screen.

**Figure 6-31** IEC104



**Step 2** Tap target parameters. On the displayed screen, enter relevant information.

**NOTE**

- IEC104 is a universal standard protocol used to connect to a third-party management system. Because there is no security authentication mechanism, data transmitted by IEC104 is not encrypted. To reduce network security risks, the function of connecting to a third-party management system using IEC104 is disabled by default. This protocol can transmit the running data and control commands of PV plants, which may cause user data breach and control permission theft. Therefore, exercise caution when using this protocol. Users are liable for any loss caused by the use of this protocol to connect to a third-party management system (non-secure protocol). Users are advised to take measures at the PV plant level to reduce security risks, or use Huawei management system to mitigate the risks.
- You can set the IP whitelist after **Linking setting** on the **Basic parameters** screen is enabled.
- On the **Transfer table config** screen, you can set teleindication and telemetry signals for devices.

----End

## 6.5.2.11 Setting FTP Parameters

### Context

The FTP function is used to access a third-party NMS. The SmartLogger can report the configuration information and running data of the managed plant system through FTP. The third-party NMS can access Huawei devices with proper configurations.


**NOTE**

FTP is a universal standard protocol without any security authentication mechanism. Data transmitted by FTP is not encrypted. To reduce network security risks, the IP address of the connected third-party FTP server is left blank by default. This protocol can transmit the running data of PV plants, which may cause user data breach. Therefore, exercise caution when using this protocol. Users are liable for any loss caused by the enabling of the FTP protocol (non-secure protocol). Users are advised to take measures at the PV plant level to reduce security risks, or use Huawei management system to mitigate the risks

### Procedure

- Step 1** Choose **More > Settings > Extended Param. > FTP** to access the parameter setting screen.

**Figure 6-32** FTP

**NOTE**

- Perform **Test transmission** to check whether the SmartLogger can report data to the FTP server.

- Set **FTP server** to the domain name or IP address of the FTP server. If **FTP server** is set to the domain name of the FTP server, ensure that the address of the DNS server is set correctly.
- Set **User name** and **Password** for logging in to the FTP server.
- Set **Remote directory** to create a subdirectory of the same name under the default path for uploading data.
- If **Data export** is enabled, you can set the SmartLogger to report data regularly or at a specified time. Data reported at a specified time is all data, whose file name remains the same for a whole day. You can choose all data or incremental data to be reported regularly.

----End

## 6.5.2.12 Setting Email Parameters

### Context


The SmartLogger can send emails to inform users of the current energy yield information, alarm information, and device status of the power plant system, helping users know the running status of the power plant system in time.

When using this function, ensure that the SmartLogger can connect to the configured email server and the Ethernet parameters and email parameters are correctly set for the SmartLogger.

### Procedure

**Step 1** Choose **More > Settings > Extended Param. > Email** to access the parameter setting screen.

**Figure 6-33** Email



#### NOTE

- You can tap **Send test email** to check whether the SmartLogger can successfully send emails to users.
- You can set **SMTP server** to the domain name or IP address of the SMTP server. If it is set to the domain name of the SMTP server, ensure that the address of the DNS server is set correctly.
- Set **User name** and **Password** for logging in to the SMTP server.
- **Send address** indicates the sender's email address. Ensure that the sender's email server is the same as the server specified by **SMTP server**.

----End

## 6.5.2.13 Setting a File Save Path

### Prerequisites

This function is available only on the Android system.


### Context

You can modify the save path for logs of devices connected to the SmartLogger and export logs from the path.

### Procedure

- Step 1** Choose **More > Settings > Path Settings > File save path** to access the screen for setting a file save path.

**Figure 6-34** Setting a file save path



- Step 2** Tap **File save path** to set a file save path.

----End

## 6.5.3 Maintenance


### 6.5.3.1 Solar Inverter Inspection

### Context


After a solar inverter is put into use, it should be inspected periodically to detect any potential risks and problems.

### Procedure


- Step 1** Tap **More > Inverter Inspect** to access the inspection screen.



**Step 2** Select **Single inspect** or **Batch inspect**.



**Step 3** Select **Inspection type** and tap **Next** in the upper-right corner of the screen to start inspection.



**Step 4** An inspection file is generated after the inspection is complete.

**NOTE**

By default, the inspection file is saved in **storage/emulated/0/inverterapp** in the phone memory. You can change the log save path by referring to *Setting a File Save Path*.

----End


## 6.5.3.2 System Maintenance

### 6.5.3.2.1 Changing a User Password

#### Procedure

**Step 1** Choose **More > System Maintenance > Change Password** to access the password change screen.

**Figure 6-35** System Maintenance



**NOTE**

The password must meet the following requirements:

- Contains 6–20 characters.
- Contains at least two of the following types: lowercase letters, uppercase letters, and digits.

----End

### 6.5.3.2.2 Resetting the System


#### Context

After the system resets, the SmartLogger restarts.

#### Procedure

- Step 1** Choose **More > System Maintenance > Reset**. A dialog box for resetting the system is displayed.



**Figure 6-36** System Maintenance

**Step 2** Enter the password for logging in to the app, and tap **OK**.

----End

### 6.5.3.2.3 Clearing Data

#### Context

Clear data if the SmartLogger is relocated and its historical data needs to be deleted.


#### NOTICE

- After you perform **Clear Data**, electric energy yield data, performance data, and alarms are cleared from the SmartLogger.
- After you perform **Clear Data**, the devices connected to the SmartLogger are not removed. If the original device will no longer connect to the SmartLogger, remove the device.
- If you perform **Clear Data** on the SmartLogger, you also have to perform **Reset Alarms** on the NMS. Otherwise, the alarm information collected by the NMS and SmartLogger will be different.

#### Procedure

**Step 1** Choose **More > System Maintenance > Clear Data**. A dialog box for clearing data is displayed.

**Figure 6-37** System Maintenance



**Step 2** Enter the password for logging in to the app, and tap **OK**.

----End

### 6.5.3.2.4 Generating the Local Maintenance Script

#### Prerequisites

A USB flash drive has been inserted into the USB port on the SmartLogger.


#### Context

Generating the local maintenance script is used to set SmartLogger commands and save the script file in the USB flash drive. The SmartLogger executes the local script file in the USB flash drive to export SmartLogger logs, export or import all files, upgrade application software, and upgrade BSP.

#### Procedure

**Step 1** Choose **More > System Maintenance > Generate local maint. Script** to access the screen for generating the script.

**Figure 6-38** System Maintenance



**Step 2** Select operations as required and tap **Generate local maint. Script** to save the generated local maintenance script file in the USB flash drive.

----End

## Follow-up Procedure


You can also set SmartLogger commands without logging in to the app. For details, see [8.3.2 SmartLogger Maintenance Script](#).

### 6.5.3.2.5 Offline Configuration

You can import the offline configuration files to the SmartLogger over the app.

**Step 1** Choose **More** > **System Maintenance** > **Offline configuration** to perform offline configuration.

**Figure 6-39** System Maintenance



----End

**NOTE**

After the configuration file is imported, choose **Latest Status** to view the import status of the last offline configuration file and choose **Enable offline config** to import other offline configuration files.


### 6.5.3.2.6 Importing and Exporting All Files

If the SmartLogger needs to be replaced, you can export the files before the replacement and then import the files of the new SmartLogger to ensure data integrity.

#### Procedure

- Step 1** Choose **More > System Maintenance > Import all files (or Export all files)** to import or export all files.

**Figure 6-40** System Maintenance



----End

### 6.5.3.2.7 Restoring Factory Settings

#### Context


#### NOTICE

Perform this operation with caution because all configured parameters except the current date, time, baud rate, and address will be restored to their factory default values. This operation will not affect operating information, alarm records, or system logs.

#### Procedure

- Step 1** Choose **More > System Maintenance > Restore factory settings**. The **Restore factory** dialog box is displayed.

**Figure 6-41** System Maintenance



**Step 2** Enter the password for logging in to the app, and tap **OK**.

----End

### 6.5.3.3 Device Management

You can choose **More > Device Mgmt** to manage all devices connected to the SmartLogger.

#### 6.5.3.3.1 Changing a Device Name

##### Procedure

**Step 1** Choose **More > Device Mgmt.** to access the **Device Mgmt.** screen.

**Step 2** Tap a device name to change it.

**Figure 6-42** Changing a device name



**NOTE**

The name of the SmartLogger cannot be changed.


----End

### 6.5.3.3.2 Deleting Devices

#### Procedure

- Step 1** Choose **More > Device Mgmt.** to access the **Device Mgmt.** screen.
- Step 2** Hold down a device name, select the devices to be deleted, and tap **Batch delete** to delete them.

**Figure 6-43** Deleting devices



**NOTE**

Deleted devices are not displayed on the **Monitor** screen.

----End

### 6.5.3.3 Automatically Searching for Devices

#### Context

The SmartLogger can automatically detect and connect to devices.


The EMI, power meter, slave SmartLogger, and third-party devices cannot be automatically detected. You need to add them manually. For details, see [6.5.3.3.4 Manually Adding a Device](#).

#### Procedure

**Step 1** Choose **More > Device Mgmt.** to access the **Device Mgmt.** screen.



**Figure 6-44** Device management



**Step 2** Tap the drop-down list in the upper-right corner of the **Device Mgmt.** screen.

**Step 3** Automatically searching for devices

----End

### 6.5.3.3.4 Manually Adding a Device


#### Context

The EMI, power meter, slave SmartLogger, and third-party devices cannot be automatically detected. You need to add them manually.

#### Procedure

**Step 1** Choose **More** > **Device Mgmt.** to access the **Device Mgmt.** screen.

**Figure 6-45** Device management



**Step 2** Tap the drop-down list in the upper-right corner of the **Device Mgmt.** screen.

**Step 3** Tap **Add Device** and set device parameters.

#### NOTE

- **Comm. Protocol** is set to **Modbus RTU** by default. If you need to modify it, refer to [6.5.2.5 Setting RS485 Parameters](#).

- Before adding the EMI or power meter manually, set the EMI or power meter parameters. For details, see *SmartLogger3000 User Manual*, *SmartLogger2000 User Manual* or *SmartLogger1000A User Manual*.

----End

### 6.5.3.3.5 Automatically Allocating Addresses


#### Context

The SmartLogger can automatically allocate addresses to the connected devices and adjust the addresses based on device sequence numbers.

#### Procedure

**Step 1** Choose **More > Device Mgmt.** to access the **Device Mgmt.** screen.

**Figure 6-46** Device management



**Step 2** Tap the drop-down list in the upper-right corner of the **Device Mgmt.** screen.

**Step 3** Tap **Auto Assign Address**.

----End

### 6.5.3.3.6 Importing Configuration

#### Prerequisites

The name extension of the file to be imported must be **.cfg**. Otherwise, the file will be unavailable.

- The file to be imported is stored in the memory or SD card of the mobile phone.


#### Context

When connecting to a user-defined device or the IEC103 device, import a configuration file and add a device manually. Then, the device can be queried on the **Monitor** screen.

## Procedure

**Step 1** Choose **More > Device Mgmt.** to access the **Device Mgmt.** screen.

**Figure 6-47** Device management



**Step 2** Tap the drop-down list in the upper-right corner of the **Device Mgmt.** screen.

**Step 3** Tap **Import Config** to import the **.cfg** file.

----End

### 6.5.3.3.7 Exporting Configuration


#### Context

After connecting to a third-party device, you can choose **Export Config** to view its configuration file.

## Procedure

**Step 1** Choose **More > Device Mgmt.** to access the **Device Mgmt.** screen.

**Figure 6-48** Device management



**Step 2** Tap the drop-down list in the upper-right corner of the **Device Mgmt.** screen.

**Step 3** Tap **Export Config**.

----End

### 6.5.3.3.8 Resetting Alarms


#### Context

- If you reset alarms, all the active and historical alarms of the selected device are deleted and the SmartLogger starts to collect new alarm data.
- If data is deleted for a solar inverter, you must reset alarms on the SmartLogger and the NMS; otherwise, the SmartLogger cannot collect new alarm data from the solar inverter.
- If alarms are reset on the SmartLogger, you must reset alarms on the NMS; otherwise, the NMS cannot obtain the new alarm data collected by the SmartLogger from the solar inverter.

#### Procedure

**Step 1** Choose **More** > **Device Mgmt.** to access the **Device Mgmt.** screen.

**Figure 6-49** Device management



**Step 2** Tap the drop-down list in the upper-right corner of the **Device Mgmt.** screen.

**Step 3** Tap **Reset Alarms** and select a device on the **Reset Alarms** screen.

**Step 4** Tap **OK**.

----End

### 6.5.3.3.9 Starting, Shutting down, and Resetting Solar Inverters in Batches


#### Context

Batch control operations allow the SmartLogger to start, shut down, and reset the connected solar inverters in batches. The solar inverters automatically restart after reset.

#### Procedure

**Step 1** Choose **More** > **Device Mgmt.** to access the **Device Mgmt.** screen.

**Figure 6-50** Device management



**Step 2** Tap the drop-down list in the upper-right corner of the **Device Mgmt.** screen.

**Step 3** Tap **Batch Control**.

**Step 4** Tap **Batch startup**, **Batch shutdown**, or **Batch reset**, enter the app login password, and tap **OK**.

----End

### 6.5.3.3.10 Setting Access Parameter


#### Context

Before connecting a device to the SmartLogger, configure access parameters correctly.

#### Procedure

**Step 1** Choose **More > Device Mgmt.** to access the **Device Mgmt.** screen.

**Figure 6-51** Device management



**Step 2** Tap the drop-down list in the upper-right corner of the **Device Mgmt.** screen.

**Step 3** Tap **Access Param.** to access the settings screen.

**NOTE**

If the SmartLogger communicates with the solar inverter over the MBUS, set **Embedded MBUS enable** to **Enable**.

----End

### 6.5.3.4 Managing the Device List


#### Context

On the device list screen, you can choose **Export Device Info** > **Edit Device Info File** > **Import Device Info** to modify device information in the information file.

#### Procedure

**Step 1** Choose **More** > **Device List** to access the device list screen.

**Figure 6-52** Device List



**Step 2** Tap **Export Device Info** to export the device information file.

**NOTE**

The exported device information file is in .csv format.

**Step 3** Tap **Edit Device Info File** to modify the device information file.

1. In the path where the device information file is exported, tap the exported .csv file to access the screen for modifying the file.
2. Tap a parameter to be modified and enter or select target information.
3. After all modifications, tap **Save** in the upper-right corner of the screen.

**Step 4** Tap **Import Device Info** to import the modified device information file to the SmartLogger.

----End


### 6.5.3.5 Exporting Device Logs

#### Prerequisites


A USB flash drive has been inserted into the USB port on the SmartLogger.

#### Procedure

**Step 1** Choose **More** > **Device logs** to access the device log screen.

**Step 2** Tap  in the upper-right corner of the screen, select a device whose logs are to be exported, and tap **Next**.

**Figure 6-53** Exporting device logs



**Step 3** Select the types of logs to be exported and tap **OK** to start exporting device logs.

 **NOTE**

The downloaded device logs are saved at the storage path of the USB flash drive.

----End

## 6.5.3.6 Device Upgrade


### Prerequisites


- Obtain the upgrade package from your supplier or Huawei engineers.
- Insert the USB flash drive where the upgrade package is saved into the USB port on the SmartLogger.

### Procedure

**Step 1** Choose **More** > **Upgrade** to access the device upgrade screen.

**Figure 6-54** Device upgrade



- Step 2** Tap  in the upper-right corner, select a single device or devices of the same type, and tap **Next**.
- Step 3** Select the upgrade package and tap **Next**.
- Step 4** Confirm the upgrade package and the device to be upgraded, and tap **Finish** to start upgrading the device.
- End

### 6.5.3.7 Spot-Checking Solar Inverters


#### Context


You can perform spot-check for the solar inverter whose **Grid Code** is **Japan standard**.

#### Procedure

- Step 1** Choose **More > Inverter Spot** to access the solar inverter spot-check screen.

**Figure 6-55** Inverter spot




- Step 2** (Optional) Tap  in the upper-right corner of the **Inverter Spot** screen, select **Sel Ana Para**, and tap **Finish** to set analog parameters.



 **NOTE**

After the parameters on the **Sel Analog Para** screen are set, the analog parameters and their values are displayed on the solar inverter spot-check screen. You can also tap **Sel Device** to set parameters when the solar inverters are being spot-checked.

**Step 3** Tap  in the upper-right corner of the **Inverter Spot** screen and select **Sel Device** to access the **Sel Device** screen.

**Step 4** Select one or more devices to be spot-checked, and then tap **Finish** to start spot-check.

----End

## 6.5.3.8 Feedback


### Context

Users can provide feedback in text, pictures, and files.


 **NOTE**

Do not add private data.

### Procedure

**Step 1** Choose  > **Feedback** in the upper-right corner of the home screen.

**Figure 6-56** Feedback




**Step 2** Tap **Specify the type** and select **Feedback** or **Suggestion**.

**Figure 6-57** Problem record

The screenshot shows a mobile application interface for reporting a problem. The title bar is dark blue with a white back arrow and the text 'Problem record'. Below the title bar, there are three main sections: 1. '\*Specify the type' with a right-pointing arrow. 2. '\*Description (0/200 words)' with a text input field containing the placeholder 'Briefly describe the problem.'. 3. 'Upload image (0/20)' with a plus sign icon. Below these is 'Upload log (0B/20MB)' with a trash icon and a plus sign icon. At the bottom is a blue 'Submit' button.

**Step 3** Briefly describe the problem that you encounter in the **Description** column.

**Step 4** (Optional) Tap  to upload pictures.

**Step 5** (Optional) Tap  to upload logs. Select device logs or app logs as required.

**Step 6** Tap **Submit**.


----End

## 6.5.3.9 Help

### Context

If you have any questions when using an involved device or the app, search for solutions in the help information.

### Procedure


**Step 1** Choose  > **Help** in the upper-right corner of the home screen.

**Figure 6-58** Help 1



**Step 2** Specify your question. A solution will be displayed.

**Figure 6-59** Help 2



----End

### 6.5.3.10 About


#### Context

You can query the app version, connected product model, SN, firmware version, software version, technical support website, privacy policy (displayed only on the SUN2000 app), customer service contact information, and open source software policy.

#### NOTE

- When the app starts for the first time after being downloaded or updated, the privacy policy is displayed. You can use the app only after agreeing to the privacy policy, and the privacy policy will no longer appear. If you do not agree to the privacy policy, the app exits, and the privacy policy is still displayed when you start the app next time until you agree to the privacy policy.
- You can revoke the agreed privacy policy.

#### Procedure

**Step 1** In the upper-right corner of the home screen, choose  > **About** to view the app version, connected product model, SN, firmware version, software version, and technical support website.

**Figure 6-60** About



**Step 2** Tap **Privacy policy**, **Customer service contact information**, or **Open source software policy** to view the privacy policy, customer service contact information, and open source software policy.

----End


## 6.5.4 Device Monitoring

An advanced user can tap **Monitor** to query the running information and alarms about the SmartLogger and the devices connected to it, set parameters, and send commands.

### 6.5.4.1 Query

**Step 1** On the home screen, tap **Monitor** to access the device monitoring screen.

**Figure 6-61** Device monitoring



**Step 2** Select a target device to access the function menu screen of the device.

**Step 3** Tap **Alarm**, **Running Info.**, **Energy Yield**, or **About** to view the alarms, running information, energy yield, and version information about the device.

#### NOTE

- The displayed information varies according to the device type.
- The SmartLogger can connect to third-party devices that support the Modbus-RTU protocol, such as the box-type transformer and EMI. The SmartLogger cannot automatically search user-defined devices. You need to manually add them.
- The SmartLogger can connect to a maximum of five types of user-defined devices and can connect to multiple devices of the same type.
- The SmartLogger can connect to a third-party device that supports IEC103, such as a relay protection or monitoring device like a box-type transformer. The SmartLogger cannot automatically search IEC103 devices. You need to manually add them.

- The SmartLogger can connect to a maximum of five types of IEC103 devices and can connect to multiple devices of the same type.

----End

## 6.5.4.2 Settings

### Context

An advanced user can set solar inverter parameters, MBUS parameters, PID Module parameters and DL/T645 parameters.

### Procedure

- Step 1** On the **Monitor** screen, select the target device to access the function menu screen of the solar inverter.
- Step 2** Tap **Settings** to access the settings screen.
- Step 3** Set parameters as required.

#### NOTE

For Setting MBUS Parameters, set **Anti-crosstalk** to **Enable** to make devices in the anti-crosstalk list take effect.

----End

## 6.5.4.3 Maintenance

### 6.5.4.3.1 Log Download

### Context

An advanced user can download only the logs of the SmartLogger, solar inverter, MBUS, and PID module.

### Procedure

- Step 1** Select a device on the **Monitor** screen to access the function menu screen of the device.
- Step 2** Tap **Device Logs** to access the log download screen.
- Step 3** Download log files as required.

#### NOTE

- By default, Android system logs are saved in the **storage/emulated/0/inverterapp** folder in the phone memory. You can change the save path by referring to "Setting a File Save Path".
- The downloaded solar inverter logs are saved at the **Device Log** directory in **File Manager** in your mobile phone. You can also send the logs to your mailbox for checking.

----End

### 6.5.4.3.2 Solar Inverter Maintenance

#### Procedure

**Step 1** Tap **SUN2000** on the **Monitor** screen and select the target device to access the function menu screen of the solar inverter.

**Step 2** Tap **Maintenance** to access the maintenance screen.

**Step 3** Tap  next to **Power on, Power off, AFCI self-check, or Reset**.

#### NOTE

- AFCI self-check is available only for the solar inverter model marked with **-US**.
- Tap **License Management** or **Performance Data** to view the certificate information and performance data curve of the solar inverter.

**Step 4** Enter the password for logging in to the app, and tap **OK**.


----End

### 6.5.4.3.3 MBUS Maintenance

#### Procedure

**Step 1** Tap **MBUS** on the **Monitor** screen and select the target device to access the function menu screen of the MBUS.

**Step 2** Tap **Maintenance** to access the maintenance screen.

**Step 3** Tap  next to **Search STA Again** and search for the STA list again as prompted.

**Step 4** Tap  next to **MBUS reset** and reset the MBUS as prompted.

**Step 5** Tap **Anti-crosstalk list** to synchronize, import, or export the list.

----End

### 6.5.4.3.4 PID Module Maintenance

#### Procedure

**Step 1** Tap **PID** on the **Monitor** screen and select the target device to access the function menu screen of the PID module.

**Step 2** Tap **Maintenance** to access the maintenance screen.

**Step 3** Tap  next to **Power on, Power off, or Data clear** as required.

#### NOTE

- If you clear data, active and historical alarms stored on the PID module will all be cleared.
- Tap **Performance Data** to view the performance data curve of the PID module.

**Step 4** Enter the password for logging in to the app, and tap **OK**.

----End


## 6.6 Screen Operations (Special User)

### 6.6.1 Query

#### Procedure

- Step 1** After logging in to the app, you can view the running details of the connected solar inverters on the home screen.

**Figure 6-62** Home screen



**Table 6-4** Home screen

Parameter	Description
Total Inverter Qty	Number of solar inverters connected to the SmartLogger.
Rated power	Total rated power of solar inverters connected to the SmartLogger.
Output power	Total output power of solar inverters connected to the SmartLogger.

Parameter	Description
E-Total	Total energy yields of solar inverters connected to the SmartLogger.
E-Daily	Total energy yields of solar inverters connected to the SmartLogger on the current day.
CO <sub>2</sub> reduction	Total amount of reduced CO <sub>2</sub> emission of the solar inverters connected to the SmartLogger
Income	Total revenues corresponding to energy yields of solar inverters connected to the SmartLogger.
Grid scheduling	Active power percentage and reactive power factor for power grid scheduling.
Alarm	Current alarms: You can view the detailed information about major, minor, and warning alarms. Historical alarms: You can view details about historical alarms filtered by sequence number, device, and time.
Yield	You can query information about energy yields of all solar inverters connected to the SmartLogger. Tap <b>Day</b> , <b>Month</b> , <b>Year</b> , or <b>History</b> to display the daily, monthly, yearly, or historical energy yield information.

----End

## 6.6.2 Settings

### 6.6.2.1 Setting RS485 Parameters


#### Context

Set RS485 parameters to ensure normal communication between the SmartLogger and devices such as the SUN2000, EMI, and power meter.

#### Procedure

- Step 1** Choose **More** > **Settings** > **RS485** to access the parameter setting screen.
- Step 2** Select a port from **COM1** to **COM6**.  
Use the settings of **COM1** as an example.



**Figure 6-63** COM1

COM1	
Baud rate(bps)	9600
Parity	None
Start address	1
End address	100
Protocol	Modbus
Stop Bit	NA

**NOTE**

- **COM1** to **COM6** correspond to communications ports **COM1–COM3** (SmartLogger1000A and SmartLogger3000) or **COM1–COM6** (SmartLogger2000). The default baud rate is 9600 bit/s.
- Set the protocol supported by the RS485 port based on either the protocol supported by the connected device or the status of the device in the network. When the SmartLogger serves as a slave node to interconnect with a third-party device over Modbus-RTU, set **Protocol** to **Modbus-Slave**. When the connected solar inverter performs rapid power grid scheduling using both MBUS and RS485, set **Protocol** to **Modbus-Control**.
- **Parity**, **Protocol**, and **Stop bit** must be set to the same values for all devices connected to the same RS485 port.
- The baud rate for the RS485 ports of the SmartLogger must be the same as the baud rate for the device that communicates with the SmartLogger.
- $1 \leq \text{Start address} \leq \text{End address} \leq 247$ . The address range of the ports can overlap. Set the address range as required. A larger address range requires a longer searching time. The start and end addresses have no impact on the devices that have been connected.

**Step 3** On the **RS485** screen, tap **Night Communication Settings** to set the parameters for communication at night.

----End

## 6.6.2.2 Active Power Control

### Procedure

**Step 1** Choose **More > Settings > Active Power Control** to access the **Active Power Control** screen.

**Step 2** Tap **Active power control mode** to set the active power control mode.

**Figure 6-64** Active power control




----End

### 6.6.2.3 Setting Modbus-RTU Power Meter Parameters

#### Procedure

**Step 1** Choose **More > Settings > Power Meter** to access the parameter setting screen.

**Figure 6-65** Power Meter



**Step 2** Tap target parameters. On the displayed screen, enter relevant information.


----End

### 6.6.2.4 Remotely Shutting Down Solar Inverters in Dry Contact Mode

#### Procedure

**Step 1** Choose **More > Settings > Dry contact remote shutdown**. On the displayed screen, set parameters to remotely shut down solar inverters in dry contact mode.

**Figure 6-66** Remotely shutting down solar inverters in dry contact mode



----End

## 6.6.2.5 Setting Reactive Power Control

### Procedure

- Step 1** On the home screen, tap **More > Settings > Reactive pwr control** to access the parameter setting screen.
- Step 2** Tap **Edit** to edit characteristic curve points to control the reactive power output.

----End

## 6.6.3 Maintenance


### 6.6.3.1 Solar Inverter Inspection

#### Context


After a solar inverter is put into use, it should be inspected periodically to detect any potential risks and problems.

#### Procedure


- Step 1** Tap **More > Inverter Inspect** to access the inspection screen.



- Step 2** Select **Single inspect** or **Batch inspect**.



**Step 3** Select **Inspection type** and tap **Next** in the upper-right corner of the screen to start inspection.



**Step 4** An inspection file is generated after the inspection is complete.

**NOTE**

By default, the inspection file is saved in **storage/emulated/0/inverterapp** in the phone memory. You can change the log save path by referring to *Setting a File Save Path*.

----End

## 6.6.3.2 System Maintenance


You can choose **More > System Maintenance** to change the SmartLogger password and reset the system.

### 6.6.3.2.1 Changing a User Password

#### Procedure

**Step 1** Choose **More > System Maintenance > Change Password** to access the password change screen.

**Figure 6-67** Change Password



**NOTE**

The password must meet the following requirements:

- Contains 6–20 characters.
- Contains at least two of the following types: lowercase letters, uppercase letters, and digits.

----End


### 6.6.3.2.2 Resetting the System

#### Context

After the system resets, the SmartLogger restarts.

#### Procedure

- Step 1** Choose **More > System Maintenance > Reset**. A dialog box for resetting the system is displayed.

**Figure 6-68** Reset

**Step 2** Enter the password for logging in to the app, and tap **OK**.

----End

### 6.6.3.2.3 Clearing Data

#### Context


Clear data if the SmartLogger is relocated and its historical data needs to be deleted.

#### NOTICE

- After you perform **Clear Data**, electric energy yield data, performance data, and alarms are cleared from the SmartLogger.
- After you perform **Clear Data**, the devices connected to the SmartLogger are not removed. If the original device will no longer connect to the SmartLogger, remove the device.
- If you perform **Clear Data** on the SmartLogger, you also have to perform **Reset Alarms** on the NMS. Otherwise, the alarm information collected by the NMS and SmartLogger will be different.

#### Procedure

**Step 1** Choose **More > System Maintenance > Clear Data**. A dialog box for clearing data is displayed.

**Figure 6-69** System Maintenance

**Step 2** Enter the password for logging in to the app, and tap **OK**.

----End

### 6.6.3.2.4 Generating the Local Maintenance Script

#### Prerequisites

A USB flash drive has been inserted into the USB port on the SmartLogger.


#### Context

Generating the local maintenance script is used to set SmartLogger commands and save the script file in the USB flash drive. The SmartLogger executes the local script file in the USB flash drive to export SmartLogger logs, export or import all files, upgrade application software, and upgrade BSP.

#### Procedure

**Step 1** Choose **More > System Maintenance > Generate local maint. Script** to access the screen for generating the script.

**Figure 6-70** System Maintenance



**Step 2** Select operations as required and tap **Generate local maint. Script** to save the generated local maintenance script file in the USB flash drive.

----End

## Follow-up Procedure

You can also set SmartLogger commands without logging in to the app. For details, see [8.3.2 SmartLogger Maintenance Script](#).

### 6.6.3.2.5 Restoring Factory Settings

#### Context

---

#### NOTICE

Perform this operation with caution because all configured parameters except the current date, time, baud rate, and address will be restored to their factory default values. This operation will not affect operating information, alarm records, or system logs.


---

#### Procedure

**Step 1** Choose **More > System Maintenance > Restore factory settings**. The **Restore factory** dialog box is displayed.



**Figure 6-71** System Maintenance



**Step 2** Enter the password for logging in to the app, and tap **OK**.

----End

### 6.6.3.3 Device Management

You can choose **More > Device Mgmt** to manage all devices connected to the SmartLogger.

#### 6.6.3.3.1 Changing a Device Name

##### Procedure

**Step 1** Choose **More > Device Mgmt.** to access the **Device Mgmt.** screen.

**Step 2** Tap a device name to change it.

**Figure 6-72** Changing a device name



**NOTE**

The name of the SmartLogger cannot be changed.


----End

### 6.6.3.3.2 Deleting Devices

#### Procedure

- Step 1** Choose **More > Device Mgmt.** to access the **Device Mgmt.** screen.
- Step 2** Hold down a device name, select the devices to be deleted, and tap **Batch delete** to delete them.

**Figure 6-73** Deleting devices



**NOTE**

Deleted devices are not displayed on the **Monitor** screen.

----End

### 6.6.3.3.3 Automatically Searching for Devices

#### Context


The SmartLogger can automatically detect and connect to devices.

The EMI, power meter, slave SmartLogger, and third-party devices cannot be automatically detected. You need to add them manually. For details, see [6.5.3.3.4 Manually Adding a Device](#).

#### Procedure

**Step 1** Choose **More > Device Mgmt.** to access the **Device Mgmt.** screen.

**Figure 6-74** Device management



**Step 2** Tap the drop-down list in the upper-right corner of the **Device Mgmt.** screen.

**Step 3** Automatically searching for devices

----End

### 6.6.3.3.4 Manually Adding a Device


#### Context

The EMI, power meter, slave SmartLogger, and third-party devices cannot be automatically detected. You need to add them manually.

#### Procedure

**Step 1** Choose **More** > **Device Mgmt.** to access the **Device Mgmt.** screen.

**Figure 6-75** Device management



**Step 2** Tap the drop-down list in the upper-right corner of the **Device Mgmt.** screen.

**Step 3** Tap **Add Device** and set device parameters.

#### NOTE

- **Comm. Protocol** is set to **Modbus RTU** by default. If you need to modify it, refer to [6.5.2.5 Setting RS485 Parameters](#).

- Before adding the EMI or power meter manually, set the EMI or power meter parameters. For details, see *SmartLogger3000 User Manual*, *SmartLogger2000 User Manual* or *SmartLogger1000A User Manual*.

----End

### 6.6.3.3.5 Automatically Allocating Addresses


#### Context

The SmartLogger can automatically allocate addresses to the connected devices and adjust the addresses based on device sequence numbers.

#### Procedure

**Step 1** Choose **More > Device Mgmt.** to access the **Device Mgmt.** screen.

**Figure 6-76** Device management



**Step 2** Tap the drop-down list in the upper-right corner of the **Device Mgmt.** screen.

**Step 3** Tap **Auto Assign Address**.

----End

### 6.6.3.3.6 Importing Configuration

#### Prerequisites

The name extension of the file to be imported must be **.cfg**. Otherwise, the file will be unavailable.

- The file to be imported is stored in the memory or SD card of the mobile phone.


#### Context

When connecting to a user-defined device or the IEC103 device, import a configuration file and add a device manually. Then, the device can be queried on the **Monitor** screen.

## Procedure

**Step 1** Choose **More > Device Mgmt.** to access the **Device Mgmt.** screen.

**Figure 6-77** Device management



**Step 2** Tap the drop-down list in the upper-right corner of the **Device Mgmt.** screen.

**Step 3** Tap **Import Config** to import the **.cfg** file.

----End

### 6.6.3.3.7 Exporting Configuration


#### Context

After connecting to a third-party device, you can choose **Export Config** to view its configuration file.

## Procedure

**Step 1** Choose **More > Device Mgmt.** to access the **Device Mgmt.** screen.

**Figure 6-78** Device management



**Step 2** Tap the drop-down list in the upper-right corner of the **Device Mgmt.** screen.

**Step 3** Tap **Export Config**.

----End

### 6.6.3.3.8 Resetting Alarms


#### Context

- If you reset alarms, all the active and historical alarms of the selected device are deleted and the SmartLogger starts to collect new alarm data.
- If data is deleted for a solar inverter, you must reset alarms on the SmartLogger and the NMS; otherwise, the SmartLogger cannot collect new alarm data from the solar inverter.
- If alarms are reset on the SmartLogger, you must reset alarms on the NMS; otherwise, the NMS cannot obtain the new alarm data collected by the SmartLogger from the solar inverter.

#### Procedure

**Step 1** Choose **More** > **Device Mgmt.** to access the **Device Mgmt.** screen.

**Figure 6-79** Device management



**Step 2** Tap the drop-down list in the upper-right corner of the **Device Mgmt.** screen.

**Step 3** Tap **Reset Alarms** and select a device on the **Reset Alarms** screen.

**Step 4** Tap **OK**.

----End

### 6.6.3.3.9 Starting, Shutting down, and Resetting Solar Inverters in Batches


#### Context

Batch control operations allow the SmartLogger to start, shut down, and reset the connected solar inverters in batches. The solar inverters automatically restart after reset.

#### Procedure

**Step 1** Choose **More** > **Device Mgmt.** to access the **Device Mgmt.** screen.

**Figure 6-80** Device management



**Step 2** Tap the drop-down list in the upper-right corner of the **Device Mgmt.** screen.

**Step 3** Tap **Batch Control**.

**Step 4** Tap **Batch startup**, **Batch shutdown**, or **Batch reset**, enter the app login password, and tap **OK**.

----End

### 6.6.3.3.10 Setting Access Parameter


#### Context

Before connecting a device to the SmartLogger, configure access parameters correctly.

#### Procedure

**Step 1** Choose **More > Device Mgmt.** to access the **Device Mgmt.** screen.

**Figure 6-81** Device management



**Step 2** Tap the drop-down list in the upper-right corner of the **Device Mgmt.** screen.

**Step 3** Tap **Access Param.** to access the settings screen.



 **NOTE**

If the SmartLogger communicates with the solar inverter over the MBUS, set **Embedded MBUS enable** to **Enable**.

----End

## 6.6.3.4 Managing the Device List


### Context

On the device list screen, you can choose **Export Device Info** > **Edit Device Info File** > **Import Device Info** to modify device information in the information file.

### Procedure

**Step 1** Choose **More** > **Device List** to access the device list screen.

**Figure 6-82** Device List



**Step 2** Tap **Export Device Info** to export the device information file.

 **NOTE**

The exported device information file is in .csv format.

**Step 3** Tap **Edit Device Info File** to modify the device information file.

1. In the path where the device information file is exported, tap the exported .csv file to access the screen for modifying the file.
2. Tap a parameter to be modified and enter or select target information.
3. After all modifications, tap **Save** in the upper-right corner of the screen.

**Step 4** Tap **Import Device Info** to import the modified device information file to the SmartLogger.

----End


## 6.6.3.5 Exporting Device Logs

### Prerequisites


A USB flash drive has been inserted into the USB port on the SmartLogger.

### Procedure

**Step 1** Choose **More** > **Device logs** to access the device log screen.

**Step 2** Tap  in the upper-right corner of the screen, select a device whose logs are to be exported, and tap **Next**.

**Figure 6-83** Exporting device logs



**Step 3** Select the types of logs to be exported and tap **OK** to start exporting device logs.

 **NOTE**

The downloaded device logs are saved at the storage path of the USB flash drive.

----End

## 6.6.3.6 Device Upgrade


### Prerequisites


- Obtain the upgrade package from your supplier or Huawei engineers.
- Insert the USB flash drive where the upgrade package is saved into the USB port on the SmartLogger.

### Procedure

**Step 1** Choose **More** > **Upgrade** to access the device upgrade screen.

**Figure 6-84** Device upgrade



**Step 2** Tap  in the upper-right corner, select a single device or devices of the same type, and tap **Next**.

**Step 3** Select the upgrade package and tap **Next**.

**Step 4** Confirm the upgrade package and the device to be upgraded, and tap **Finish** to start upgrading the device.

----End

### 6.6.3.7 Spot-Checking Solar Inverters


#### Context


You can perform spot-check for the solar inverter whose **Grid Code** is **Japan standard**.

#### Procedure

**Step 1** Choose **More > Inverter Spot** to access the solar inverter spot-check screen.


**Figure 6-85** Inverter spot



**Step 2** (Optional) Tap  in the upper-right corner of the **Inverter Spot** screen, select **Sel Ana Para**, and tap **Finish** to set analog parameters.

 **NOTE**

After the parameters on the **Sel Analog Para** screen are set, the analog parameters and their values are displayed on the solar inverter spot-check screen. You can also tap **Sel Device** to set parameters when the solar inverters are being spot-checked.

**Step 3** Tap  in the upper-right corner of the **Inverter Spot** screen and select **Sel Device** to access the **Sel Device** screen.

**Step 4** Select one or more devices to be spot-checked, and then tap **Finish** to start spot-check.

----End

## 6.6.3.8 Feedback


### Context

Users can provide feedback in text, pictures, and files.


 **NOTE**

Do not add private data.

### Procedure

**Step 1** Choose  > **Feedback** in the upper-right corner of the home screen.

**Figure 6-86** Feedback



**Step 2** Tap **Specify the type** and select **Feedback** or **Suggestion**.

**Figure 6-87** Problem record

The screenshot shows a mobile application interface for recording a problem. It features a dark blue header with a back arrow and the text 'Problem record'. Below the header, there are three main sections: 1. A field labeled '\*Specify the type' with a right-pointing arrow. 2. A field labeled '\*Description (0/200 words)' with a text area containing the placeholder 'Briefly describe the problem.'. 3. A field labeled 'Upload image (0/20)' with a plus sign icon. Below these is the 'Upload log (0B/20MB)' section with a trash icon and a plus icon. At the bottom is a blue 'Submit' button.

**Step 3** Briefly describe the problem that you encounter in the **Description** column.

**Step 4** (Optional) Tap  to upload pictures.

**Step 5** (Optional) Tap  to upload logs. Select device logs or app logs as required.

**Step 6** Tap **Submit**.


----End

## 6.6.3.9 Help


### Context

If you have any questions when using an involved device or the app, search for solutions in the help information.

### Procedure


**Step 1** Choose  > **Help** in the upper-right corner of the home screen.

**Figure 6-88** Help 1



**Step 2** Specify your question. A solution will be displayed.

**Figure 6-89** Help 2



----End

### 6.6.3.10 About


#### Context

You can query the app version, connected product model, SN, firmware version, software version, technical support website, privacy policy (displayed only on the SUN2000 app), customer service contact information, and open source software policy.


#### NOTE

- When the app starts for the first time after being downloaded or updated, the privacy policy is displayed. You can use the app only after agreeing to the privacy policy, and the privacy policy will no longer appear. If you do not agree to the privacy policy, the app exits, and the privacy policy is still displayed when you start the app next time until you agree to the privacy policy.
- You can revoke the agreed privacy policy.

#### Procedure

**Step 1** In the upper-right corner of the home screen, choose  > **About** to view the app version, connected product model, SN, firmware version, software version, and technical support website.

**Figure 6-90** About



**Step 2** Tap **Privacy policy**, **Customer service contact information**, or **Open source software policy** to view the privacy policy, customer service contact information, and open source software policy.

----End


## 6.6.4 Device Monitoring

A special user can tap **Monitor** to query the running information and alarms about the SmartLogger and the devices connected to it, set parameters, and send commands.

### 6.6.4.1 Query

**Step 1** On the home screen, tap **Monitor** to access the device monitoring screen.

**Figure 6-91** Device monitoring



**Step 2** Select a target device to access the function menu screen of the device.

**Step 3** Tap **Alarm**, **Running Info.**, **Energy Yield**, or **About** to view the alarms, running information, energy yield, and version information about the device.

#### NOTE

- The displayed information varies according to the device type.
- The SmartLogger can connect to third-party devices that support the Modbus-RTU protocol, such as the box-type transformer and EMI. The SmartLogger cannot automatically search user-defined devices. You need to manually add them.
- The SmartLogger can connect to a maximum of five types of user-defined devices and can connect to multiple devices of the same type.
- The SmartLogger can connect to a third-party device that supports IEC103, such as a relay protection or monitoring device like a box-type transformer. The SmartLogger cannot automatically search IEC103 devices. You need to manually add them.

- The SmartLogger can connect to a maximum of five types of IEC103 devices and can connect to multiple devices of the same type.

----End

## 6.6.4.2 Settings

### Context

An advanced user can set only the running parameters of solar inverters.

### Procedure

- Step 1** Tap **SUN2000** on the **Monitor** screen and select the target device to access the function menu screen of the solar inverter.
- Step 2** Tap **Settings** to access the settings screen.
- Step 3** Set parameters as required.
- Step 4** (Optional) Select parameters as required and tap **Batch set** to set running parameters for multiple solar inverters of the same series.

----End

## 6.6.4.3 Maintenance

### 6.6.4.3.1 Log Download

### Context

An advanced user can download only the logs of the SmartLogger, solar inverter, MBUS, and PID module.

### Procedure

- Step 1** Select a device on the **Monitor** screen to access the function menu screen of the device.
- Step 2** Tap **Device Logs** to access the log download screen.
- Step 3** Download log files as required.

#### NOTE

- By default, Android system logs are saved in the **storage/emulated/0/inverterapp** folder in the phone memory. You can change the save path by referring to "Setting a File Save Path".
- The downloaded solar inverter logs are saved at the **Device Log** directory in **File Manager** in your mobile phone. You can also send the logs to your mailbox for checking.

----End




### 6.6.4.3.2 Solar Inverter Maintenance

#### Procedure

**Step 1** Tap **SUN2000** on the **Monitor** screen and select the target device to access the function menu screen of the solar inverter.

**Step 2** Tap **Maintenance** to access the maintenance screen.

**Step 3** Tap  next to **Power on** or **Power off** to perform the operation.

 **NOTE**

Tap **Performance Data** to view the performance data curve of the solar inverter.

**Step 4** Enter the password for logging in to the app, and tap **OK**.

----End

# 7 Operations on the Screen for Connecting to the PID Module

## NOTICE

The app screenshots provided in this chapter correspond to the SUN2000 app 3.2.00.003 version. The data on the screenshots is for reference only.

## 7.1 PID Module

### Connection Modes

After the SmartPID2000 (PID module for short) is powered on, it can connect to the app over a WLAN module, a Bluetooth module, or a USB data cable.

**Table 7-1** Product mapping (Android)

PID Module	PID Module Version	App Version	Connection Mode	
			USB-Adapter2000-C WLAN Module/USB-Adapter2000-B Bluetooth Module	USB Data Cable
SmartPID2000	SmartPID2000 V100R001C00 and later versions	3.2.00.003	Supported	

**Table 7-2** Product mapping (iOS)

PID Module	PID Module Version	App Version	Connection Mode	
			USB-Adapter2000-B Bluetooth Module	USB Data Cable
SmartPID2000	SmartPID2000 V100R001C00 and later versions	2.2.00.050	Supported	Not supported

## 7.2 Required Accessories

### Mobile Phone

- Mobile phone operating system: Android 4.4 or later.
- Recommended phone brands: Huawei and Samsung.
- The mobile phone supports the access to the Internet over a web browser.
- WLAN/Bluetooth supported.

### WLAN/Bluetooth Module

Purchase a WLAN/Bluetooth module that matches the PID module. A WLAN/Bluetooth module purchased from any other source may not support communication between the app module and the PID module.

**Table 7-3** WLAN/Bluetooth module model

Model	Module	Item Code	Purchased From
USB-Adapter2000-C	WLAN module	02312MCK	Can be purchased from Huawei
USB-Adapter2000-B	Bluetooth module	02311NEA	
BF4030	Bluetooth module	06080358	

### USB Data Cable

The USB data cable is delivered with the phone.


## 7.3 User Operation Permissions

The user accounts that can log in to the app are classified into common users, special users, and advanced users based on the responsibilities of PV plant operation personnel.


- Common user: Has the permissions of viewing PID module data and setting user parameters.
- Advanced users: Has the permissions of viewing PID module data, setting functional parameters, and maintaining devices.
- Special user: Has the permissions of viewing PID module data, setting user parameters, and maintaining devices (including starting and shutting down the PID module, clearing data, and upgrading devices).

Figure 7-1, Figure 7-2 and Figure 7-3 show the menu operation permissions of common users, advanced users, and special users respectively.

**Figure 7-1** Operation permissions of common users




**Figure 7-2** Operation permissions of advanced users



**NOTE**

**File save path** is available only for Android system.

**Figure 7-3** Operation permissions of special users



**NOTE**

**File save path** is available only for Android system.

## 7.4 Login


### Prerequisites

- The PID module has been powered on.
- Connect over a Bluetooth module:
  - a. A WLAN/Bluetooth module is available and has been inserted into the USB port in the PID module maintenance compartment.
  - b. The WLAN/Bluetooth function is enabled on the mobile phone.
  - c. Keep the mobile phone within 5 m away from the PID module. Otherwise, communication between them would be affected.
- Connect over a USB data cable:
  - a. A USB data cable is available. One end of the USB data cable is connected to the USB port in the PID module maintenance compartment and the other end is connected to the USB port on the mobile phone.
  - b. After connecting the USB data cable, **Connected to USB Accessory** is displayed on the mobile phone, indicating that the PID module and the mobile phone have been successfully connected. Otherwise, the USB data cable connection is invalid.

## Procedure


- Step 1** Start the app. Tap **Connect** to access the code scanning screen and connect to the PID module.

**Figure 7-4** Connect



- **Code scanning:** On the scanning screen, place the QR code or bar code of the WLAN/Bluetooth module in the scan frame. The device will be automatically connected after the code is identified.

**Figure 7-5** Scan



- Manual connection: On the scanning screen, tap **Manual Connection** and select a connection mode.

**Figure 7-6** Manual connection



- Select **WLAN** and connect to the corresponding WLAN in the WLAN connection list of the APP. The initial name of the WLAN hotspot is **Adapter-WLAN module SN**, and the initial password is **Changeme**.

---

**NOTICE**

Use the initial password upon first power-on and change it immediately after login. To ensure account security, change the password periodically and keep the new password in mind. Not changing the initial password may cause password disclosure. A password left unchanged for a long period of time may be stolen or cracked. If a password is lost, devices cannot be accessed. In these cases, the user is liable for any loss caused to the PV plant.

- Select **Bluetooth**, and tap **Search for device**. After a Bluetooth device is found, select the target Bluetooth device, and set up a connection. If the Bluetooth module is USB-Adapter2000-B, the connected Bluetooth device is named after last 8 digits of the SN barcode + HWAPP. The SN barcode can be obtained from the silk screen on the Bluetooth module.
- Select **USB**, and tap **OK** to allow the app to access the USB accessory. After you select **Use by default for this USB accessory**, the message will not appear if you log in to the app again without removing the USB data cable.

**Step 2** Select a login user and enter the password.

**NOTE**

- The login password is the same as that for the PID module connected to the app and is used only when the PID module connects to the app.
- The initial passwords for **Common User**, **Advanced User**, and **Special User** are all **00000a**. If you log in to the system for the first time, use the initial password and change the password as soon as possible. After the password is used for a period of time, change it periodically to ensure account security.
- During the login, if five consecutive invalid password entries are made (the interval between two consecutive entries is less than 2 minutes), the account will be locked for 10 minutes. The password should consist of six characters.

**Step 3** After successful login, the **Quick Settings** screen or **Function Menu** screen is displayed.

**NOTE**

- If you log in to the app after the PID module powers on for the first time or factory defaults are restored, the **Quick Settings** screen will be displayed. You can set basic parameters for the PID module on the **Quick Settings** screen. After the settings take effect, you can access the **Function Menu** screen and modify the parameters on the **Settings** screen.
- If you do not set basic parameters for the PID module on the **Quick Settings** screen, the screen is still displayed when you log in to the app next time.

----**End**




## 7.5 Screen Operations (Common User)

### 7.5.1 Query

#### Procedure

- Step 1** After logging in to the app, you can view the PID module working mode and compensation mode on the home screen.

**Figure 7-7** Home screen





- Step 2** Tap **Alarms** or **Running Info.** to view active alarms, historical alarms, and PID module running information.

You can view the following information on the alarm information screen:

- Tap an alarm record and view the alarm details.
- Swipe right or left on the screen or tap either **Active Alarm** or **Historical Alarm** to display a list of active alarms or historical alarms.

#### NOTE

- Tap  to set the alarm sorting mode for active alarms or historical alarms.

- Tap  to set a time criterion. The historical alarms generated within the time segment are displayed.

----End

## 7.5.2 Settings


### Prerequisite

Common users can set user parameters only for the PID module.

### Procedure

**Step 1** On the home screen, choose **Settings > User Parameters** and set user parameters.

**Figure 7-8** User parameters



#### NOTE

The password must meet the following requirements:

- Contains six characters.
- Contains at least two of the three types: lowercase letters, uppercase letters, and digits.

----End

## 7.5.3 Maintenance

### 7.5.3.1 Feedback


#### Context

Users can provide feedback in text, pictures, and files.


#### NOTE

Do not add private data.

### Procedure


**Step 1** Choose  > **Feedback** in the upper-right corner of the home screen.

**Figure 7-9** Feedback




**Step 2** Tap **Specify the type** and select **Feedback** or **Suggestion**.

**Figure 7-10** Problem record



**Step 3** Briefly describe the problem that you encounter in the **Description** column.

**Step 4** (Optional) Tap  to upload pictures or logs.

**Step 5** (Optional) Tap  to upload logs. Select device logs or app logs as required.

**Step 6** Tap **Submit**.


----End

## 7.5.3.2 Help


### Context

If you have any questions when using an involved device or the app, search for solutions in the help information.

## Procedure


**Step 1** Choose  > **Help** in the upper-right corner of the home screen.

**Figure 7-11** Help



**Step 2** Specify your question. A solution will be displayed.

**Figure 7-12** Help 2



----End

### 7.5.3.3 About


#### Context

You can query the app version, connected product model, SN, firmware version, software version, technical support website, privacy policy (displayed only on the SUN2000 app), customer service contact information, and open source software policy.


#### NOTE

- When the app starts for the first time after being downloaded or updated, the privacy policy is displayed. You can use the app only after agreeing to the privacy policy, and the privacy policy will no longer appear. If you do not agree to the privacy policy, the app exits, and the privacy policy is still displayed when you start the app next time until you agree to the privacy policy.
- You can revoke the agreed privacy policy.

## Procedure

**Step 1** In the upper-right corner of the home screen, choose  > **About** to view the app version, connected product model, SN, firmware version, software version, and technical support website.

**Figure 7-13** About



**Step 2** Tap **Privacy policy**, **Customer service contact information**, or **Open source software policy** to view the privacy policy, customer service contact information, and open source software policy.

----End


## 7.6 Screen Operations (Advanced User)

### 7.6.1 Query

#### Procedure

**Step 1** After logging in to the app, you can view the PID module working mode and compensation mode on the home screen.

**Figure 7-14** Home screen





**Step 2** Tap **Alarms** or **Running Info.** to view active alarms, historical alarms, and PID module running information.

You can view the following information on the alarm information screen:

- Tap an alarm record and view the alarm details.
- Swipe right or left on the screen or tap either **Active Alarm** or **Historical Alarm** to display a list of active alarms or historical alarms.

 **NOTE**

- Tap  to set the alarm sorting mode for active alarms or historical alarms.
- Tap  to set a time criterion. The historical alarms generated within the time segment are displayed.

**----End**


## 7.6.2 Settings

### 7.6.2.1 Setting Protection Parameters

#### Procedure

- Step 1** On the home screen, choose **Settings > Protection Parameters** to access the parameter setting screen.

**Figure 7-15** Protection parameters



**Table 7-4** Parameter description

No.	Parameter	Description	Unit	Remarks
1	Maximum output voltage	Specifies the highest step-up voltage of the PID module in normal or commissioning mode.	V	<p>The default value is 500 V. For the 1500 V SUN2000, the recommended value is 800 V.</p> <ul style="list-style-type: none"> <li>For the 1000 V/1100 V SUN2000, the value ranges from 0 V to 550 V. The parameter value indicates the maximum DC step-up voltage between PV and the ground.</li> <li>For the 1500 V SUN2000, the value ranges from 0 V to 800 V. The parameter value indicates the maximum DC step-up voltage between PV and the ground.</li> </ul>
2	AC-to-ground resistance alarm threshold	Specifies the alarm threshold for the impedance between the AC side of the PID module and the ground.	kΩ	You can set an alarm threshold for the impedance between the AC grid and the ground for the PID module. If the detected impedance is below the threshold, the PID module will generate an alarm.

No.	Parameter	Description	Unit	Remarks
3	Maximum system DC-to-ground withstand voltage	Specifies the voltages between the PV side and the ground and between the AC side and the ground in normal mode.	V	Specifies the lower threshold of the maximum voltage range between the solar inverter DC side (including the solar inverter, PV module, cable, SPD, and switch) and the ground.  The default value is 1000 V. For the 1500 V SUN2000, the recommended value is 1500 V.


----End

## 7.6.2.2 Setting Feature Parameters

### Procedure

- Step 1** On the home screen, choose **Settings > Feature Parameters** to access the parameter setting screen.

**Figure 7-16** Feature parameters





**Table 7-5** Parameter description

No.	Parameter	Description	Unit	Remarks
1	Offset mode	Specifies the compensation mode of the PID module.	-	<ul style="list-style-type: none"> <li>Select <b>Disable</b> if the PID module is not required.</li> <li>Select <b>N/PE</b> if the PID module is required to use voltage output from the power grid.</li> </ul>
2	Compensation offset voltage	Specifies the compensation offset voltage between PV and the ground after the PID module operates stably.	V	<ul style="list-style-type: none"> <li>If <b>PV module compensation voltage direction</b> is set to <b>PV– positive offset</b>, this parameter specifies the positive voltage between PV– and the ground.</li> <li>If <b>PV module compensation voltage direction</b> is set to <b>PV+ negative offset</b>, this parameter specifies the negative voltage between PV+ and the ground.</li> </ul> <p><b>NOTE</b> If <b>Compensation offset voltage</b> is set to 500 V, the PID module provides the maximum output to enhance the voltage compensation effect. The output voltage amplitude of the PID module is automatically capped to ensure the safety of a PV plant. The output voltage amplitude is also related to the maximum system DC-to-ground withstand voltage and maximum output voltage.</p>
3	PV module compensation voltage direction	Specifies the offset direction of the PID module.	-	For the specific PV module compensation type, consult the PV module vendor. For example, P-type PV modules, HIT, CIS, thin-film PV modules, and CdTe PV modules meet the requirement for PV– positive offset.
4	Modbus version number	Specifies the version number of the Modbus protocol of the PID module.	-	-

No.	Parameter	Description	Unit	Remarks
5	IMD access	Specifies whether the PID module and insulation monitor device (IMD) can operate in cycle mode.	-	<ul style="list-style-type: none"> <li>Select <b>Enable</b> if you allow the PID module and IMD to operate in cycle mode.</li> </ul> <p>Only the IMDs of mainstream suppliers such as DOLD and BENDER are supported, and the IMDs must have enabled dry contacts.</p> <p><b>NOTICE</b> You can set <b>Periodic PID runtime</b> and <b>Periodic IMD runtime</b> only when <b>IMD access</b> is set to <b>Enable</b>.</p> <ul style="list-style-type: none"> <li>Select <b>Disable</b> if you forbid the access of IMDs.</li> </ul>
6	Periodic PID runtime	Specifies the operating duration of the PID module when the PID module and IMD operate in cycle mode.	min	The IMD is shut down when the PID module is operating.
7	Periodic IMD runtime	Specifies the operating duration of the IMD when the PID module and IMD operate in cycle mode.	min	The PID module is standby when the IMD is operating.


----End

### 7.6.2.3 Setting User Parameters

#### Procedure

- Step 1** On the home screen, choose **Settings > User Parameters** to access the parameter setting screen.

**Figure 7-17** User parameters



**NOTE**

The password must meet the following requirements:

- Contains six characters.
- Contains at least two of the three types: lowercase letters, uppercase letters, and digits.


----End

## 7.6.2.4 Setting Communications Parameters

### Procedure

- Step 1** On the home screen, choose **Settings > Comm. Parameters** to access the parameter setting screen.
- Step 2** Tap **RS485** to set RS485 communications parameters.

**Figure 7-18** Communications parameters



----End

## 7.6.2.5 Setting a File Save Path

### Prerequisites

This function is available only on the Android system.

## Context

You can modify the save path for operation logs and PID module logs and export logs from the path.

## Procedure

**Step 1** On the home screen, choose **Settings > File Save Path** to access the path setting screen.

**Figure 7-19** File save path



**Step 2** Tap **File save path** to set a file save path.

----End

## 7.6.3 Maintenance

### 7.6.3.1 Log Download


## Context

On the **Device Logs** screen, you can export operation logs and PID logs from the mobile phone.

## Procedure

**Step 1** On the home screen, tap **Device Logs** to access the log download screen.

**Figure 7-20** Downloading logs



**Step 2** Download log files as required.

**NOTE**

- By default, Android system logs are saved in the **storage/emulated/0/inverterapp** folder in the phone memory. You can change the save path by referring to "Setting a File Save Path".
- The downloaded solar inverter logs are saved at the **Device Log** directory in **File Manager** in your mobile phone. You can also send the logs to your mailbox for checking.


----End

## 7.6.3.2 System Maintenance

### Procedure


**Step 1** On the home screen, tap **Maintenance** to access the maintenance screen.

**Figure 7-21** Maintenance



**Step 2** Tap **Setting work mode** to set working mode parameters.

**Figure 7-22** Setting work mode



**Step 3** Tap  next to **Power on**, **Power off**, **Reset**, **Data clear**, or **Restore defaults** as required.

 **NOTE**

- If you clear data, active and historical alarms stored on the PID module will all be cleared.
- Tap **Performance Data** to view the performance data curve of the PID module.

**Step 4** Enter the password for logging in to the app, and tap **OK**.

----End

### 7.6.3.3 Device Upgrade


#### Prerequisites

Obtain the upgrade package from your supplier or Huawei engineers.

## Procedure

- Step 1** Copy the upgrade package to your mobile phone without decompressing the package.
- Step 2** Tap **Upgrade** to access the PID module upgrade screen. Upgrade the software version of the device as required.

**Figure 7-23** PID Upgrade



----End

## 7.6.3.4 Feedback


### Context

Users can provide feedback in text, pictures, and files.


#### NOTE

Do not add private data.

## Procedure


- Step 1** Choose  > **Feedback** in the upper-right corner of the home screen.

**Figure 7-24** Feedback



- Step 2** Tap **Specify the type** and select **Feedback** or **Suggestion**.

**Figure 7-25** Problem record



**Step 3** Briefly describe the problem that you encounter in the **Description** column.

**Step 4** (Optional) Tap  to upload pictures or logs.

**Step 5** (Optional) Tap  to upload logs. Select device logs or app logs as required.

**Step 6** Tap **Submit**.


----End

### 7.6.3.5 Help

#### Context


If you have any questions when using an involved device or the app, search for solutions in the help information.

#### Procedure

**Step 1** Choose  > **Help** in the upper-right corner of the home screen.




**Figure 7-26 Help**



**Step 2** Specify your question. A solution will be displayed.

**Figure 7-27 Help 2**



----End

### 7.6.3.6 About


#### Context

You can query the app version, connected product model, SN, firmware version, software version, technical support website, privacy policy (displayed only on the SUN2000 app), customer service contact information, and open source software policy.


#### NOTE

- When the app starts for the first time after being downloaded or updated, the privacy policy is displayed. You can use the app only after agreeing to the privacy policy, and the privacy policy will no longer appear. If you do not agree to the privacy policy, the app exits, and the privacy policy is still displayed when you start the app next time until you agree to the privacy policy.
- You can revoke the agreed privacy policy.

#### Procedure

**Step 1** In the upper-right corner of the home screen, choose  > **About** to view the app version, connected product model, SN, firmware version, software version, and technical support website.

**Figure 7-28** About



**Step 2** Tap **Privacy policy**, **Customer service contact information**, or **Open source software policy** to view the privacy policy, customer service contact information, and open source software policy.

----End


## 7.7 Screen Operations (Special User)

### 7.7.1 Query

#### Procedure

**Step 1** After logging in to the app, you can view the PID module working mode and compensation mode on the home screen.

**Figure 7-29** Home screen





**Step 2** Tap **Alarms** or **Running Info.** to view active alarms, historical alarms, and PID module running information.

You can view the following information on the alarm information screen:

- Tap an alarm record and view the alarm details.
- Swipe right or left on the screen or tap either **Active Alarm** or **Historical Alarm** to display a list of active alarms or historical alarms.

**NOTE**

- Tap  to set the alarm sorting mode for active alarms or historical alarms.
- Tap  to set a time criterion. The historical alarms generated within the time segment are displayed.

**---End**


## 7.7.2 Settings

### 7.7.2.1 Setting User Parameters

#### Procedure

- Step 1** On the home screen, choose **Settings** > **User Parameters** to access the parameter setting screen.

**Figure 7-30** User parameters



#### NOTE

The password must meet the following requirements:

- Contains six characters.
- Contains at least two of the three types: lowercase letters, uppercase letters, and digits.

----End

### 7.7.2.2 Setting a File Save Path

#### Prerequisites

This function is available only on the Android system.

#### Context

You can modify the save path for operation logs and PID module logs and export logs from the path.

#### Procedure

- Step 1** On the home screen, choose **Settings** > **File Save Path** to access the path setting screen.

**Figure 7-31** File save path



- Step 2** Tap **File save path** to set a file save path.

----End

## 7.7.3 Maintenance

### 7.7.3.1 Log Download


#### Context

On the **Device Logs** screen, you can export operation logs and PID logs from the mobile phone.

#### Procedure

**Step 1** On the home screen, tap **Device Logs** to access the log download screen.

**Figure 7-32** Downloading logs



**Step 2** Download log files as required.

#### NOTE

- By default, Android system logs are saved in the **storage/emulated/0/inverterapp** folder in the phone memory. You can change the save path by referring to "Setting a File Save Path".
- The downloaded solar inverter logs are saved at the **Device Log** directory in **File Manager** in your mobile phone. You can also send the logs to your mailbox for checking.

----End

## 7.7.3.2 System Maintenance

### Procedure

**Step 1** On the home screen, tap **Maintenance** to access the maintenance screen.

**Figure 7-33 Maintenance**



**Step 2** Tap  next to **Power on**, **Power off**, or **Data clear** as required.

#### NOTE

- If you clear data, active and historical alarms stored on the PID module will all be cleared.
- Tap **Performance Data** to view the performance data curve of the PID module.

**Step 3** Enter the password for logging in to the app, and tap **OK**.

----End

## 7.7.3.3 Device Upgrade

### Prerequisites


Obtain the upgrade package from your supplier or Huawei engineers.

### Procedure

**Step 1** Copy the upgrade package to your mobile phone without decompressing the package.

**Step 2** Tap **Upgrade** to access the PID module upgrade screen. Upgrade the software version of the device as required.

**Figure 7-34 PID Upgrade**



----End

## 7.7.3.4 Feedback


### Context

Users can provide feedback in text, pictures, and files.


#### NOTE

Do not add private data.

### Procedure


**Step 1** Choose  > **Feedback** in the upper-right corner of the home screen.

**Figure 7-35** Feedback




**Step 2** Tap **Specify the type** and select **Feedback** or **Suggestion**.

**Figure 7-36** Problem record



**Step 3** Briefly describe the problem that you encounter in the **Description** column.

**Step 4** (Optional) Tap  to upload pictures or logs.

**Step 5** (Optional) Tap  to upload logs. Select device logs or app logs as required.

**Step 6** Tap **Submit**.


----End

## 7.7.3.5 Help


### Context

If you have any questions when using an involved device or the app, search for solutions in the help information.

### Procedure


**Step 1** Choose  > **Help** in the upper-right corner of the home screen.

**Figure 7-37** Help



**Step 2** Specify your question. A solution will be displayed.

**Figure 7-38** Help 2



----End



## 7.7.3.6 About


### Context

You can query the app version, connected product model, SN, firmware version, software version, technical support website, privacy policy (displayed only on the SUN2000 app), customer service contact information, and open source software policy.


#### NOTE

- When the app starts for the first time after being downloaded or updated, the privacy policy is displayed. You can use the app only after agreeing to the privacy policy, and the privacy policy will no longer appear. If you do not agree to the privacy policy, the app exits, and the privacy policy is still displayed when you start the app next time until you agree to the privacy policy.
- You can revoke the agreed privacy policy.

### Procedure

- Step 1** In the upper-right corner of the home screen, choose  > **About** to view the app version, connected product model, SN, firmware version, software version, and technical support website.

**Figure 7-39** About




- Step 2** Tap **Privacy policy**, **Customer service contact information**, or **Open source software policy** to view the privacy policy, customer service contact information, and open source software policy.

----End

# 8 SUN2000 APP Tool Kit

You can download the upgrade package for the distributed solar inverter, scan the solar inverter SN bar code, and set a local maintenance script for the solar inverter, SmartLogger, or PID module using the tool kit without logging in to the app.

**Figure 8-1** Tool kit



## 8.1 Device Software Update


### Context

Only the upgrade package of a distributed solar inverter can be downloaded.

### Procedure

**Step 1** On the app connection screen, tap  > **Download device software** in the upper-right corner.

**Figure 8-2** Tool kit



**Step 2** If an update of device upgrade package is detected, confirm to download it.

**Step 3** Tap **Download** on the screen for downloading the upgrade package.

----End

 **NOTE**

After the distributed solar inverter is connected, the system prompts you to install the upgrade package. Perform operations as prompted.

## 8.2 MBUS Whitelist


### Prerequisites

- Tools such as the diagonal pliers, grease pen, Android smartphone (with the SUN2000 app installed) are available.
- You have collected SN labels.


### NOTICE

- The solar inverter without an LCD allows you to collect and scan the SN bar code.
- When using diagonal pliers to cut off the SN bar code label suspended under a solar inverter, mark its device name on the back of the label to ensure mapping between the solar inverter name and SN bar code. The SN label position of the SUN2000-33KTL is shown in [Figure 8-3](#), and that of the SUN2000-50KTL is shown in [Figure 8-4](#).

**Figure 8-3** SN label position on the SUN2000-33KTL




**Figure 8-4** SN label position on the SUN2000-50KTL




## Context

The SN bar codes of solar inverters are obtained in centralized mode. These bar codes help set up mapping between solar inverter names and SN bar codes on the SmartLogger and assist the SmartLogger to communicate with the solar inverters and commission them.

## Procedure

- Step 1** Choose  > **MBUS whitelist** on the app connection screen. On the **MBUS whitelist** screen, enter a user-defined file name and tap **Next**.

**Figure 8-5** MBUS whitelist




### NOTE

If the SN file already exists, open and scan the file.

- Step 2** On the **SN List** screen, tap **Scan** or **Manual input** to record SN bar codes or QR codes and device names.


**Figure 8-6** SN list



- Method 1: Scan
  - a. Tap **Scan** and specify a scanning mode to start scanning. Ensure that the camera is about 15 cm away from the SN label or QR code.
  - b. After scanning, enter the device number at the back of the scanned label on the **SN Details** screen.
- Method 2: Manual input

- a. Tap **Manual input**. On the **SN Details** screen, enter the SN bar code and the device name at the back of the label.
- b. Tap **OK** to save the SN information.

 **NOTE**

You can choose  > **MBUS Whitelist** to find the saved SN information file on the list of saved files.

----End

## Follow-up Procedure

- After scanning the SN bar code information file, you can choose **More > Device List** on the SmartLogger home page to modify the device information.
- Upload the scanned information file to the PC and rename the file as **DeviceInfo.csv**, which provides information when changing the device name and device address on the SmartLogger. For details, see *SmartLogger3000 User Manual*, *SmartLogger2000 User Manual* or *SmartLogger1000A User Manual*.

## 8.3 Local Maintenance Script

### 8.3.1 Solar Inverter Maintenance Script

#### Context

The solar inverter maintenance script is used to set commands for the solar inverter (or PID module). After the script file is copied to the USB flash drive, the solar inverter (or PID module) executes the maintenance script to import or export configuration, export data, and upgrade devices.

 **NOTE**


- The SUN2000-(8KTL-28KTL) does not support the function of generating the solar inverter maintenance script.
- Delete the script file immediately after use to reduce information disclosure risks.

#### Procedure

**Step 1** On the app connection screen, tap  > **Local maintenance script** to access the command setting screen.

**Step 2** In the **Local maintenance script** area, select **Inverter/PID**.

**Figure 8-7** Inverter command settings



**Step 3** Tap **Step 1** and select an operation as required.

**Step 4** Tap **Add** to add a step.

**Step 5** Repeat **Step 3–Step 4** to finish required operations.

**Step 6** Tap **Save**.

**Step 7** Enter the user name and password for logging in to the app, and then tap **OK** to save the maintenance script in your mobile phone.

**NOTE**

The name of the maintenance script file is **sun\_lmt\_mgr\_cmd.emap**. You can choose **Tool Kit > File Manager > Device Log** to delete or email the maintenance script.

----End

## 8.3.2 SmartLogger Maintenance Script

### Context


The SmartLogger maintenance script is used to set SmartLogger commands. After the script file is copied to the USB flash drive, the SmartLogger executes the script file to export SmartLogger logs, export or import all files, and upgrade the SmartLogger and BSP.

### Procedure

**Step 1** On the app connection screen, tap  > **Local maintenance script** to access the command setting screen.

**Step 2** Select **SmartLogger** for **Local maintenance script**.

**Figure 8-8** SmartLogger command settings



**Step 3** Tap **Step 1** and select an operation as required.

**Step 4** Tap **Add** to add a step.

**Step 5** Repeat [Step 3–Step 4](#) to finish required operations.

**Step 6** Tap **Save**.

**Step 7** Enter the user name and password for logging in to the app, and then tap **OK** to save the maintenance script in your mobile phone.

**NOTE**

The name of the maintenance script file is **logger\_lmt\_mgr\_cmd.emap**. You can choose **Tool Kit > File Manager > Device Log** to delete or email the maintenance script.

----End

## Follow-up Procedure


You can also log in to the app as an advanced user or a special user and choose **More > System Maintenance > SmartLogger Command Set** on the **Home** screen of the SmartLogger to set the parameters.

## 8.4 File Management

### Context


The file management function manages app operation logs, device logs, and generated script files and configuration files. You can delete the logs and files, send them to your mailbox, or export them using a Mac.

### Procedure

**Step 1** On the app connection screen, tap  > **File Manager** to access the **File Manager** screen.



**Figure 8-9** File management



**Step 2** To delete files, select one or more files and tap **Delete**.

**Step 3** To send files to your mailbox, select one or more files and tap **Send**.

----End

## 8.5 About


### Context

This screen is used to query the app version information, technical support website, privacy policy (displayed only on the SUN2000 app), customer service contact information, and open source software policy.


#### NOTE

- When the app starts for the first time after being downloaded or updated, the privacy policy is displayed. You can use the app only after agreeing to the privacy policy, and the privacy policy will no longer appear. If you do not agree to the privacy policy, the app exits, and the privacy policy is still displayed when you start the app next time until you agree to the privacy policy.
- You can revoke the agreed privacy policy.

## Procedure

**Step 1** On the app connection screen, tap  > **About** to view the app version information and technical support website.

**Figure 8-10** About



**Step 2** Tap **Privacy policy** or **Open source software policy** to view the privacy policy and open source software policy.

**----End**

# 9 Troubleshooting

**Table 9-1** Troubleshooting

No.	Symptom	Possible Cause	Solution
1	The app fails to be installed.	<ul style="list-style-type: none"> <li>The version of the mobile phone operating system is earlier than the required version.</li> <li><b>Allow Installation of apps from unknown sources</b> is not selected.</li> </ul>	<ul style="list-style-type: none"> <li>Upgrade the version of the mobile phone operating system.</li> <li>Choose <b>Settings &gt; Security</b> and select <b>Allow Installation of apps from unknown sources</b>.</li> </ul>
2	Communication failed.	<ol style="list-style-type: none"> <li>When the mobile phone is more than 5 m away from the devices, the Bluetooth module is disconnected.</li> <li>The USB data cable is incorrectly connected.</li> <li>The mobile phone or router is more than 5 meters away from the solar inverter, so the WiFi connection is disconnected.</li> </ol>	<ol style="list-style-type: none"> <li>Keep the mobile phone within 5 m away from the devices and reconnect the Bluetooth module.</li> <li>Reconnect the USB data cable.</li> <li>Keep the mobile phone or router within 5 meters of the solar inverter and reconnect the WiFi connection.</li> </ol>
3	The solar inverter cannot be obtained.	An error occurs in the WiFi connection to the app.	<ul style="list-style-type: none"> <li>If the solar inverter still cannot be obtained after several attempts, log out and try again.</li> <li>Check whether the WiFi connection is correct.</li> </ul>

No.	Symptom	Possible Cause	Solution
4	The message <b>Failed to connect to the Bluetooth. Try to connect to the system Bluetooth.</b> is displayed.	<ul style="list-style-type: none"> <li>The Bluetooth module is abnormal.</li> <li>The Bluetooth module is used.</li> </ul>	<ul style="list-style-type: none"> <li>Verify that the Bluetooth module works properly.</li> <li>Verify that the Bluetooth module is not used.</li> </ul>
5	The message <b>Enable Bluetooth connection.</b> is displayed.	The Bluetooth function is not enabled.	Enable the Bluetooth function.
6	The message <b>Failed to identify the device. Check whether the device is correctly connected.</b> is displayed.	<ul style="list-style-type: none"> <li>The WLAN module is abnormal.</li> <li>The WLAN module is used</li> </ul>	<ul style="list-style-type: none"> <li>Verify that the WLAN module works properly.</li> <li>Verify that the WLAN module is not used</li> </ul>
7	The message <b>Failed to connect to the inverter. Please reconnect it.</b> is displayed.	The mobile phone or router is more than 5 meters away from the solar inverter, or the WiFi signal is weak.	Ensure that the WiFi network is connected. Log out of the app and then log in again.
8	Data failed to be obtained during operations.	<ol style="list-style-type: none"> <li>The Bluetooth module is abnormal.</li> <li>The USB data cable is incorrectly connected.</li> <li>Connection to the solar inverter is disconnected.</li> </ol>	<ol style="list-style-type: none"> <li>Reseat the Bluetooth module.</li> <li>Reconnect the USB data cable.</li> <li>Connect to the solar inverter again.</li> </ol>
9	The MBUS scanning function cannot be used.	The app does not have the permission to use the camera.	Enable the app to use the camera.
10	The label information cannot be identified when the MBUS scanning function is being used.	<ul style="list-style-type: none"> <li>The scan position is incorrect, or the camera is too far away from the bar code.</li> <li>The light is insufficient.</li> <li>The label is blocked.</li> </ul>	<ul style="list-style-type: none"> <li>Adjust the scan position and ensure that the camera is 15 cm away from the label.</li> <li>Move the label to a place with sufficient light.</li> <li>Remove the blockage from the label.</li> </ul>
11	No upgrade package is available for an upgrade.	No upgrade package is saved in the mobile phone.	Save the upgrade package in the mobile phone.

No.	Symptom	Possible Cause	Solution
12	The battery of the mobile phone is too low.	N/A	Charge the mobile phone.
13	When you set parameters on the local commissioning tool and go to the <b>Add Plant</b> screen by following <b>Setup Wizard</b> , a message is displayed indicating that the network is abnormal.	<ol style="list-style-type: none"> <li>1. When you go to the <b>Add Plant</b> screen, the mobile phone is connected to the solar inverter WiFi but not to an available network.</li> <li>2. When you go to the <b>Add Plant</b> screen, the mobile phone is not connected to any network.</li> </ol>	Connect your phone to an available network.
14	The user fails to locate the position on the map.	<ol style="list-style-type: none"> <li>1. The GPS or network signal of the mobile phone is poor.</li> <li>2. The GPS function is not enabled on the phone.</li> </ol>	<ol style="list-style-type: none"> <li>1. You need to locate the position at a place with good network quality or with strong GPS signals.</li> <li>2. Enable the GPS function on the phone.</li> </ol>


# 10 FAQs

## 10.1 Setting the Email on the Mobile Phone

### Procedure


**Step 1** Find and tap **Email** on the phone.

**Figure 10-1** Home screen of the phone




**Step 2** Choose your email service provider from the list. If it is on the list already, directly choose it. If not, choose **Other** on the list.

**Figure 10-2** Adding an account




**Step 3** Specify the correct email address and password. Tap **Next** to authenticate.

**Figure 10-3** Setting the account




**Step 4** If **Account setup error** is displayed, confirm it and choose **Manual setup**.

**Figure 10-4** Manually setting an account



**Step 5** Choose the protocol type of the email server (POP3 by default).


**Figure 10-5** Setting the account type



**Step 6** After the configuration is completed, you can set the sending and receiving options of the email account.



**Figure 10-6** Setting the sending and receiving options



**Step 7** Tap **Next** to enter the mailbox. If you can receive and send emails, the email function of the SUN2000 APP is successfully enabled.


**NOTE**

The phone mailbox configuration interface will be different depending on the phone model. The actual mobile phone interface is subject to change.

----End

## 10.2 Changing the App Login Password

### Procedure

**Step 1** In the upper-right corner of the home screen, choose  > **Change password** to change the password.

**Figure 10-7** Changing the password



**Step 2** Specify **Old password**, **New password**, and **Confirm password**, and then tap **OK**.

 **NOTE**

The password must meet the following requirements:

- Contains six characters.
- Contains at least two of the three types: lowercase letters, uppercase letters, and digits.

----End

## 10.3 How Do I Set a User-Defined Grid Code

### Context

If the national grid code of the solar inverter is not in the list, you can customize a grid code.

### Procedure

**Step 1** On the home screen, choose **Settings** > **Grid Parameters** to access the parameter setting screen.

**Step 2** In the grid code drop-down list, tap **Custom** to deliver the settings to the device.

**Table 10-1** User-defined grid code

User-defined Grid Code	Default Output Mode	Phase Voltage Level Vn(V)	Line Voltage Level Vn(V)	Frequency Level Fn(Hz)
Custom(50Hz)	Three-phase four-wire	230	400	50
Custom(60Hz)	Three-phase four-wire	230	400	60
Custom-MV480(50Hz)	Three-phase three-wire	277	480	50
Custom-MV480(60Hz)	Three-phase three-wire	277	480	60

 **NOTE**

Select a user-defined grid code (**Custom**) based on the voltage and frequency of the local power grid system.

**Step 3** Set the power grid, protection, feature, or power adjustment parameters on the **Settings** screen based on the local power grid requirements.

For details about the parameter settings for commercial solar inverters, see [A Commercial Smart Inverters Parameters](#).

For details about the parameter settings for distributed solar inverters, see [4.7 Settings](#).

----End

## 10.4 How Do I Fix WLAN Connection Failure

Symptom	Possible Cause	Suggestion
WLAN connection failure	The WLAN network is not allowed.	Forget the WLAN network from the WLAN list in the phone system and reconnect to the network. The screen varies depending on the phone model.
	You have entered an incorrect WLAN password.	Forget the WLAN network from the WLAN list in the phone system and reconnect to the network using the correct password. The screen varies depending on the phone model.
	The WLAN network is being used by another phone.	Wait for the other phone to exit or restart the WLAN network.
	The WLAN hotspot is automatically disabled because it is not used for a long time after connection.	Restart the WLAN network and search again.

### NOTE

If you cannot rectify faults with the measures listed in the "Suggestion" column, contact your dealer or Huawei technical support.

# A Commercial Smart Inverters Parameters

## A.1 Grid parameters

### A.1.1 Advanced User

Parameter	Description
Grid Code	Set this parameter based on the grid code of the country or region where the inverter is used and the inverter application scenario.
Isolation settings	Set the working mode of the inverter based on the grounding status at DC side and the connection to the power grid.

### A.1.2 Special User

Parameter	Description
Grid Code	Set this parameter based on the grid code of the country or region where the inverter is used and the inverter application scenario.
Isolation settings	Set the working mode of the inverter based on the grounding status at DC side and the connection to the power grid.
Output mode	Specifies whether the inverter output has a neutral wire based on the application scenario.
PQ mode	If this parameter is set to <b>PQ mode 1</b> , the maximum AC output power equals the maximum apparent power. If this parameter is set to <b>PQ mode 2</b> , the maximum AC output power equals the rated output power.
Automatically start upon grid recovery	Specifies whether to allow the inverter to automatically start after the power grid recovers.
Grid connected recovery time from grid faults (s)	Specifies the time after which the inverter begins restarting after the power grid recovers.

Parameter	Description
Startup voltage lower threshold of grid connection (V)	According to the standards of certain countries and regions, after the inverter is powered on for the first time for grid connection, if the power grid voltage is lower than <b>Startup voltage lower threshold of grid connection</b> , the inverter is not allowed to connect to the grid.
Startup frequency upper threshold of grid connection (Hz)	According to the standards of certain countries and regions, after the inverter is powered on for the first time for grid connection, if the power grid voltage is higher than <b>Startup frequency upper threshold of grid connection</b> , the inverter is not allowed to connect to the grid.
Startup frequency lower threshold of grid connection (Hz)	According to the standards of certain countries and regions, after the inverter is powered on for the first time for grid connection, if the power grid voltage is lower than <b>Startup frequency lower threshold of grid connection</b> , the inverter is not allowed to connect to the grid.
Grid reconnection voltage upper limit (V)	The standards of certain countries and regions require that after the inverter shuts down for protection due to a fault, if the power grid voltage is higher than <b>Grid reconnection voltage upper limit</b> , the inverter is not allowed to reconnect to the grid.
Grid reconnection voltage lower limit (V)	The standards of certain countries and regions require that after the inverter shuts down for protection due to a fault, if the power grid voltage is lower than <b>Grid reconnection voltage lower limit</b> , the inverter is not allowed to reconnect to the grid.
Grid reconnection frequency upper limit (Hz)	The standards of certain countries and regions require that after the inverter shuts down for protection due to a fault, if the power grid frequency is higher than <b>Grid reconnection frequency upper limit</b> , the inverter is not allowed to reconnect to the grid.
Grid reconnection frequency lower limit (Hz)	The standards of certain countries and regions require that after the inverter shuts down for protection due to a fault, if the power grid frequency is lower than <b>Grid reconnection frequency lower limit</b> , the inverter is not allowed to reconnect to the grid.
Reactive power compensation (cosφ-P) trigger voltage (%)	Specifies the voltage threshold for triggering reactive power compensation based on the cosφ-P curve.
Reactive power compensation (cosφ-P) exit voltage (%)	Specifies the voltage threshold for exiting reactive power compensation based on the cosφ-P curve.

## A.2 Protection Parameters

### A.2.1 Advanced User

Parameter	Description
Insulation resistance protection threshold (M $\Omega$ )	To ensure device safety, the inverter detects the insulation resistance of the input side with respect to ground when it starts a self-check. If the detected value is less than the preset value, the inverter does not connect to the grid.

### A.2.2 Special User

Parameter	Description
Voltage unbalance protection threshold (%)	Specifies the inverter protection threshold when the power grid voltage is unbalanced.
Phase protection point (°)	The Japanese standard requires that during passive islanding detection, protection should be triggered if an abrupt voltage phase change is detected.
Phase angle offset protection	The standards of certain countries and regions require that the inverter needs to be protected when the phase angle offset of the power grid three phases exceeds a certain value.
10-min overvoltage protection threshold (V)	Specifies the 10-minute overvoltage protection threshold.
10-min overvoltage protection duration (ms)	Specifies the 10-minute overvoltage protection duration.
Level-1 overvoltage protection threshold (V)	Specifies the level-1 overvoltage protection threshold.
Level-1 overvoltage protection duration (ms)	Specifies the level-1 overvoltage protection duration.
Level-2 overvoltage protection threshold (V)	Specifies the level-2 overvoltage protection threshold.
Level-2 overvoltage protection duration (ms)	Specifies the level-2 overvoltage protection duration.
Level-3 overvoltage protection threshold (V)	Specifies the level-3 overvoltage protection threshold.
Level-3 overvoltage protection duration (ms)	Specifies the level-3 overvoltage protection duration.
Level-4 overvoltage protection threshold (V)	Specifies the level-4 overvoltage protection threshold.
Level-4 overvoltage protection duration (ms)	Specifies the level-4 overvoltage protection duration.

Parameter	Description
Level-5 overvoltage protection threshold (V)	Specifies the level-5 overvoltage protection threshold.
Level-5 overvoltage protection duration (ms)	Specifies the level-5 overvoltage protection duration.
Level-6 overvoltage protection threshold (V)	Specifies the level-6 overvoltage protection threshold.
Level-6 overvoltage protection duration (ms)	Specifies the level-6 overvoltage protection duration.
Level-1 undervoltage protection threshold (V)	Specifies the level-1 undervoltage protection threshold.
Level-1 undervoltage protection duration (ms)	Specifies the level-1 undervoltage protection duration.
Level-2 undervoltage protection threshold (V)	Specifies the level-2 undervoltage protection threshold.
Level-2 undervoltage protection duration (ms)	Specifies the level-2 undervoltage protection duration.
Level-3 undervoltage protection threshold (V)	Specifies the level-3 undervoltage protection threshold.
Level-3 undervoltage protection duration (ms)	Specifies the level-3 undervoltage protection duration.
Level-4 undervoltage protection threshold (V)	Specifies the level-4 undervoltage protection threshold.
Level-4 undervoltage protection duration (ms)	Specifies the level-4 undervoltage protection duration.
Level-5 undervoltage protection threshold (V)	Specifies the level-5 undervoltage protection threshold.
Level-5 undervoltage protection duration (ms)	Specifies the level-5 undervoltage protection duration.
Level-6 undervoltage protection threshold (V)	Specifies the level-6 undervoltage protection threshold.
Level-6 undervoltage protection duration (ms)	Specifies the level-6 undervoltage protection duration.
Level-1 overfrequency protection threshold (Hz)	Specifies the level-1 overfrequency protection threshold.
Level-1 overfrequency protection duration (ms)	Specifies the level-1 overfrequency protection duration.
Level-2 overfrequency protection threshold (Hz)	Specifies the level-2 overfrequency protection threshold.

Parameter	Description
Level-2 overfrequency protection duration (ms)	Specifies the level-2 overfrequency protection duration.
Level-3 overfrequency protection threshold (Hz)	Specifies the level-3 overfrequency protection threshold.
Level-3 overfrequency protection duration (ms)	Specifies the level-3 overfrequency protection duration.
Level-4 overfrequency protection threshold (Hz)	Specifies the level-4 overfrequency protection threshold.
Level-4 overfrequency protection duration (ms)	Specifies the level-4 overfrequency protection duration.
Level-5 overfrequency protection threshold (Hz)	Specifies the level-5 overfrequency protection threshold.
Level-5 overfrequency protection duration (ms)	Specifies the level-5 overfrequency protection duration.
Level-6 overfrequency protection threshold (Hz)	Specifies the level-6 overfrequency protection threshold.
Level-6 overfrequency protection duration (ms)	Specifies the level-6 overfrequency protection duration.
Level-1 underfrequency protection threshold (Hz)	Specifies the level-1 underfrequency protection threshold.
Level-1 underfrequency protection duration (ms)	Specifies the level-1 underfrequency protection duration.
Level-2 underfrequency protection threshold (Hz)	Specifies the level-2 underfrequency protection threshold.
Level-2 underfrequency protection duration (ms)	Specifies the level-2 underfrequency protection duration.
Level-3 underfrequency protection threshold (Hz)	Specifies the level-3 underfrequency protection threshold.
Level-3 underfrequency protection duration (ms)	Specifies the level-3 underfrequency protection duration.
Level-4 underfrequency protection threshold (Hz)	Specifies the level-4 underfrequency protection threshold.
Level-4 underfrequency protection duration (ms)	Specifies the level-4 underfrequency protection duration.
Level-5 underfrequency protection threshold (Hz)	Specifies the level-5 underfrequency protection threshold.
Level-5 underfrequency protection duration (ms)	Specifies the level-5 underfrequency protection duration.



Parameter	Description
Level-6 underfrequency protection threshold (Hz)	Specifies the level-6 underfrequency protection threshold.
Level-6 underfrequency protection duration (ms)	Specifies the level-6 underfrequency protection duration.

## A.3 Feature parameters

### A.3.1 Advanced User

Parameter	Description	Remarks
MPPT multi-peak scanning	When the inverter is used in scenarios where PV strings are greatly shaded, set this parameter to <b>Enable</b> , and then the inverter will perform MPPT scanning at regular intervals to locate the maximum power.	-
MPPT multi-peak scan interval (min)	Specifies the MPPT scanning interval.	This parameter is displayed when <b>MPPT multi-peak scanning</b> is set to <b>Enable</b> .
RCD enhancement	RCD refers to the residual current of the inverter to the ground. To ensure device and personal safety, RCD should be limited to the specified value in the standard. If an AC switch with a residual current detection function is installed outside the inverter, this function should be enabled to reduce the residual current generated when the inverter is running, thereby preventing the AC switch from misoperations.	-
Night-time reactive power output	In some specific application scenarios, a power grid company requires that the inverter can perform reactive power compensation at night to ensure that the power factor of the local power grid meets requirements.	This parameter is displayed when <b>Isolation settings</b> is set to <b>Input ungrounded, with TF</b> .
PID protection at night	When the inverter outputs reactive power at night and this parameter is set to <b>Enable</b> , the inverter will shut down automatically if it detects abnormal status of the PID compensation.	-
Strong adaptability	If the power grid short-circuit capacity or PV plant installed capacity is less than 3, the power grid quality will be affected if the power grid impedance is too high, which may cause the inverter to malfunction. In this case, if the inverter is required to work properly, set this parameter to <b>Enable</b> .	-

Parameter	Description	Remarks
Power quality optimization mode	If this parameter is set to <b>Enable</b> , the inverter output current harmonics will be optimized.	-
PV module type	This parameter is used to set different types of PV modules and the shutdown time of the concentration PV module. If the concentration PV modules are shaded, the power drops drastically to 0 and the inverter shuts down. The energy yield would be affected since it takes too long for the power to resume and inverter to restart. The parameter does not need to be set for crystalline silicon and filmy PV modules.	<ul style="list-style-type: none"> <li>If this parameter is set to <b>Crystalline silicon</b> or <b>Film</b>, the inverter automatically detects the power of PV modules when they are shaded and shuts down if the power is too low.</li> <li>When concentration PV modules are used: <ul style="list-style-type: none"> <li>If this parameter is set to <b>CPV 1</b>, the inverter can quickly restart in 60 minutes if the input power of PV modules drops drastically due to shading.</li> <li>If this parameter is set to <b>CPV 2</b>, the inverter can quickly restart in 10 minutes if the input power of PV modules drops drastically due to shading.</li> </ul> </li> </ul>
Built-in PID compensation direction	When the external PID module compensates the PID voltage for the PV system, set <b>Built-in PID compensation direction</b> to the actual compensation direction of the PID module so that the inverter can output reactive power at night.	This parameter is displayed when <b>PV module type</b> is set to <b>Crystalline silicon</b> . Select <b>PV-positive offset</b> for P-type PV modules. Select <b>PV+ negative offset</b> for N-type PV modules.
PID running mode	Specifies the operation mode of the inverter built-in PID.	-
PID nighttime off-grid repair	Specifies whether to enable the PID nighttime off-grid repair.	If <b>PID running mode</b> is not set to <b>Disable</b> , the parameter can be set.
PID daytime off-grid repair	Specifies whether to enable the PID daytime off-grid repair.	
String connection mode	Specifies the connection mode of PV strings.	<ul style="list-style-type: none"> <li>When PV strings connect to the inverter separately (All PV strings separated), there is no need to set this parameter. The inverter can automatically detect the connection mode of the PV strings.</li> <li>When PV strings connect to one another in parallel outside the inverter and then connect to it independently (All PV strings connected), set this parameter to <b>All PV strings connected</b>.</li> </ul>

Parameter	Description	Remarks
Automatic OFF due to communication interrupted	The standards of certain countries and regions require that the inverter must shut down after the communication is interrupted for a certain time.	If <b>Automatic OFF due to communication interrupted</b> is set to <b>Enable</b> and the inverter communication is interrupted for a specified time (set by <b>Communication interruption duration</b> ), the inverter will automatically shut down.
Communication interruption duration (min)	Specifies the duration for determining communication interruption. Used for automatic shutdown for protection in case of communication interruption.	-
Automatic ON due to communication resumed	If this parameter is set to <b>Enable</b> , the inverter automatically starts after communication recovers. If this parameter is set to <b>Disable</b> , the inverter needs to be started manually after communication recovers.	This parameter is displayed when <b>Automatic OFF due to communication interrupted</b> is set to <b>Enable</b> .
Soft start/boot time (s)	Specifies the duration for the power to gradually increase when the inverter starts.	-
Shutdown gradient (%/s)	Specifies the power change speed when the inverter shuts down.	-
AFCI	The North American standard requires that the inverter should have DC arc detection function.	-
AFCI detection adaptive mode	Adjusts the sensitivity of arc detection.	This parameter is displayed only when <b>AFCI</b> is set to <b>Enable</b> .
AFCI self-test	Send the AFCI self-check command manually.	-
Current error during the scan (A)	To prevent inaccurate scanning caused by sunlight change, the current change of PV strings operating properly should be monitored when the I-V curves of PV strings are being scanned. When the current exceeds the specified value, it is determined that the sunlight changes. The I-V curves should be scanned again.	-
OVGR associated shutdown	If this parameter is set to <b>Enable</b> , the inverter shuts down after receiving the OVGR signal. If this parameter is set to <b>Disable</b> , the inverter does not shut down after receiving the OVGR signal.	This parameter is displayed if the Japanese grid code is selected.
Dry contact function	Identifies the dry contact signals from the SmartLogger.	Set this parameter to <b>OVGR</b> for OVGR signals, and set it to <b>NC</b> for other signals. This parameter is displayed if the Japanese grid code is selected.

Parameter	Description	Remarks
Commanded shutdown hold after power recovery	The standards of certain countries and regions require that if the inverter is shut down after receiving a command and powered on again after power recovers, it should still be in commanded shutdown state.	-
Night-time hibernation	The inverter monitors PV strings at night. If this parameter is set to <b>Enable</b> , the monitoring function of the inverter will hibernate at night to reduce power consumption.	-
MBUS communication	For inverters that support RS485 communication and MBUS communication, you are advised to set this parameter to <b>Disable</b> to reduce power consumption.	-
RS485-2 communication	If this parameter is set to <b>Enable</b> , the RS485-2 port can be used. If the port is not used, you are advised to set this parameter to <b>Disable</b> to reduce power consumption.	-
Delay upgrade	This parameter is mainly used in the upgrade scenarios where the PV power supply is disconnected at night due to no sunlight or unstable at dawn or dusk due to poor sunlight.	After the inverter starts to upgrade, if <b>Delay upgrade</b> is set to <b>Enable</b> , the upgrade package is loaded first. After the PV power supply recovers and the activation conditions are met, the inverter automatically activates the upgrade.
String monitor	The inverter monitors PV strings in real time. If any PV string is abnormal (such as the PV string is shaded or the electric energy yield decreases), the inverter generates an alarm to remind maintenance personnel to maintain the PV string in a timely manner.	If PV strings are often shaded, you are advised to set <b>String monitor</b> to <b>Disable</b> to prevent false alarms.
String detection low power delay (min)	Specifies the delay time for generating abnormal string alarms when the inverter detects that a PV string is working with low power. This parameter is mainly used in the scenario where PV strings are shaded for a long time in the morning and evening, and is used to prevent false alarms.	This parameter is displayed when <b>String monitor</b> is set to <b>Enable</b> .
String detection high power delay (min)	Specifies the delay time for generating abnormal string alarms when the inverter detects that a PV string is working with high power.	
String detection power segment division percentage (%)	Specifies the thresholds for determining whether a PV string is working with high power or low power. This parameter is used to distinguish the working status of PV strings.	

Parameter	Description	Remarks
String detection reference asymmetric coefficient	Specifies the threshold for determining PV string exception. The false alarms caused by fixed shadow shading can be controlled by changing this parameter.	
String detection starting power percentage (%)	Specifies the threshold for starting PV string exception detection. The false alarms caused by fixed shadow shading can be controlled by changing this parameter.	
OFF at 0% power limit	If this parameter is set to <b>Enable</b> , the inverter shuts down after receiving the 0% power limit command. If this parameter is set to <b>Disable</b> , the inverter does not shut down after receiving the 0% power limit command.	-
Maximum apparent power (kVA)	Specifies the output upper threshold for the maximum apparent power to adapt to the capacity requirements of standard and customized inverters.	If the maximum active power equals the value of Smax_limit, this parameter is not displayed.
Maximum active power (kW)	Specifies the output upper threshold for the maximum active power to adapt to different market requirements.	For 1000 V inverters, this parameter is configurable only for the SUN2000-25KTL-US, and the maximum value is 27.5 kW.
Tracker controller	Selects a controller vendor.	-
Adjust total energy yield (kWh)	Specifies the initial energy yield of the inverter. This parameter is used in inverter replacement scenarios. Set the initial energy yield of the new inverter to the total energy yield of the old inverter to ensure continuous statistics of cumulative energy yield.	-
Duration for determining short-time grid disconnection (ms)	The standards of certain countries and regions require that the inverter should not disconnect from the power grid if the power grid experiences a short-time failure. After the fault is rectified, the inverter output power needs to be quickly restored.	-
Buzzer	If this parameter is set to <b>Enable</b> , the buzzer sounds when the DC input cable is incorrectly connected. If this parameter is set to <b>Disable</b> , the buzzer does not sound when the DC input cable is incorrectly connected.	-

## A.3.2 Special User

Parameter	Description	Remarks
Automatic OFF due to communication interrupted	The standards of certain countries and regions require that the inverter must shut down after the communication is interrupted for a certain time.	If <b>Automatic OFF due to communication interrupted</b> is set to <b>Enable</b> and the inverter communication is interrupted for a specified time (set by <b>Communication interruption duration</b> ), the inverter will automatically shut down.
Communication interruption duration (min)	Specifies the duration for determining communication interruption. Used for automatic shutdown for protection in case of communication interruption.	-
Automatic ON due to communication resumed	If this parameter is set to <b>Enable</b> , the inverter automatically starts after communication recovers. If this parameter is set to <b>Disable</b> , the inverter needs to be started manually after communication recovers.	This parameter is displayed when <b>Automatic OFF due to communication interrupted</b> is set to <b>Enable</b> .
Soft start/boot time (s)	Specifies the duration for the power to gradually increase when the inverter starts.	-
LVRT	LVRT is short for low voltage ride-through. When the grid voltage is abnormally low for a short time, the inverter cannot disconnect from the power grid immediately and has to work for some time.	-
Threshold for triggering LVRT (V)	Specifies the threshold for triggering LVRT. The threshold settings should meet the local grid standard.	This parameter is displayed when <b>LVRT</b> is set to <b>Enable</b> .
LVRT reactive power compensation factor	During LVRT, the inverter needs to generate reactive power to support the power grid. This parameter is used to set the reactive power generated by the inverter.	<ul style="list-style-type: none"> <li>This parameter is displayed when <b>LVRT</b> is set to <b>Enable</b>.</li> <li>For example, if this parameter is set to <b>2</b>, the reactive power generated by the inverter is 20% of the rated power when the AC voltage drops by 10% during LVRT.</li> </ul>
HVRT	HVRT is short for high voltage ride-through. When the grid voltage is abnormally high for a short time, the inverter cannot disconnect from the power grid immediately and has to work for some time.	-
Threshold for triggering HVRT (V)	Specifies the threshold for triggering HVRT. The threshold settings should meet the local grid standard.	This parameter is displayed when <b>HVRT</b> is set to <b>Enable</b> .

Parameter	Description	Remarks
HVRT reactive power compensation factor	During HVRT, the inverter needs to generate reactive power to support the power grid. This parameter is used to set the reactive power generated by the inverter.	
VRT exit hysteresis threshold	Specifies the LVRT/HVRT recovery threshold.	<ul style="list-style-type: none"> <li>This parameter is displayed when <b>LVRT</b> or <b>HVRT</b> is set to <b>Enable</b>.</li> <li>LVRT recovery threshold = Threshold for triggering LVRT + VRT exit hysteresis threshold</li> <li>HVRT recovery threshold = Threshold for triggering HVRT + VRT exit hysteresis threshold</li> </ul>
LVRT undervoltage protection shield	Specifies whether to shield the undervoltage protection function during LVRT.	This parameter is displayed when <b>LVRT</b> is set to <b>Enable</b> .
Grid voltage protection shield during VRT	Specifies whether to shield the undervoltage protection function during LVRT or HVRT.	This parameter is displayed when <b>LVRT</b> or <b>HVRT</b> is set to <b>Enable</b> .
Grid voltage jump triggering threshold (%)	Specifies the LVRT or HVRT threshold for triggering a transient voltage jump of a power grid. A transient voltage jump indicates that the inverter cannot immediately disconnect from the power grid when the power grid is abnormal due to transient changes.	This parameter is available when <b>Grid code</b> is set to <b>VDE 4120</b> .
Zero current due to power grid fault	Certain countries and regions have requirements on the output current during high/low voltage ride-through. In this case, set this parameter to <b>Enable</b> . After this parameter is set to <b>Enable</b> , the output current is less than 10% of the rated current during high/low voltage ride-through.	This parameter is displayed when <b>LVRT</b> or <b>HVRT</b> is set to <b>Enable</b> .
Active islanding protection	Specifies whether to enable the active islanding protection function.	-
Passive islanding protection	Specifies whether to enable the passive islanding protection function.	This parameter is displayed if the Japanese grid code is selected.
Voltage rise suppression	The standards of certain countries and regions require that when the output voltage exceeds a certain value, the inverter must suppress voltage rise by outputting reactive power and reducing active power.	-
Voltage rise suppressing reactive power adjustment point (%)	The standards of certain countries and regions require that the inverter generate a certain amount of reactive power when the output voltage exceeds a certain value.	<ul style="list-style-type: none"> <li>This parameter is displayed when <b>Voltage rise suppression</b> is set to <b>Enable</b>.</li> <li>The value of <b>Voltage rise suppressing active power derating</b></li> </ul>

Parameter	Description	Remarks
Voltage rise suppressing active power derating point (%)	The standards of certain countries and regions require that the active power of the inverter be derated according to a certain slope when the output voltage exceeds a certain value.	<b>point</b> must be greater than that of <b>Voltage rise suppressing reactive power adjustment point</b> .
Voltage rise suppression P-U curve	The standards of certain countries and regions require that the P-U curve be set.	This parameter is displayed when <b>Voltage rise suppression</b> is set to <b>Enable</b> .
Voltage rise suppression Q-U curve	The standards of certain countries and regions require that the Q-U curve be set.	
Frequency change rate protection	Set this parameter to <b>Enable</b> to protect the inverter when the grid frequency changes too fast.	-
Frequency change rate protection threshold (Hz/s)	Specifies the frequency change rate protection threshold.	This parameter is displayed if <b>Frequency change rate protection</b> is set to <b>Enable</b> .
Frequency change rate protection duration (s)	The inverter is protected when the grid frequency change duration exceeds the value.	
Soft start time after grid failure (s)	Specifies the time for the power to gradually increase when the inverter restarts after the power grid recovers.	-

## A.4 Power adjustment parameters

### A.4.1 Special User

Parameter	Description	Remarks
Remote power schedule	If this parameter is set to <b>Enable</b> , the inverter responds to the scheduling instruction from the remote port. If this parameter is set to <b>Disable</b> , the inverter does not respond to the scheduling instruction from the remote port.	-
Schedule instruction valid duration (s)	Specifies the time for maintaining the scheduling instruction.	When this parameter is set to 0, the scheduling instruction takes effect permanently.
Maximum apparent power (kVA)	Specifies the output upper threshold for the maximum apparent power to adapt to the capacity requirements of standard and customized inverters.	If the maximum active power equals the value of <b>Smax_limit</b> , this parameter is not displayed.



Parameter	Description	Remarks
Maximum active power (kW)	Specifies the output upper threshold for the maximum active power to adapt to different market requirements.	-
OFF at 0% power limit	If this parameter is set to <b>Enable</b> , the inverter shuts down after receiving the 0% power limit command. If this parameter is set to <b>Disable</b> , the inverter does not shut down after receiving the 0% power limit command.	-
Active power change gradient (%/s)	Specifies the change speed of the inverter active power.	-
Derated by fixed active power (kW)	Adjusts the active power output of the inverter by fixed value.	This parameter is displayed if <b>Remote power schedule</b> is set to <b>Enable</b> . For 1000 V inverters, the maximum value of this parameter for the SUN2000-25KTL-US is 27.5 kW.
Derated by active power % (%)	Adjusts the active power output of the inverter by percentage.	This parameter is displayed if <b>Remote power schedule</b> is set to <b>Enable</b> . If this parameter is set to <b>100</b> , the inverter outputs based on the maximum output power.
Reactive power change gradient (%/s)	Specifies the change speed of the inverter reactive power.	-
Plant active power gradient (min/100%)	Specifies the rate of active power rise due to sunlight changes.	-
Average active power filtering time (ms)	Specifies the period of active power rise due to sunlight changes. This parameter is used with <b>Plant active power gradient</b> .	-
PF (U) voltage detection filtering time (s)	Specifies the time for filtering the grid voltage in the PF-U curve.	-
Reactive power adjustment time (s)	Specifies the adjustment time for the reactive power to reach the target value during reactive power adjustment.	-
Power factor	Specifies the power factor of the inverter.	This parameter is displayed if <b>Remote power schedule</b> is set to <b>Enable</b> .
Reactive power compensation (Q/S)	Specifies the reactive power output by the inverter.	
Night-time reactive power compensation (Q/S)	During the reactive power compensation at night, the reactive power is scheduled by percentage.	-

Parameter	Description	Remarks
Night-time reactive power output	In some specific application scenarios, a power grid company requires that the inverter can perform reactive power compensation at night to ensure that the power factor of the local power grid meets requirements.	This parameter is displayed when <b>Isolation settings</b> is set to <b>Input ungrounded, with TF</b> .
Enable reactive power parameters at night	When this parameter is set to <b>Enable</b> , the inverter outputs reactive power based on the setting of <b>Reactive power compensation at night</b> . Otherwise, the inverter executes the remote scheduling command.	This parameter is displayed when <b>Night-time reactive power output</b> is set to <b>Enable</b> .
Night-time reactive power compensation (kVar)	During the reactive power compensation at night, the reactive power is scheduled by fixed value.	This parameter is displayed when <b>Night-time reactive power output</b> and <b>Enable reactive power parameters at night</b> are set to <b>Enable</b> .
Overfrequency derating	If this parameter is set to <b>Enable</b> , the active power of the inverter will be derated according to a certain slope when the grid frequency exceeds the frequency that triggers overfrequency derating.	-
Frequency for triggering overfrequency derating (Hz)	The standards of certain countries and regions require that the output active power of inverters be derated when the power grid frequency exceeds a certain value.	<ul style="list-style-type: none"> <li>• This parameter is displayed when <b>Overfrequency derating</b> is set to <b>Enable</b>.</li> <li>• When setting this parameter, ensure that the following condition is met: <b>Frequency for exiting overfrequency derating</b> ≤ <b>Frequency for triggering overfrequency derating</b> &lt; <b>Cutoff frequency of overfrequency derating</b>.</li> </ul>
Frequency for exiting overfrequency derating (Hz)	Specifies the frequency threshold for exiting overfrequency derating.	
Cutoff frequency of overfrequency derating (Hz)	Specifies the frequency threshold for cutting off overfrequency derating.	
Cutoff power of overfrequency derating (%)	Specifies the power threshold for cutting off overfrequency derating.	
Frequency detection filtering time (ms)	Specifies the frequency detection filter time.	
Overfrequency derating power drop gradient (%/s)	Specifies the decrease rate of the overfrequency derating power.	
Power recovery gradient of overfrequency derating (%/min)	Specifies the recovery rate of the overfrequency derating power.	

Parameter	Description	Remarks
Voltage derating	If this parameter is set to <b>Enable</b> , the active power of the inverter will be derated according to a certain slope when the grid voltage exceeds the voltage that triggers overfrequency derating.	-
Voltage derating start point (V)	Specifies the start point for voltage derating.	<ul style="list-style-type: none"> <li>This parameter is displayed when <b>Voltage derating</b> is set to <b>Enable</b>.</li> <li>When setting this parameter, ensure that the following condition is met: <b>Voltage derating start point &lt; Voltage derating stop point</b>.</li> </ul>
Cut-off point of voltage derating (V)	Specifies the stop point for voltage derating.	
Voltage derating cut-off power (V)	Specifies the power threshold for cutting off voltage derating.	
Communication disconnection fail-safe	In the inverter export limitation scenario, if this parameter is set to <b>Enable</b> , the inverter will perform active power derating by percentage when the communication between the inverter and the SmartLogger or Smart Dongle is disconnected for more than the time specified by <b>Communication disconnection detection time</b> .	N/A
Communication disconnection detection time (s)	Specifies the fail-safe detection time for the disconnection between the inverter and the SmartLogger or Smart Dongle.	This parameter is displayed when <b>Communication disconnection fail-safe</b> is set to <b>Enable</b> .
Active power output limit for fail-safe (%)	Specifies the derating value of the inverter active power by percentage.	
Apparent power baseline (kVA)	Adjusts the apparent output baseline of the inverter.	-
Active power baseline (kW)	Adjusts the active output baseline of the inverter.	-
Frequency modulation control	The standards of certain countries and regions require that if the power grid frequency fluctuates around a certain value, the inverter needs to fine-tune the active power output based on <b>Frequency modulation control droop</b> to help stabilize the power grid frequency. In this case, set this parameter to <b>Enable</b>	-
Adjustment ratio of frequency modulation control	Specifies the droop of the active power output.	This parameter is displayed when <b>Frequency modulation control</b> is set to <b>Enable</b> .
Underfrequency rise power	The standards of certain countries and regions require that if the power grid frequency is lower than <b>Frequency for triggering of underfrequency rise power</b> , the inverter needs to increase the active power output to help increase the power grid frequency. In this case, set this parameter to <b>Enable</b> .	-

Parameter	Description	Remarks
Frequency for triggering of underfrequency rise power (Hz)	Specifies the frequency threshold of <b>Underfrequency rise power</b> .	This parameter is displayed when <b>Underfrequency rise power</b> is set to <b>Enable</b> .
Power recovery gradient of underfrequency rise (%/min)	Specifies the recovery rate of <b>Underfrequency rise power</b> .	
Cutoff frequency of underfrequency rise power (Hz)	Specifies the cutoff frequency of <b>Underfrequency rise power</b> .	
Cutoff power of underfrequency rise power (%)	Specifies the cutoff power of <b>Underfrequency rise power</b> .	
Frequency for exiting of underfrequency rise power (Hz)	Specifies the exit frequency of <b>Underfrequency rise power</b> .	
Q-U characteristic curve mode	Specifies the reactive power compensation mode of the inverter output.	-
Power percentage for triggering Q-U scheduling	Specifies the reference apparent power, in percentage. When the actual apparent power of the inverter is greater than the value of this parameter, the Q-U characteristic curve scheduling function is enabled.	-
Q-U characteristic curve	The inverter adjusts Q/S (the ratio of the output reactive power to apparent power) in real time based on U/Un(%) (the ratio of the actual power grid voltage to the rated power grid voltage).	-
Q-P characteristic curve	The inverter adjusts Q/Pn (the ratio of the output reactive power to the rated active power) in real time based on P/Pn(%) (the ratio of the actual active power to the rated active power).	-
Cosφ-P/Pn characteristic curve	The inverter adjusts the output power factor cosφ in real time based on P/Pn(%).	-

## A.5 Grid-tied control parameters

### Special User

**Table A-1** Grid-tied control parameters

Parameter	Description
Active power control mode	Specifies the active power output mode at the grid-tied point.
Closed-loop controller	Specifies the grid-tied power controller. Before setting the parameter, confirm the controller type. Incorrect setting will result in abnormal power output of the solar inverter. <b>Solar inverter</b> applies only to the scenario where a single solar inverter is used or where a single solar inverter is used with an SDongle.
Limitation mode	Specifies the active power limitation mode as required by the power grid.
PV plant capacity (kW)	Specifies the PV array capacity.
Maximum grid feed-in power (kW)	In <b>Grid connection with limited power (kW)</b> mode, set the maximum power fed to the power grid from the PV array.
Maximum grid feed-in power (%)	In <b>Grid connection with limited power (%)</b> mode, set the proportion of the maximum power fed to the power grid from the PV array to the capacity of the PV plant.
Power adjustment period (s)	Specifies the interval for sending adjustment commands.
Maximum protection time (s)	Specifies the protection duration to determine whether the communication between the external controller and the Smart Power Sensor is interrupted.
Power control hysteresis (kW)	Specifies the dead zone for adjusting the inverter output power. If the power fluctuation is within the power control hysteresis, the power is not adjusted.
Fail-safe power threshold (%)	When the communication between the SDongle/SmartLogger, power meter, and solar inverter is interrupted, the solar inverter generates power based on this threshold.
Reactive power control mode	Specifies the reactive power output mode at the grid-tied point.
Power factor	Specifies the target power factor of the power meter.
Adjustment period (s)	Specifies the interval for sending adjustment commands.
Adjustment deadband	Specifies the adjustment power factor precision.
Fail-safe power factor	When the communication between the SDongle/SmartLogger, power meter, and solar inverter is interrupted, the solar inverter generates power based on this threshold.
Communication disconnection fail-safe	When this parameter is set to <b>Enable</b> , and the communication between the solar inverter and the SDongle/SmartLogger is interrupted for a certain period (set by <b>Communication disconnection detection time</b> ), the solar inverter generates power based on <b>Fail-safe power</b> .

<b>Parameter</b>	<b>Description</b>
Communication disconnection detection time (s)	Specifies the protection duration to determine whether the communication between the SDongle/SmartLogger and the solar inverter is interrupted.

# B Domain Name List of Management Systems

 **NOTE**

The list is subject to change.

**Table B-1** Domain names of management systems

Domain Name	Data Type	Scenario
intl.fusionsolar.huawei.com	Public network address	FusionSolar hosting cloud <b>NOTE</b> Compatible with the former FusionSolar hosting cloud domain name cn.fusionsolar.huawei.com for the Chinese mainland.
neteco.alsoenergy.com	Public network address	Partner's management system
re-ene.kyuden.co.jp	Public network address	Remote output control server of Kyushu Electric Power Company
re-ene.yonden.co.jp	Public network address	Remote output control server of Shikoku Electric Power Company
eu.fusionsolar.huawei.com	Public network address	Network management system NetEco in Europe
au1.fusionsolar.huawei.com	Public network address	Network management system NetEco in Australia
br1.fusionsolar.huawei.com	Public network address	Network management system NetEco in Brazil
huawei.devicedataacquisition.com	Public network address	Third-party network management system Locus dedicated for the United States

# C Acronyms and Abbreviations

---

## A

<b>AFCI</b>	arc-fault circuit-interrupter
<b>APP</b>	application

## L

<b>LCD</b>	liquid crystal display
------------	------------------------

## M

<b>MBUS</b>	monitoring bus
-------------	----------------

## P

<b>PID</b>	potential induced degradation
<b>PV</b>	photovoltaic

## S

<b>SD</b>	secure digital memory card
-----------	----------------------------